

SPARE PARTS CATALOGUE

TRIMMERS/EDGERS: HUSQVARNA 110IL SANS BATTERIE NI CHARGEUR


Spare Parts List

SPARE PARTS LIST

TRIMMERS/EDGERS

HUSQVARNA 110IL SANS BATTERIE NI
CHARGEUR


A 110iL
HOUSING



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
1	531147295	CARTER	Housing Kit
2	531147296	BOUTON	Spring button kit
3	531147297	DÉCLENCHÉUR	Trigger kit
4	531147298	CARTER	
5	531147299	VIS	Screw multipack 10pcs

foretjardin.com


E 110iL
TRIMMER HEAD



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
1	531147301	TETE DE COUPE	Trimmer head Assy
2	531147302	BOUTON	Button kit
3	531147303	CARTER	Upper cover
4	531147304	LIGNE DE COUPE	
5	531147305	BOBINE DE FIL A ALIMENTATION MANUELLE	
6	531147306	CARTER	Lower cover

ForêtJardin.com


B 110iL
TUBE



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
2	531147308	TUBE ASSY	Al tube assy
3	531147309	ATTACHE	Coupler, upper
4	531147310	TUBE ASSY	Al tube assy
5	531147311	POIGNEE COMPLETE	D shape handle Assy


foretjardin.com

C 110iL
ELECTRICAL



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
1	531147283	CARTE DES CIRCUITS	PCBA and UI key pad assy
2	531147284	CLE DE BLOCAGE	
3	531147285	MICRO INTERRUPTEUR	
4	531147286	CARTER	UI plastic part
5	503212906	VIS CCRPANT	ST2.9 x 6

D 110iL
HEAD ASSY



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
1	531147287	KIT COUVERCLE	
2	531147288	BUTTON KIT	Rotating button kit
3	531147289	CARTER	Motor housing kit
4	531147290	SECATEURS	
5	531147291	PROTECTEUR	Plant protector
6	531147292	PROTECTEUR	Stone Guard
7	531147293	COUTEAU	Cutting blade kit
8	531147294	WHEEL KIT	Edger wheel kit
9	531147299	VIS	Screw multipack 10pcs

ForêtJardin.com