




SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

LC 153, 96131003701, 2015-12



Référence	Numéro de Pièce	Description	Remarque
1	532 42 68-12	GUIDE-CHAÎNE	
2	583 84 86-03	POIGNÉE	
3	532 43 97-19	POIGNÉE	
4	581 90 21-01	GUIDE	
5	581 91 26-01	BOUTON	
7	532 06 64-26	HOOP	
8	874 78 05-12	VIS	
11	532 41 53-50	CABLE DE CONTRÔLE	
12	532 17 88-48	VIS	
13	532 43 00-34	SUPPORT	
15	532 05 17-93	PIN RETAINING SCREW	
18	817 60 04-06	VIS	
19	532 40 66-89	AXE	FRONT, LEFT
20	532 40 66-90	AXE	FRONT, RIGHT
21	532 43 61-19	PROTECTEUR	
22	532 40 64-28	RESSORT	
23	581 42 56-01	PORTE	
25	588 91 24-06	ENSEMBLE DE SUPPORT DE POIGNEE	LH
26	588 91 24-03	ENSEMBLE DE SUPPORT DE POIGNEE	RH
28	817 06 04-10	VIS	
29	532 41 05-94	WHEEL ADJ BRACKET FRONT	
30	532 40 16-29	RONDELLE D'ESPACEMENT	
32	532 44 15-59	RESSORT	
33	532 70 10-37	BOUTON	
34	588 91 26-02	BRAS	
35	532 42 65-89	ÉCROU	
36	532 40 16-38	BOULON	
37	532 41 31-83	WHEEL AND TIRE ASSY, REAR	
39	532 40 91-49	ÉCROU	
40	532 41 19-49	CADRE	
42	532 40 54-21	RESSORT	LH
43	532 40 54-23	RESSORT	RH
44	532 18 41-93	BOULON	
45	532 15 04-06	BOULON	
46	532 18 21-66	DECAL	
47	873 75 11-53	ÉCROU	
48	588 91 26-02	BRAS	
49	588 26 86-02	ROUE	
50	581 00 21-04	BAC DE RAMASSAGE COMPLET	
52	532 44 19-82	KIT	
53	532 85 10-84	VIS	
54	532 85 02-63	RONDELLE	
55	532 85 10-74	RONDELLE	
56	532 19 93-77	MOWER BLADE	
57	581 54 79-01	ADAPTATEUR	
59	000 00 00-00	W/O DESCRIPTION	B&S 93J02-0078-H1 FOR SERVICE & PARTS 1-800-233-3723
61	532 40 91-48	ÉCROU	
65	532 08 83-48	RONDELLE	
66	532 19 74-80	JOINT TORIQUE	
73	532 40 16-30	RONDELLE	
74	532 12 50-78	RONDELLE	
76	532 41 05-89	BAFFLE.REAR.PLASTIC.21.RD.ECON	
77	817 41 13-12	VIS	
78	532 19 92-55	STYLO	
79	532 75 11-53	LOCKNUT 5/16-18 RL550HVA	
80	532 43 06-79	BOUTON	
82	532 18 23-98	BOUTON	
83	532 42 85-01	PLAQUE	
84	817 00 05-10	BOULON	
	532 18 21-91	LABEL WARNING	NOT SHOWN
	581 00 67-04	SAC	NOT SHOWN