




SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

LC140 S, 967636801, 2016-09




BAC DE RAMASSAGE

LC140 S, 967636801, 2016-09


Référence	Numéro de Pièce	Description	Remarque
1	587 58 63-01	GRASSBAG	
2	587 58 60-01	CARTER	
3	587 91 18-01	SUPPORT	
4	587 91 21-01	VIS	
5	587 58 61-01	POIGNÉE	
6	587 91 23-01	VIS	

HANDLE



Référence	Numéro de Pièce	Description	Remarque
1	587 91 33-01	ECROU HEXAGONAL	
2	587 58 58-01	BOUTON	
3	502 27 59-01	POIGNÉE	
4	502 25 87-01	BAGUE D'ESPACEMENT	
5	502 25 99-01	BOULON	
6	502 42 99-01	BOULON	
7	587 91 35-01	BOULON DE BLOCAGE	
8	501 05 57-01	SUPPORT	
9	502 40 21-01	BOULON	
10	501 05 54-01	CARTER	
11	502 51 77-01	POIGNÉE	
12	587 91 40-01	BOULON	
13	502 27 58-01	CROCHET	
14	587 91 44-01	ANNEAU	
15	502 43 42-01	RONDELLE DU RESSORT	
16	587 91 32-01	ÉCROU	
17	502 40 18-01	CÂBLE	
18	502 40 56-01	BLOC	
19	501 05 53-01	PLAQUE	
20	502 40 67-01	CARTER	
21	501 05 52-01	BARRE	
22	502 40 54-01	TROLLEY	
23	502 40 66-01	TROLLEY	
24	502 40 11-01	CABLE ASSEMBLE	

ENGINE




MOTEUR

LC140 S, 967636801, 2016-09

Référence	Numéro de Pièce	Description	Remarque
1	587 91 38-01	BOULON DE BLOCAGE	
2	587 91 07-01	RONDELLE	
3	587 38 63-10	COUTEAU	
4	587 91 12-01	SUPPORT DE LAME	
5	587 91 54-01	DOUILLE	
6	587 91 02-01	BUSHING	
7	587 91 53-01	BROCHE PLATE	
8	587 91 20-01	POULIE	
9	587 91 28-01	VIS	
10	587 90 96-01	COURROIE	
11	587 91 22-01	VIS	
12	587 91 26-01	VIS	
13	587 90 98-01	CARTER	
14	587 91 34-01	LOCK NUT	
15	587 90 88-01	PLAQUE	
16	587 91 37-01	BOULON	
17	587 91 11-01	JOINT	
18	587 91 35-01	BOULON DE BLOCAGE	
19	587 91 61-01	MOTEUR	
20	587 91 24-01	VIS	
21	587 58 49-01	COUVERCLE	
22	579 68 51-01	BOULON	
23	587 90 99-01	SEGMENT	
24	579 68 52-01	ÉCROU	
25	587 91 00-01	CARTER	
26	587 91 13-01	PLAQUE DE GUIDAGE	
27	587 91 41-01	BOULON	
28	587 91 39-01	BOULON	
29	579 68 79-01	ÉCROU	
30	587 91 51-01	RESSORT	
31	502 23 10-01	BARRE	
32	587 91 50-01	SUPPORT	
33	587 58 59-01	CLAPET	
34	501 05 56-01	PLAQUE	
35	501 05 44-01	SUPPORT	
36	501 05 47-01	SUPPORT	
37	501 05 55-01	PLAQUE	

MOWER DECK



Référence	Numéro de Pièce	Description	Remarque
1	587 58 50-01	COUVERCLE DE ROUE	
2	587 58 52-01	COUVERCLE DE ROUE	
3	587 91 35-01	BOULON DE BLOCAGE	
4	587 91 29-01	ROULEMENT	
5	587 58 54-01	ROUE	
6	587 91 46-01	RONDELLE	
7	587 91 15-01	AXE	
8	587 91 25-01	VIS	
9	587 91 10-01	PLAQUE DE FIXATION	
10	587 90 97-01	CIRCLIPS	
11	587 58 51-01	COUVERCLE DE ROUE	
12	587 58 53-01	COUVERCLE DE ROUE	
13	587 58 55-01	ROUE	
14	587 91 01-01	ROUE D'ENGRENAGE	
15	587 91 21-01	VIS	
16	587 58 62-01	CARTER	
17	587 91 27-01	RONDELLE	
18	587 91 16-01	AXE	
19	502 23 05-01	POIGNEE COMPLÈTE	
20	587 58 57-01	BOUTON	
21	587 91 48-01	RONDELLE	
22	587 91 31-01	BOULON DE BLOCAGE	
23	587 91 08-01	RONDELLE	
24	587 91 26-01	VIS	
25	587 99 35-01	RONDELLE	
26	587 99 25-01	JOINT TORIQUE	
27	587 91 09-01	PLAQUE DE FIXATION	
28	587 91 34-01	LOCK NUT	
29	502 23 06-01	BIELLE	
30	587 91 58-01	TUBING	
31	587 91 49-01	RESSORT	
32	587 91 47-01	RONDELLE	
33	587 91 57-01	ENGRENAGE COMPLET	
34	587 91 45-01	RONDELLE	
35	587 91 30-01	ROULEMENT	
36	587 91 55-01	CARTER	
37	587 91 52-01	AXE	
38	587 90 87-01	BOITE A VITESSE	
39	587 91 56-01	ENGRENAGE COMPLET	