

SPARE PARTS CATALOGUE
CHAIN SAWS: ELECTRIC: HUSQVARNA 317


Spare Parts List

SPARE PARTS LIST

CHAIN SAWS: ELECTRIC


HUSQVARNA 317

C *compl 508 04 23-23



PXM_REF	PXM_PARTNO	DESCRIPTION
508 04 23-23	508042323	OEILLET
735 31 08-21	735310821	CIRCLIP
508 04 62-03	508046203	VIS
508 04 60-01	508046001	DÉ DE TENSION DE CHAÎNE
508 04 62-02	508046202	VIS
508 03 09-01	508030901	VIS
508 04 22-20	508042220	SUPPORT
738 21 01-02	738210102	ROULEMENT À BILLES
725 24 57-76	725245776	VIS EHHM
508 04 54-51	508045451	BRAS
508 04 34-02	508043402	STYLO
508 04 54-20	508045420	LEVIER
508 04 54-40	508045440	BRAS
508 04 54-30	508045430	LEVIER
508 04 34-01	508043401	STYLO
508 04 63-01	508046301	RESSORT
508 04 77-16	508047716	PIN RETAINING SCREW

F



PXM_REF	PXM_PARTNO	DESCRIPTION
508 03 19-10	508031910	RÉSERVOIR
508 04 35-08	508043508	JOINT
508 04 35-05	508043505	JOINT TORIQUE
508 04 35-03	508043503	JOINT TORIQUE
508 04 33-14	508043314	POMPE À HUILE
508 04 35-06	508043506	JOINT
508 03 18-12	508031812	RÉSERVOIR

foretjardin.com

G

 **Husqvarna**



Electric

321

—508 03 86-17

508 03 86-16—

 **Husqvarna**



Electric

321

 **Husqvarna**



Electric

317

—508 03 86-19

508 03 86-18—

 **Husqvarna**




Electric

317

PXM_REF	PXM_PARTNO	DESCRIPTION
508 03 86-17	508038617	DECAL
508 03 86-19	508038619	DECAL
508 03 86-18	508038618	DECAL
508 03 86-16	508038616	DECAL

for
et
jardin.com


E 321



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
508 04 37-02	508043702	ROUE D'ENGRENAGE	
508 04 27-20	508042720	DOUILLE	
508 04 55-30	508045530	RONDELLE	
503 20 07-12	503200712	VIS IHSCFM	
508 04 51-07	508045107	ENGRENAGE	3/8 X6T

for
et
jardin.com



A



PXM_REF	PXM_PARTNO	DESCRIPTION
508 04 31-04	508043104	TUBULAR HANDLE
508 04 46-30	508044630	LEVIER
508 04 46-50	508044650	LEVIER
508 04 46-61	508044661	BRAS
508 04 46-42	508044642	LEVIER
508 04 30-22	508043022	FORET
508 04 42-40	508044240	CARTER
508 04 43-40	508044340	CARTER
508 03 09-01	508030901	VIS
508 03 12-01	508031201	VIS
508 04 44-09	508044409	JOINT
508 04 62-02	508046202	VIS
731 23 18-51	731231851	ECROU HEXAGONAL
508 04 77-01	508047701	RONDELLE D'ESPACEMENT
508 04 45-20	508044520	CARTER

H Accessories

Zubehöre
Accessoires
Acessorios
Tillbehör



PXM_REF	PXM_PARTNO	DESCRIPTION
508 03 80-02	508038002	CLE ALLEN
501 83 44-09	501834409	BAR COVER

Forêtjardin.com


D 317



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
508 04 37-02	508043702	ROUE D'ENGRENAGE	
508 04 55-01	508045501	PLAQUE	
725 63 29-51	725632951	VIS IHCSFM	
508 04 64-01	508046401	CARRIER	
508 04 58-00	508045800	RONDELLE	
508 04 51-07	508045107	ENGRENAGE	3/8 X6T
508 04 55-20	508045520	RONDELLE	
508 04 27-10	508042710	RONDELLE D'ESPACEMENT	

foretjardin.com

B *compl 508 04 36-51 (321)
 *compl 508 04 36-50 (317)



CHAIN SAWS: ELECTRIC

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
508 04 36-51	508043651	MOTEUR	321
508 04 36-50	508043650	MOTEUR	317
508 04 37-07	508043707	RESSORT	
508 04 37-05	508043705	BROSSE	
508 03 41-20	508034120	BRAKER	317
508 04 69-13	508046913	CONDENSATEUR	317
508 03 38-01	508033801	CABLE ASSEMBLE	EU
508 03 39-01	508033901	CABLE ASSEMBLE	CH
508 03 40-12	508034012	CABLE ASSEMBLE	UK
508 03 40-03	508034003	CABLE ASSEMBLE	AUS, NZ
508 03 42-04	508034204	DOUILLE	
508 03 43-20	508034320	INTERRUPTEUR	
508 04 38-55	508043855	CÂBLE	317
508 04 54-05	508045405	BRAKER	
508 04 38-56	508043856	CABLE ASSY	317
508 04 38-57	508043857	CABLE ASSY	317
508 04 54-10	508045410	PLAQUE	
508 04 39-46	508043946	PRINTED CIRCUIT CARD	321