

SPARE PARTS CATALOGUE
CHAIN SAWS: ELECTRIC: HUSQVARNA 321

foretjardin.com


Spare Parts List

SPARE PARTS LIST

CHAIN SAWS: ELECTRIC

HUSQVARNA 321

E 321



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
508 04 37-02	508043702	ROUE D'ENGRENAGE		
508 04 27-20	508042720	DOUILLE		
508 04 55-30	508045530	RONDELLE		
503 20 07-12	503200712	VIS IHSCFM		
508 04 51-07	508045107	ENGRENAGE	3/8 -6T	

foretjardin.com

G

 **Husqvarna** —508 03 86-17

Electric 321

508 03 86-16—

 **Husqvarna**

Electric 321

 **Husqvarna** —508 03 86-19

Electric 317

508 03 86-18—


 **Husqvarna**

Electric 317

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
508 03 86-17	508038617	DECAL		
508 03 86-16	508038616	DECAL		
508 03 86-19	508038619	DECAL		
508 03 86-18	508038618	DECAL		

foretjardin.com


D 317



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
508 04 37-02	508043702	ROUE D'ENGRENAGE		
508 04 27-10	508042710	RONDELLE D'ESPACEMENT		
508 04 55-01	508045501	PLAQUE		
725 63 29-51	725632951	VIS IHCSFM		
508 04 64-01	508046401	CARRIER		
508 04 58-00	508045800	RONDELLE		
508 04 51-07	508045107	ENGRENAGE	3/8 -6T	
508 04 55-20	508045520	RONDELLE		

foretjardin.com

C



CHAIN SAWS: ELECTRIC

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
508 04 23-23	508042323	OEILLET		
735 31 08-21	735310821	CIRCLIP		
508 04 62-03	508046203	VIS		
508 04 60-01	508046001	DÉ DE TENSION DE CHÂÎNE		
508 04 62-02	508046202	VIS		
508 03 09-01	508030901	VIS		
508 04 22-20	508042220	SUPPORT		
738 21 01-02	738210102	ROULEMENT À BILLES		
725 24 57-76	725245776	VIS EHHM		
508 04 54-50	508045450	LEVIER		
508 04 34-02	508043402	STYLO		
508 04 54-20	508045420	LEVIER		
508 04 54-40	508045440	BRAS		
508 04 54-30	508045430	LEVIER		
508 04 34-01	508043401	STYLO		
508 04 63-01	508046301	RESSORT		
508 04 77-16	508047716	PIN RETAINING SCREW		


H Accessories

Zubehöre

Accessoires

Acessorios


Tilbehör



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
508 03 80-02	508038002	CLE ALLEN		
501 83 44-09	501834409	BAR COVER		

foretjardin.com


B



CHAIN SAWS: ELECTRIC

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
508 04 36-51	508043651	MOTEUR	321	
508 04 36-50	508043650	MOTEUR	317	
508 04 37-07	508043707	RESSORT		
508 04 37-05	508043705	BROSSE		
508 03 41-20	508034120	BRAKER	317	
508 04 69-13	508046913	CONDENSATEUR	317	
508 03 38-01	508033801	CABLE ASSEMBLE	EU	
508 03 39-01	508033901	CABLE ASSEMBLE	CH	
508 03 40-12	508034012	CABLE ASSEMBLE	UK	
508 03 40-03	508034003	CABLE ASSEMBLE	AUS, NZ	
508 03 42-04	508034204	DOUILLE		
508 03 43-20	508034320	INTERRUPTEUR		
508 04 39-46	508043946	PRINTED CIRCUIT CARD	321	
508 04 38-55	508043855	CÂBLE	317	
508 04 54-05	508045405	BRAKER		
508 04 38-56	508043856	CABLE ASSY	317	
508 04 38-57	508043857	CABLE ASSY	317	
508 04 54-10	508045410	PLAQUE		

A




CHAIN SAWS: ELECTRIC

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
508 04 31-04	508043104	TUBULAR HANDLE		
508 04 46-30	508044630	LEVIER		
508 04 46-50	508044650	LEVIER		
508 04 46-60	508044660	LEVIER		
508 03 09-01	508030901	VIS		
508 03 12-01	508031201	VIS		
508 04 62-02	508046202	VIS		
731 23 18-51	731231851	ECROU HEXAGONAL		
508 04 77-01	508047701	RONDELLE D'ESPACEMENT		
508 04 45-20	508044520	CARTER		
508 04 44-09	508044409	JOINT		
508 04 43-40	508044340	CARTER		
508 04 46-40	508044640	LEVIER		
508 04 30-20	508043020	BARRE		
508 04 42-40	508044240	CARTER		

foretjardin.com

F



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
508 03 19-10	508031910	RÉSERVOIR		
508 04 35-08	508043508	JOINT		
508 04 35-05	508043505	JOINT TORIQUE		
508 04 33-14	508043314	POMPE À HUILE		
508 04 35-03	508043503	JOINT TORIQUE		
508 04 35-06	508043506	JOINT		
508 03 18-12	508031812	RÉSERVOIR		

foretjardin.com