

SPARE PARTS CATALOGUE
CHAIN SAWS: ELECTRIC: HUSQVARNA 321

foretjardin.com


Spare Parts List

SPARE PARTS LIST

CHAIN SAWS: ELECTRIC

HUSQVARNA 321


B *compl 508 04 36-51 (321)
 *compl 508 04 36-50 (317)



CHAIN SAWS: ELECTRIC

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK	QTY.
508 04 36-51	508043651	MOTEUR	321	
508 04 36-50	508043650	MOTEUR	317	
508 04 37-07	508043707	RESSORT		
508 04 37-05	508043705	BROSSE		
508 04 69-14	508046914	CONDENSATEUR	317	
508 03 38-01	508033801	CABLE ASSEMBLE	EU	
508 03 39-01	508033901	CABLE ASSEMBLE	CH	
508 03 40-12	508034012	CABLE ASSEMBLE	UK	
508 03 40-03	508034003	CABLE ASSEMBLE	AUS, NZ	
508 03 42-04	508034204	DOUILLE		
508 03 43-20	508034320	INTERRUPTEUR		
508 03 41-20	508034120	BRAKER	317	
508 04 38-57	508043857	CABLE ASSY	317	
508 04 38-55	508043855	CÂBLE	317	
508 04 54-05	508045405	BRAKER		
508 04 38-56	508043856	CABLE ASSY	317	
508 04 54-10	508045410	PLAQUE		
508 04 39-46	508043946	PRINTED CIRCUIT CARD	321	

C *compl 508 04 23-23



CHAIN SAWS: ELECTRIC



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
508 04 23-23	508042323	OEILLET	
735 31 08-21	735310821	CIRCLIP	
508 04 62-03	508046203	VIS	
508 04 60-01	508046001	DÉ DE TENSION DE CHAÎNE	
508 04 62-02	508046202	VIS	
508 03 09-01	508030901	VIS	
508 04 22-20	508042220	SUPPORT	
738 21 01-02	738210102	ROULEMENT À BILLES	
725 24 57-76	725245776	VIS EHHM	
508 04 54-51	508045451	BRAS	
508 04 34-02	508043402	STYLO	
508 04 54-20	508045420	LEVIER	
508 04 54-40	508045440	BRAS	
508 04 54-30	508045430	LEVIER	
508 04 34-01	508043401	STYLO	
508 04 63-01	508046301	RESSORT	
508 04 77-16	508047716	PIN RETAINING SCREW	

D



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
508 04 37-02	508043702	ROUE D'ENGRENAGE	
508 04 55-01	508045501	PLAQUE	
508 04 62-06	508046206	LEVIER	
508 04 64-01	508046401	CARRIER	
508 04 58-00	508045800	RONDELLE	
508 04 51-07	508045107	ENGRENAGE	3/8 X6T
508 04 55-20	508045520	RONDELLE	
508 04 27-10	508042710	RONDELLE D'ESPACEMENT	


G Accessories
Zubehöre
Accessoires
Acessorios
Tillbehör



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
508 03 80-02	508038002	CLE ALLEN	
501 83 44-09	501834409	BAR COVER	

foretjardin.com

E



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
508 03 19-10	508031910	RÉSERVOIR	
508 04 35-08	508043508	JOINT	
508 04 35-05	508043505	JOINT TORIQUE	
508 04 35-03	508043503	JOINT TORIQUE	
508 04 33-14	508043314	POMPE À HUILE	
508 04 35-06	508043506	JOINT	
508 03 18-12	508031812	RÉSERVOIR	


foretjardin.com

F



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
508 03 86-17	508038617	DECAL	
508 03 86-19	508038619	DECAL	
508 03 86-18	508038618	DECAL	
508 03 86-16	508038616	DECAL	

A



CHAIN SAWS: ELECTRIC

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
508 04 31-04	508043104	TUBULAR HANDLE	
508 04 46-30	508044630	LEVIER	
508 04 46-50	508044650	LEVIER	
508 04 46-44	508044644	LEVIER	
508 04 01-10	508040110	NONAME	
508 04 42-40	508044240	CARTER	
508 04 62-02	508046202	VIS	
731 23 18-51	731231851	ECROU HEXAGONAL	
508 04 77-01	508047701	RONDELLE D'ESPACEMENT	
508 04 45-20	508044520	CARTER	
508 04 44-09	508044409	JOINT	
508 03 12-01	508031201	VIS	
508 03 09-01	508030901	VIS	
508 04 43-41	508044341	LEVIER	
508 04 24-10	508042410	LEVIER	