

HUSQVARNA - SPARE PARTS CATALOG

CHAIN SAWS: HUSQVARNA 120I


foretjardin.com

Sparepartslist

SPAREPARTSLIST

CHAIN SAWS

HUSQVARNA 120I




CHAIN SAWS

PXM_REF	PXM_PARTNO	DESCRIPTION
1	587426601	VIS
2	585602701	MOUNTING PLATE
3	585581301	FREIN
4	587600101	RESSORT
5	585819002	VIS
6	588162502	CARTER
7	585592501	VIS
8	585590201	POIGNÉE AVANT
9	585590001	BOUTON
10	585590101	RESSORT
11	585589801	DÉCLENCHÉUR
12	585589301	LEVIER
13	585931901	PIVOT
14	585566802	CARTER
15	505288501	CAPTEUR DE CHAÎNE
16	575309802	VIS
17	585818901	VIS
18	585592301	SUPPORT
19	582541501	CLE DE BLOCAGE
20	585636201	RESSORT
21	577996601	BOUTON-POUSOIR
22	585636001	BOUTON-POUSOIR
23	585636601	RESSORT
24	585593001	BOITIER DE LA BATTERIE
25	577844301	DECAL
26	582569301	CONNECTEUR
27	582712201	VIS
28	574223901	VIS
29	585819001	VIS
30	582486701	CARTER

E2 120i
HOUSING


HIGHER THAN S/N



CHAIN SAWS

PXM_REF	PXM_PARTNO	DESCRIPTION
1	587426601	VIS
2	85602701	TBD
3	585581301	FREIN
4	587600101	RESSORT
5	585819002	VIS
6	588162502	CARTER
7	585592501	VIS
8	585590201	POIGNÉE AVANT
9	585590001	BOUTON
10	585590101	RESSORT
11	585589801	DÉCLENCHEUR
12	585589301	LEVIER
13	585931901	PIVOT
14	585566802	CARTER
15	505288501	CAPTEUR DE CHAÎNE
16	575309802	VIS
17	585818901	VIS
18	585592301	SUPPORT
19	582541501	CLE DE BLOCAGE
20	585636201	RESSORT
21	577996601	BOUTON-POUSOIR
22	585636001	BOUTON-POUSOIR
23	585636601	RESSORT
24	585593001	BOITIER DE LA BATTERIE
25	577844301	DECAL
26	582712201	VIS
27	574223901	VIS
28	585819001	VIS
29	591073801	CARTER


C 120i
OIL PUMP




CHAIN SAWS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
1	586846501	POMPE A HUILE COMPLÈTE	
2	586902901	VIS	
3	585566601	TUYAU D'HUILE	

A 120i
OIL TANK




PXM_REF	PXM_PARTNO	DESCRIPTION
1	582734601	RÉSERVOIR COMPLET
2	582148601	RESSORT
3	574800901	TUBE
4	585566601	TUYAU D'HUILE
5	581990101	GOUPIILLE
6	575484501	VALVE NIPPLE
7	522620003	BOUCHON DE RÉSERVOIR COMPLET

D 120i
CLUTCH COVER

CHAIN SAWS

PXM_REF	PXM_PARTNO	DESCRIPTION
1	591471101	BOUTON
2	585593201	CARTER D'EMBRAYAGE
3	578776501	DÉ DE TENSION DE CHÂÎNE
4	585594001	DOUILLE
5	585593901	ARBRE
6	585593701	PLAQUE
7	585593501	PIGNON
8	585593401	CARTER
9	585819001	VIS

F 120i
ELECTRICAL




CHAIN SAWS

PXM_REF	PXM_PARTNO	DESCRIPTION
1	591157001	INTERRUPTEUR
2	582405905	UNITÉ DE COMMANDE
3	591157101	MICRO INTERRUPTEUR

B2 120i
GEAR BOX

HIGHER THAN S/N




CHAIN SAWS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
1	574797701	CIRCLIPS	
2	585602001	RONDELLE	
3	585589601	ENGRENAGE A VIS	"3/8"-6T"
4	586903001	VIS	
5	585589701	PLAQUE	
6	585603501	PLAQUE	
7	586902601	STYLO	
8	585594401	PLAQUE	
9	585590501	RESSORT DE FREIN	
10	587377701	COUVERCLE	
11	585590301	BANDE DE FREIN	
12	586902801	VIS	
13	582486801	GEARBOX	
14	586902701	ÉCROU	
15	582488701	MAILLON ENTRAÎNEMENT	
16	591388901	ARBRE	
17	585944402	VIS	
18	591073901	GEARBOX	
19	585819002	VIS	
20	591090701	MOTEUR	

B1 120i
GEAR BOX

UP TO S/N



CHAIN SAWS

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
1	586903001	VIS	
2	585589701	PLAQUE	
3	585603501	PLAQUE	
4	586902601	STYLO	
5	585594401	PLAQUE	
6	585590501	RESSORT DE FREIN	
7	585590301	BANDE DE FREIN	
8	582486801	GEARBOX	
9	582864301	ARBRE	
10	582454701	GEARBOX	
11	585819002	VIS	
12	586902801	VIS	
13	582864201	PIGNON	
14	582561101	VIS	
15	582456701	CONNECTEUR	
16	582492201	MOTEUR	
17	587377701	COUVERCLE	
18	582488701	MAILLON ENTRAÎNEMENT	
19	586902701	ÉCROU	
20	574797701	CIRCLIPS	
21	585602001	RONDELLE	
22	585589601	ENGRENAGE A VIS	3/8"-6T