

SPARE PARTS CATALOGUE
CHAIN SAWS: ELECTRIC: HUSQVARNA 315


Spare Parts List

SPARE PARTS LIST

CHAIN SAWS: ELECTRIC

HUSQVARNA 315

D



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
508 04 37-02	508043702	ROUE D'ENGRENAGE	
508 04 56-01	508045601	PLAQUE	
508 04 58-00	508045800	RONDELLE	
725 63 29-51	725632951	VIS IHCSFM	
508 04 64-01	508046401	CARRIER	
508 04 55-01	508045501	PLAQUE	
508 04 51-07	508045107	ENGRENAGE	3/8 -6T
508 04 27-06	508042706	TAMBOUR D'EMBRAYAGE	
508 04 67-10	508046710	RONDELLE	

foretjardin.com


A HUSQVARNA 315Electric, 320Electric

508 03 86-13 (315Electric) —  **Husqvarna**

Electric **315**


508 03 86-14 (320Electric) —  **Husqvarna**

Electric **320**



PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
508 04 31-04	508043104	TUBULAR HANDLE	
508 03 12-01	508031201	VIS	
508 04 46-22	508044622	POIGNÉE	
508 03 09-01	508030901	VIS	
731 23 18-51	731231851	ECROU HEXAGONAL	
508 04 77-01	508047701	RONDELLE D'ESPACEMENT	
508 04 45-14	508044514	CARTER	
508 04 30-07	508043007	CARTER	
508 04 62-02	508046202	VIS	
508 04 44-09	508044409	JOINT	
508 04 43-27	508044327	CARTER	
508 04 42-24	508044224	CARTER	
508 03 86-14	508038614	DECAL	320ELECTRIC
508 03 86-13	508038613	DECAL	315ELECTRIC


E



PXM_REF	PXM_PARTNO	DESCRIPTION
508 03 19-10	508031910	RÉSERVOIR
508 04 35-07	508043507	JOINT
508 03 18-11	508031811	RÉSERVOIR
508 04 33-14	508043314	POMPE À HUILE
508 04 35-05	508043505	JOINT TORIQUE
508 04 35-03	508043503	JOINT TORIQUE
508 04 35-06	508043506	JOINT


ForêtJardin.com

C




PXM_REF	PXM_PARTNO	DESCRIPTION
508 04 23-23	508042323	OEILLET
508 04 77-16	508047716	PIN RETAINING SCREW
508 04 54-01	508045401	ISOLATEUR
725 24 57-76	725245776	VIS EHHM
738 21 01-02	738210102	ROULEMENT À BILLES
508 04 22-16	508042216	SUPPORT
508 04 30-05	508043005	BANDE DE FREIN
508 03 09-01	508030901	VIS
508 04 62-02	508046202	VIS
729 52 93-71	729529371	VIS CRPANT
508 04 66-14	508046614	VIS
508 04 66-10	508046610	STYLO
508 04 63-01	508046301	RESSORT
508 04 60-01	508046001	DÉ DE TENSION DE CHÂÎNE
508 04 62-03	508046203	VIS
735 31 08-21	735310821	CIRCLIP
508 04 61-10	508046110	RESSORT
508 04 30-06	508043006	RESSORT
501 87 53-01	501875301	GENOUILLEÈRE COMPLÈTE
729 52 79-01	729527901	VIS CRPANT

F Accessories
Zubehöre
Accessoires
Acessorios
Tillbehör



PXM_REF	PXM_PARTNO	DESCRIPTION
508 03 80-02	508038002	CLE ALLEN
501 83 44-09	501834409	BAR COVER

Forêtjardin.com

B

CHAIN SAWS: ELECTRIC

PXM_REF	PXM_PARTNO	DESCRIPTION	PXM_REMARK
508 03 41-04	508034104	INTERRUPTEUR	
508 03 42-04	508034204	DOUILLE	
508 04 38-52	508043852	CÂBLAGE	315 ELECTRIC
508 03 38-01	508033801	CABLE ASSEMBLE	EU
508 03 39-01	508033901	CABLE ASSEMBLE	CH
508 03 40-12	508034012	CABLE ASSEMBLE	UK
508 03 40-03	508034003	CABLE ASSEMBLE	AUS, NZ
508 04 37-07	508043707	RESSORT	
508 04 39-18	508043918	SHELL	
508 04 37-05	508043705	BROSSE	
508 04 37-03	508043703	SUPPORT	
508 04 36-40	508043640	MOTEUR	315 ELECTRIC
508 04 36-41	508043641	MOTEUR	320 ELECTRIC
508 04 39-41	508043941	PRINTED CIRCUIT CARD	320 ELECTRIC
508 04 38-51	508043851	MICRO INTERRUPTEUR	315 ELECTRIC
508 04 69-13	508046913	CONDENSATEUR	315 ELECTRIC