


SPARE PARTS LIST

HEDGE TRIMMERS


T55, 952715450, 2007-03



MOTEUR

T55, 952715450, 2007-03

Référence	Numéro de Pièce	Description
1	530 01 63-86	VIS
2	530 05 64-54	SHROUD GOLD
3	530 07 14-86	JEU DE JOINTS
4	530 01 25-71	VILEBREQUIN COMPLET
5	530 07 16-81	CARTER MOTEUR
6	530 01 59-41	COLLIER DE SERRAGE
7	530 07 14-87	VOLANT
8	530 01 58-28	RONDELLE
9	530 05 57-29	RONDELLE D'ESPACEMENT
10	530 01 54-96	VIS
11	530 05 56-81	PLAQUE
12	530 01 63-92	VIS
13	530 06 93-53	POULIE DE LANCEUR
14	545 02 48-09	01 KIT--UPPER SHAFT ASS
15	530 02 75-69	POIGNÉE DE DÉMARRAGE
16	530 06 92-32	CORDE
17	530 01 91-82	PROTECTION
18	530 01 63-86	VIS
19	530 04 20-85	RETURN SPRING
20	530 01 63-57	VIS
21	530 05 41-37	BLOC ELECTRONIQUE
22	530 01 25-10	CARTER MOTEUR
23	530 05 57-28	ROULEMENT
24	530 01 92-64	JOINT
25	530 03 21-25	ROULEMENT
26	530 01 59-34	VIS
27	530 07 14-86	JEU DE JOINTS
28	530 07 17-85	PISTON
29	530 06 99-45	BIELLE
30	530 07 18-33	KIT
31	530 01 51-62	WRIST PIN RETAINER
32	530 05 51-20	SEGMENT
33	530 07 14-86	JEU DE JOINTS
34	530 05 76-34	ADAPTATEUR
35	530 01 63-09	VIS
36	530 07 17-76	CARBURATEUR
37	530 05 92-80	LEVIER
38	530 05 56-80	SHELL
39	530 01 64-29	VIS
40	530 04 79-32	FILTRE À AIR
41	530 05 56-79	CARTER
42	530 01 59-57	VIS
43	530 01 51-58	RONDELLE
44	530 07 14-86	JEU DE JOINTS
45	530 05 87-56	THROTTLE WIRE
46	952 03 02-49	BOUGIE D'ALLUMAGE
47	530 01 25-00	CYLINDRE
48	530 01 59-53	VIS
49	530 07 14-86	JEU DE JOINTS
50	530 07 18-05	SILENCIEUX
51	530 01 63-38	BOULON
52	530 07 15-44	PARTITION
53	530 01 52-41	VIS
54	530 09 56-47	FILTRE
55	530 06 92-47	TUYAU
56	530 06 92-16	DURITE D'ESSENCE
57	530 02 38-77	RACCORD
58	530 01 61-03	COLLIER DE SERRAGE
59	530 07 14-86	JEU DE JOINTS




MOTEUR

T55, 952715450, 2007-03

Référence	Numéro de Pièce	Description
1	530 01 63-86	VIS
2	530 05 64-54	SHROUD GOLD
3	530 07 14-86	JEU DE JOINTS
4	530 01 25-71	VILEBREQUIN COMPLET
5	530 07 16-81	CARTER MOTEUR
6	530 01 59-41	COLLIER DE SERRAGE
7	530 07 14-87	VOLANT
8	530 01 58-28	RONDELLE
9	530 05 57-29	RONDELLE D'ESPACEMENT
10	530 01 54-96	VIS
11	530 05 56-81	PLAQUE
12	530 01 58-82	VIS
13	530 06 93-53	POULIE DE LANCEUR
14	545 03 74-01	CARTER DE VENTILATEUR
15	530 02 75-69	POIGNÉE DE DÉMARRAGE
16	530 06 92-32	CORDE
17	530 01 91-82	PROTECTION
18	530 01 63-86	VIS
19	530 04 20-85	RETURN SPRING
20	530 01 63-57	VIS
21	530 05 41-37	BLOC ELECTRONIQUE
22	530 01 25-10	CARTER MOTEUR
23	530 05 57-28	ROULEMENT
24	530 01 92-64	JOINT
25	530 03 21-25	ROULEMENT
26	530 01 59-34	VIS
27	530 07 14-86	JEU DE JOINTS
28	530 07 17-85	PISTON
29	530 06 99-45	BIELLE
30	530 07 18-33	KIT
31	530 01 51-62	WRIST PIN RETAINER
32	530 05 51-20	SEGMENT
33	530 07 14-86	JEU DE JOINTS
34	530 05 76-34	ADAPTATEUR
35	530 01 63-09	VIS
36	530 07 17-76	CARBURATEUR
37	530 05 92-80	LEVIER
38	530 05 56-80	SHELL
39	530 01 64-29	VIS
40	530 04 79-32	FILTRE À AIR
41	530 05 56-79	CARTER
42	530 01 59-57	VIS
43	530 01 51-58	RONDELLE
44	530 07 14-86	JEU DE JOINTS
45	530 05 87-56	THROTTLE WIRE
46	952 03 02-49	BOUGIE D'ALLUMAGE
47	530 01 25-00	CYLINDRE
48	530 01 59-53	VIS
49	530 07 14-86	JEU DE JOINTS
50	530 07 18-05	SILENCIEUX
51	530 01 63-38	BOULON
52	530 07 15-44	PARTITION
53	530 01 52-41	VIS
54	530 09 56-47	FILTRE
55	530 06 92-47	TUYAU
56	530 06 92-16	DURITE D'ESSENCE
57	530 02 38-77	RACCORD
58	530 01 61-03	COLLIER DE SERRAGE
59	530 07 14-86	JEU DE JOINTS

WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.


TYPE 1



Référence	Numéro de Pièce	Description
1	530 05 41-33	CABLE ASSY
2	530 02 99-54	INTERRUPTEUR
3	530 07 16-55	POIGNÉE
4	545 02 48-09	01 KIT--UPPER SHAFT ASS
5	545 02 48-09	01 KIT--UPPER SHAFT ASS
6	545 02 48-09	01 KIT--UPPER SHAFT ASS
7	530 05 88-33	CARTER D'ENGRENAGE
8	530 01 58-86	VIS
9	530 01 60-13	ROULEMENT
10	530 09 62-58	PISTON
11	530 01 58-05	VIS
12	530 03 21-21	BUSHING
13	530 03 60-46	PLAQUE
14	530 01 58-49	VIS
15	530 01 59-34	VIS
16	530 02 99-16	PLAQUE
17	530 07 17-77	ROUE
18	530 02 99-48	JOINT
19	530 40 32-29	COUTEAU
20	530 05 78-19	CÂBLE
21	530 01 59-34	VIS
22	530 02 99-46	AMORTISSEUR
23	530 01 48-71	ENJOLIVEUR
24	530 05 91-04	THROTTLE LOCK
25	530 01 59-34	VIS
26	530 05 78-21	POIGNÉE
27	530 01 59-40	VIS
28	530 01 59-34	VIS
29	530 01 57-75	VIS
30	530 05 78-18	VERROUILLAGE
31	530 01 64-06	VIS
32	530 03 61-23	RESSORT
33	530 05 38-84	THROTTLE TRIGGER
34	530 09 49-92	POIGNÉE
35	530 01 59-55	VIS

WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

TYPE 2




Référence	Numéro de Pièce	Description
1	530 05 41-33	CABLE ASSY
2	530 02 99-54	INTERRUPTEUR
3	530 07 16-55	POIGNÉE
4	545 02 48-09	01 KIT--UPPER SHAFT ASS
5	545 02 48-09	01 KIT--UPPER SHAFT ASS
6	545 02 48-09	01 KIT--UPPER SHAFT ASS
7	530 07 19-32	CARTER D'ENGRENAGE
8	530 01 58-86	VIS
9	530 01 60-13	ROULEMENT
10	530 09 62-58	PISTON
11	530 01 58-05	VIS
12	530 03 21-21	BUSHING
13	530 01 59-40	VIS
14	530 03 60-46	PLAQUE
15	530 01 58-49	VIS
16	530 01 59-34	VIS
17	530 01 64-72	VIS
18	530 02 99-16	PLAQUE
19	530 07 17-77	ROUE
20	530 02 99-48	JOINT
21	530 40 32-29	COUTEAU
22	530 01 62-84	ÉCROU
23	530 05 78-19	CÂBLE
24	530 01 59-34	VIS
25	530 02 99-46	AMORTISSEUR
26	530 04 78-77	ENJOLIVEUR
27	530 05 91-04	THROTTLE LOCK
28	530 01 59-34	VIS
29	530 05 78-21	POIGNÉE
30	530 01 59-40	VIS
31	530 01 59-34	VIS
32	530 01 57-75	VIS
33	530 05 78-18	VERROUILLAGE
34	530 01 64-06	VIS
35	530 03 61-23	RESSORT
36	530 05 38-84	THROTTLE TRIGGER
37	530 09 49-92	POIGNÉE
38	530 01 59-55	VIS



WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

TYPE 3



Référence	Numéro de Pièce	Description
1	530 05 41-33	CABLE ASSY
2	530 02 99-54	INTERRUPTEUR
3	530 07 16-55	POIGNÉE
4	530 01 56-11	RONDELLE
5	530 07 18-03	EMBRAYAGE COMPLET
6	530 15 05-83	ASSEMBLY
7	530 07 19-32	CARTER D'ENGRENAGE
8	530 01 58-86	VIS
9	530 01 60-13	ROULEMENT
10	530 09 62-58	PISTON
11	530 01 58-05	VIS
12	530 03 21-21	BUSHING
13	530 01 59-40	VIS
14	530 03 60-46	PLAQUE
15	530 01 58-49	VIS
16	530 01 59-34	VIS
17	530 01 64-72	VIS
18	530 02 99-16	PLAQUE
19	530 07 17-77	ROUE
20	530 02 99-48	JOINT
21	530 40 32-29	COUTEAU
22	545 00 91-01	ÉCROU
23	530 05 78-19	CÂBLE
24	530 01 59-34	VIS
25	530 02 99-46	AMORTISSEUR
26	530 04 78-77	ENJOLIVEUR
27	530 05 91-04	THROTTLE LOCK
28	530 01 59-34	VIS
29	530 05 78-21	POIGNÉE
30	530 01 59-40	VIS
31	530 01 59-34	VIS
32	530 01 57-75	VIS
33	530 05 78-18	VERROUILLAGE
34	530 01 64-06	VIS
35	530 03 61-23	RESSORT
36	530 05 38-84	THROTTLE TRIGGER
37	530 09 49-92	POIGNÉE
38	530 01 59-55	VIS