



SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

4051 CM, 96141004405, 2008-03



Référence	Numéro de Pièce	Description
1	532 19 25-17	POIGNÉE
2	532 15 36-05	POIGNÉE
3	532 14 67-71	OEILLET
4	532 18 35-67	CÂBLE
5	532 19 15-74	VIS
6	532 19 19-38	BOUTON
7	532 05 17-93	PIN RETAINING SCREW
8	532 06 64-26	HOOP
9	532 40 69-85	DÉFLECTEUR
10	532 12 84-15	RIVET
11	532 41 05-40	SUPPORT
12	532 41 05-42	SUPPORT
13	817 06 04-10	VIS
14	532 19 01-54	SUPPORT DE POIGNÉE
15	532 19 01-53	SUPPORT DE POIGNÉE
16	532 40 54-17	RESSORT
17	532 40 54-18	RESSORT
18	532 13 20-04	ÉCROU
19	532 19 47-88	GUIDE
20	532 41 35-43	FOOT GUARD.21.DOMED.CE*SUBS/2*
21	817 49 04-16	VIS
25	532 15 04-06	BOULON
26	532 40 91-48	ÉCROU
27	532 19 79-85	WHEEL & TIRE ASSEMBLY
28	532 40 16-38	BOULON
30	532 41 21-74	BRAS
31	532 08 78-77	BOUTON
32	532 41 08-88	RESSORT
33	532 15 53-77	ÉCROU
34	532 40 16-30	RONDELLE
36	532 18 41-93	BOULON
38	532 40 16-29	RONDELLE D'ESPACEMENT
40	532 19 09-39	MOUNTING BRACKET, DEBRI
41	532 19 23-25	VIS
43	532 40 58-45	CARTER DE COURROIE
44	532 40 93-64	CHÂSSIS
45	532 18 21-66	DECAL
46	532 40 46-32	ADAPTATEUR
47	532 19 93-77	MOWER BLADE
48	532 85 10-74	RONDELLE
49	532 85 02-63	RONDELLE
50	532 85 10-84	VIS
96	532 19 79-91	COLLIER DE SERRAGE
--	532 19 83-27	OPERATOR'S MANUAL
--	532 19 83-28	OPERATOR'S MANUAL
--	532 19 92-17	OPERATOR'S MANUAL



Référence	Numéro de Pièce	Description
1	532 18 45-87	COMMANDE
4	532 15 87-55	VIS
6	532 15 04-95	PIN RETAINING SCREW
7	532 19 17-30	ÉCROU
11	532 19 79-86	WHEEL & TIRE ASSEMBLY
12	812 00 00-58	CIRCLIP
13	532 40 38-49	PIGNON
14	532 18 94-03	PARE-POUSSIÈRE
15	532 40 48-45	PAWL, DRIVE
16	532 06 77-25	RONDELLE
17	532 19 10-39	ROULEMENT
18	532 08 78-77	BOUTON
27	532 17 52-62	PAN HEAD TAPPING SCREW
28	532 19 58-81	DRIVE COVER
29	532 17 54-36	COURROIE EN V
33	532 40 91-48	ÉCROU
35	532 40 88-62	WHEEL ADJ KIT LH
36	532 41 52-25	GEARBOX
38	873 80 04-00	ÉCROU
40	532 13 70-90	RESSORT
41	532 40 88-61	WHEEL ADJ KIT RH
54	532 40 19-05	SAC
57	532 41 19-50	CADRE
60	532 18 34-97	POT
61	532 18 34-98	CARTER
62	532 18 34-99	ENGRENAGE
63	532 18 35-00	LEVIER
64	532 18 35-01	RESSORT
65	532 41 69-88	ARBRE
66	532 18 35-03	DOG, MOVABLE
67	532 18 35-04	DOG, FIXED
68	532 18 35-05	WIRE, FORMED
69	532 18 35-06	ROULEMENT À BILLES
70	532 18 35-07	FOURCHE
71	532 18 35-08	SEAL, OUTPUT SHAFT
72	532 18 35-09	RONDELLE
73	532 18 35-10	SEAL, CASE
74	532 18 35-11	BUSHING
75	532 19 66-13	ARBRE
76	532 18 35-13	VIS
77	532 18 35-14	SEAL, INPUT SHAFT
78	532 41 69-87	POULIE
79	532 41 69-86	LOCK NUT