



SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

655 ESC, 96141005200, 2008-07



Référence	Numéro de Pièce	Description
1	532 19 25-17	POIGNÉE
2	532 19 63-49	POIGNÉE
3	532 14 67-71	OEILLET
4	817 41 13-08	VIS
5	532 19 15-74	VIS
6	532 19 19-38	BOUTON
7	532 05 17-93	PIN RETAINING SCREW
8	532 06 64-26	HOOP
9	532 18 04-79	REAR DOOR KIT (INCL. KE
10	532 12 84-15	RIVET
11	532 18 25-38	SUPPORT BRACKET LH
12	532 18 25-39	SUPPORT BRACKET RH
13	817 06 04-10	VIS
14	532 19 01-54	SUPPORT DE POIGNÉE
15	532 19 01-53	SUPPORT DE POIGNÉE
16	532 18 00-71	RESSORT
17	532 18 00-72	RESSORT
18	532 13 20-04	ÉCROU
19	532 17 95-85	HOLDER
20	532 17 92-05	FOOT GUARD
21	532 05 48-53	VIS
22	532 18 49-41	POULIE
23	532 18 77-23	TOUCHE
25	532 15 04-06	BOULON
26	532 08 39-23	ÉCROU
27	532 16 76-28	WHEEL & TIRE ASSEMBLY
28	532 18 93-12	BOULON
29	532 18 61-53	TRIMPLATE ASSEMBLY
30	532 19 54-35	AXLE ARM ASSEMBLY, RR
31	532 17 01-43	SELECTOR KNOB
32	532 19 01-57	SELECT*RPL.PAR 532175060004
33	532 14 18-41	VIS
34	532 19 54-36	AXLE ARM ASSEMBLY, REAR
35	532 18 06-60	ENJOLIVEUR
36	532 18 41-93	BOULON
37	532 19 24-36	CHARGEUR DE BATTERIE
38	532 17 61-85	RONDELLE
39	532 17 62-35	RONDELLE
40	532 19 09-39	MOUNTING BRACKET, DEBRI
41	532 19 23-25	VIS
42	532 08 38-16	VIS
43	532 18 87-84	CARTER
44	532 19 48-60	LAWN MOWER HOUSING
45	532 18 21-66	DECAL
46	532 18 46-32	BLADE ADAPTER
47	532 17 50-52	MOWER BLADE
48	532 85 10-74	RONDELLE
49	532 85 02-63	RONDELLE
50	532 85 10-84	VIS
51	532 18 96-86	COMMANDE
52	532 18 95-89	BATTERIE
53	532 14 49-29	VIS
54	532 18 62-37	BOÎTE
55	532 18 03-31	TOUCHE
56	532 19 12-52	TRIMPLATE, BATTERY & BA
66	532 18 21-60	THROTTLE TRIGGER
96	532 19 27-70	COLLIER DE SERRAGE
--	532 18 21-34	DECALC."WARNING"



Référence	Numéro de Pièce	Description
1	532 18 45-87	COMMANDE
2	532 19 10-39	ROULEMENT
3	532 17 52-62	PAN HEAD TAPPING SCREW
4	532 15 87-55	VIS
5	532 17 54-36	COURROIE EN V
6	532 15 04-95	PIN RETAINING SCREW
7	532 19 17-30	ÉCROU
8	532 18 06-60	ENJOLIVEUR
9	532 14 52-12	ÉCROU
10	532 08 81-18	RONDELLE
11	532 18 07-67	WHEEL & TIRE ASSEMBLY
12	812 00 00-58	CIRCLIP
13	532 75 00-03	PIGNON
14	532 18 94-03	PARE-POUSSIÈRE
15	532 19 10-17	PAWL, DRIVE
16	532 06 77-25	RONDELLE
18	532 17 01-43	SELECTOR KNOB
28	532 18 14-66	DRIVE COVER,
32	532 19 41-26	DRIVE PULLEY
35	532 19 51-10	VIS DE REGLAGE
36	532 19 49-35	GEAR CASE
38	873 80 04-00	ÉCROU
40	532 13 70-90	RESSORT
41	532 19 51-07	VIS DE REGLAGE
54	532 19 54-50	GRASSBAG
55	532 17 57-39	DRIVESHAFT COVER
57	532 18 88-15	CADRE
60	532 18 34-97	POT
61	532 18 34-98	CARTER
62	532 18 34-99	ENGRENAGE
63	532 18 35-00	LEVIER
64	532 18 35-01	RESSORT
65	532 18 35-02	ARBRE
66	532 18 35-03	DOG, MOVABLE
67	532 18 35-04	DOG, FIXED
68	532 18 35-05	WIRE, FORMED
69	532 18 35-06	ROULEMENT À BILLES
70	532 18 35-07	FOURCHE
71	532 18 35-08	SEAL, OUTPUT SHAFT
72	532 18 35-09	RONDELLE
73	532 18 35-10	SEAL, CASE
74	532 18 35-11	BUSHING
75	532 19 66-13	ARBRE
76	532 18 35-13	VIS
77	532 18 35-14	SEAL, INPUT SHAFT