


SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

M4053 CM, 96131001900, 2007-04



Référence	Numéro de Pièce	Description
1	532 19 55-74	REGLAGE
2	532 19 55-47	POIGNÉE
3	532 17 42-91	POIGNÉE
4	532 19 47-88	GUIDE
5	532 13 20-04	ÉCROU
6	532 19 15-74	VIS
7	532 06 64-26	HOOP
8	874 78 05-12	VIS
11	532 17 65-56	CÂBLE
12	532 75 06-34	VIS
13	532 12 52-03	SUPPORT
14	532 19 19-38	BOUTON
15	532 05 17-93	PIN RETAINING SCREW
16	532 19 17-30	ÉCROU
17	532 17 41-12	SUPPORT BRACKET
18	817 60 04-06	VIS
19	532 18 92-77	AXLE ARM ASSEMBLY, LF
20	532 18 92-78	AXLE ARM ASSEMBLY, RF
21	532 16 94-23	FOOTGUARD
22	532 16 85-99	RESSORT
23	532 18 66-12	DÉFLECTEUR
24	873 93 05-00	ÉCROU
25	532 40 31-12	SUPPORT
26	532 40 31-13	SUPPORT
28	532 05 45-83	VIS
29	532 16 57-04	ADJUSTING BRACKET
30	532 18 39-01	RONDELLE
32	532 40 29-47	RESSORT
33	532 08 78-77	BOUTON
34	532 18 36-61	AXLE ARM ASSEMBLY (LR)
35	532 16 67-85	ÉCROU
36	532 16 08-28	BOULON
37	532 19 79-85	WHEEL & TIRE ASSEMBLY
38	532 16 43-62	SHOULDER BOLT
39	532 14 52-12	ÉCROU
40	532 19 46-42	CADRE
41	532 08 86-52	VIS
42	532 16 57-66	RESSORT
43	532 16 57-67	RESSORT
44	532 18 58-19	BARRE
45	532 15 04-06	BOULON
46	532 18 21-66	DECAL
47	532 75 11-53	LOCKNUT 5/16-18 RL550HVA
48	532 18 36-62	AXLE ARM ASSEMBLY (RR)
49	532 40 31-67	ROUE
50	532 40 20-24	GRASSBAG
52	532 40 06-59	CARTER
53	532 85 10-84	VIS
54	532 85 02-63	RONDELLE
55	532 85 10-74	RONDELLE
56	532 19 93-77	MOWER BLADE
57	532 19 38-25	ADAPTATEUR
61	532 08 39-23	ÉCROU
65	532 08 83-48	RONDELLE
66	532 19 74-80	JOINT TORIQUE
67	532 19 79-91	COLLIER DE SERRAGE
--	532 18 21-91	LABEL WARNING
--	532 40 39-47	OPERATOR'S MANUAL
--	532 40 39-49	OPERATOR'S MANUAL