


# SPARE PARTS LIST

LAWN MOWERS: CONSUMER  
WALK-BEHINDS


M51-140WFP, 96141029300, 2014-03



## CHASSIS

M51-140WFP, 96141029300, 2014-03

| Référence | Numéro de Pièce | Description           | Remarque                                                |
|-----------|-----------------|-----------------------|---------------------------------------------------------|
| 1         | 580 63 87-02    | POIGNÉE               |                                                         |
| 2         | 532 43 45-14    | POIGNÉE               |                                                         |
| 3         | 580 84 91-04    | REGLAGE               |                                                         |
| 4         | 532 42 40-33    | CÂBLE                 |                                                         |
| 5         | 532 19 15-74    | VIS                   |                                                         |
| 6         | 532 19 19-38    | BOUTON                |                                                         |
| 7         | 532 05 17-93    | AXE                   |                                                         |
| 9         | 532 40 69-85    | DÉFLECTEUR            |                                                         |
| 10        | 532 12 84-15    | RIVET                 |                                                         |
| 11        | 532 41 05-40    | SUPPORT               | LH                                                      |
| 12        | 532 41 05-42    | SUPPORT               | RH                                                      |
| 13        | 817 06 04-10    | VIS                   |                                                         |
| 14        | 532 43 45-13    | SUPPORT               | LH                                                      |
| 15        | 532 43 45-12    | SUPPORT               | RH                                                      |
| 16        | 532 40 54-17    | RESSORT               | LH                                                      |
| 17        | 532 40 54-18    | RESSORT               | RH                                                      |
| 18        | 581 91 26-01    | BOUTON                |                                                         |
| 19        | 581 90 21-01    | GUIDE                 |                                                         |
| 20        | 532 43 61-19    | PROTECTEUR            |                                                         |
| 21        | 817 49 04-16    | VIS                   |                                                         |
| 24        | 000 00 00-00    | W/O DESCRIPTION       | 9P702-0107-H1 FOR<br>SERVICE & PARTS 1-800-<br>233-.... |
| 25        | 532 15 04-06    | BOULON                |                                                         |
| 26        | 532 40 91-49    | ÉCROU                 |                                                         |
| 27        | 581 01 03-05    | ROUE COMPLÈTE         | REAR                                                    |
| 28        | 532 40 16-38    | BOULON                |                                                         |
| 30        | 532 41 31-41    | ARM SUPPORT           | REAR                                                    |
| 31        | 532 08 78-77    | BOUTON                |                                                         |
| 32        | 532 40 98-89    | SELECTOR SPRING       |                                                         |
| 33        | 873 80 05-00    | LOCK NUT              |                                                         |
| 34        | 532 40 16-30    | RONDELLE              |                                                         |
| 36        | 532 18 41-93    | BOULON                |                                                         |
| 37        | 874 78 05-12    | VIS                   |                                                         |
| 38        | 532 40 16-29    | RONDELLE D'ESPACEMENT |                                                         |
| 39        | 532 15 53-77    | ÉCROU                 |                                                         |
| 40        | 532 43 50-59    | SUPPORT               |                                                         |
| 44        | 532 40 92-65    | CHÂSSIS               |                                                         |
| 45        | 532 18 21-66    | DECAL                 |                                                         |
| 46        | 581 36 71-01    | ADAPTATEUR            |                                                         |
| 47        | 532 19 93-77    | MOWER BLADE           |                                                         |
| 48        | 532 85 10-74    | RONDELLE              |                                                         |
| 49        | 532 85 02-63    | RONDELLE              |                                                         |
| 50        | 532 85 10-84    | VIS                   |                                                         |
| 57        | 532 43 00-34    | SUPPORT               |                                                         |
| 59        | 532 17 50-71    | CLIPPING DEFLECTOR    |                                                         |
| 58        | 532 17 88-48    | VIS                   |                                                         |
| 60        | 532 17 57-35    | CHARNIÈRE             |                                                         |
| 61        | 532 19 30-00    | CHARNIÈRE             |                                                         |
| 62        | 532 17 56-50    | BARRE                 |                                                         |
| 63        | 873 80 04-00    | ÉCROU                 |                                                         |
| 64        | 532 17 50-66    | BOUCHON               |                                                         |
| 65        | 532 19 74-80    | JOINT TORIQUE         |                                                         |
| 66        | 532 08 83-48    | RONDELLE              |                                                         |
| 96        | 532 19 79-91    | COLLIER DE SERRAGE    |                                                         |
| 98        | 872 25 05-05    | BOULON                |                                                         |
| 100       | 580 44 56-01    | COUVERCLE             |                                                         |
| 101       | 532 18 16-98    | VIS                   |                                                         |
| 102       | 532 42 81-24    | FASTENER              |                                                         |
|           | 532 18 21-91    | LABEL WARNING         |                                                         |



| Référence | Numéro de Pièce | Description                 | Remarque                          |
|-----------|-----------------|-----------------------------|-----------------------------------|
| 1         | 585 04 07-02    | CÂBLE                       |                                   |
| 7         | 585 12 31-02    | REGLAGE                     |                                   |
| 11        | 581 00 92-05    | ROUE COMPLÈTE               |                                   |
| 12        | 812 00 00-58    | CIRCLIP                     |                                   |
| 13        | 532 40 38-49    | PIGNON                      |                                   |
| 14        | 581 84 04-01    | PARE-POUSSIÈRE              |                                   |
| 15        | 532 40 48-45    | PAWL, DRIVE                 |                                   |
| 16        | 532 06 77-25    | RONDELLE                    |                                   |
| 18        | 532 08 78-77    | BOUTON                      |                                   |
| 25        | 532 43 17-11    | SUPPORT                     |                                   |
| 26        | 532 16 34-09    | VIS                         |                                   |
| 28        | 532 43 26-63    | CARTER                      | Includes Mounting Screw & Pushnut |
| 29        | 532 19 41-49    | COURROIE                    |                                   |
| 32        | 532 44 32-62    | POULIE                      |                                   |
| 33        | 532 40 91-48    | ÉCROU                       |                                   |
| 35        | 532 43 84-85    | VIS DE REGLAGE              | LH                                |
| 36        | 532 40 48-33    | GEARCASE ASSEMBLY, COMPLETE |                                   |
| 38        | 873 80 04-00    | ÉCROU                       |                                   |
| 40        | 532 40 65-58    | RESSORT                     |                                   |
| 41        | 532 43 84-86    | VIS DE REGLAGE              | RH                                |
| 54        | 580 95 34-04    | BAC DE RAMASSAGE COMPLET    |                                   |
| 57        | 532 41 19-50    | CADRE                       |                                   |