


SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS


M53-140WF, 96141028001, 2013-05



CHASSIS

M53-140WF, 96141028001, 2013-05

Référence	Numéro de Pièce	Description	Remarque
1	580 63 87-02	POIGNÉE	
2	532 43 45-14	POIGNÉE	
3	580 84 91-04	REGLAGE	
4	532 42 40-33	CÂBLE	
5	532 19 15-74	VIS	
6	532 19 19-38	BOUTON	
7	532 05 17-93	AXE	
9	532 40 69-85	DÉFLECTEUR	
10	532 12 84-15	RIVET	
11	532 41 05-40	SUPPORT	
12	532 41 05-42	SUPPORT	
13	817 06 04-10	VIS	
14	532 43 45-13	SUPPORT	
15	532 43 45-12	SUPPORT	
16	532 40 54-17	RESSORT	
17	532 40 54-18	RESSORT	
18	532 13 20-04	ÉCROU	
19	532 19 47-88	GUIDE	
20	532 43 61-19	PROTECTEUR	
21	817 49 04-16	VIS	
24	000 00 00-00	W/O DESCRIPTION	B&S 9P602-0062-H1 FOR SERVICE & PARTS 1-800-233-3723
25	532 15 04-06	BOULON	
26	532 40 91-49	ÉCROU	
27	581 01 03-05	ROUE COMPLÈTE	
28	532 40 16-38	BOULON	
30	532 41 31-41	ARM SUPPORT	
31	532 08 78-77	BOUTON	
32	532 40 98-89	SELECTOR SPRING	
33	873 80 05-00	LOCK NUT	
34	532 40 16-30	RONDELLE	
36	532 18 41-93	BOULON	
37	874 78 05-12	VIS	
38	532 42 61-29	DÉFLECTEUR	
39	532 15 53-77	ÉCROU	
40	532 43 50-59	SUPPORT	
44	532 40 92-65	CHÂSSIS	
45	532 18 21-66	DECAL	
46	581 36 71-01	ADAPTATEUR	
47	532 19 93-77	MOWER BLADE	
48	532 85 10-74	RONDELLE	
49	532 85 02-63	RONDELLE	
50	532 85 10-84	VIS	
57	532 43 00-34	SUPPORT	
58	532 17 88-48	VIS	
59	532 17 50-71	CLIPPING DEFLECTOR	
60	532 17 57-35	CHARNIÈRE	
61	532 19 30-00	CHARNIÈRE	
62	532 17 56-50	BARRE	
63	873 80 04-00	ÉCROU	
64	532 17 50-66	BOUCHON	
65	532 19 74-80	JOINT TORIQUE	
66	532 08 83-48	RONDELLE	
96	532 19 79-91	COLLIER DE SERRAGE	
98	872 25 05-05	BOULON	
100	580 44 56-01	COUVERCLE	
101	532 18 16-98	VIS	
102	532 42 81-24	FASTENER	
	532 18 21-91	LABEL WARNING	NOT SHOWN



ENTRAINEMENT

M53-140WF, 96141028001, 2013-05

Référence	Numéro de Pièce	Description	Remarque
1	581 07 69-01	CABLE D'ENTRAINEMENT	
7	580 65 93-02	REGLAGE	
11	581 00 92-05	ROUE COMPLÈTE	
12	812 00 00-58	CIRCLIP	
13	532 40 38-49	PIGNON	
14	581 84 04-01	PARE-POUSSIÈRE	
15	532 40 48-45	PAWL, DRIVE	
16	532 06 77-25	RONDELLE	
18	532 08 78-77	BOUTON	
25	532 43 17-11	SUPPORT	
26	532 16 34-09	VIS	
28	532 43 26-63	CARTER	Includes Mounting Screw & Pushnut
29	532 19 41-49	COURROIE	
32	532 44 32-62	POULIE	
33	532 40 91-48	ÉCROU	
35	532 43 84-85	VIS DE REGLAGE	
36	532 40 48-33	GEARCASE ASSEMBLY, COMPLETE	
38	873 80 04-00	ÉCROU	
40	532 40 65-58	RESSORT	
41	532 43 84-86	VIS DE REGLAGE	
54	580 95 34-04	BAC DE RAMASSAGE COMPLET	
57	532 41 19-50	CADRE	