


# SPARE PARTS LIST

LAWN MOWERS: CONSUMER  
WALK-BEHINDS


M53-140WF, 96141031700, 2015-11



## CHASSIS

M53-140WF, 96141031700, 2015-11

| Référence | Numéro de Pièce | Description                       | Remarque                                             |
|-----------|-----------------|-----------------------------------|------------------------------------------------------|
| 1         | 580 63 87-02    | POIGNÉE                           |                                                      |
| 2         | 532 43 45-14    | POIGNÉE                           |                                                      |
| 3         | 587 68 93-03    | ENSEMBLE DE BRAS DE CAUTIONNEMENT |                                                      |
| 4         | 532 42 40-33    | CÂBLE                             |                                                      |
| 5         | 532 19 15-74    | VIS                               |                                                      |
| 6         | 532 19 19-38    | BOUTON                            |                                                      |
| 7         | 532 05 17-93    | AXE                               |                                                      |
| 9         | 532 40 69-85    | DÉFLECTEUR                        |                                                      |
| 10        | 532 12 84-15    | RIVET                             |                                                      |
| 11        | 532 41 05-40    | SUPPORT                           | LH                                                   |
| 12        | 532 41 05-42    | SUPPORT                           | RH                                                   |
| 13        | 817 06 04-10    | VIS                               |                                                      |
| 14        | 532 43 45-13    | SUPPORT                           | LH                                                   |
| 15        | 532 43 45-12    | SUPPORT                           | RH                                                   |
| 16        | 532 40 54-17    | RESSORT                           | LH                                                   |
| 17        | 532 40 54-18    | RESSORT                           | RH                                                   |
| 18        | 581 91 26-01    | BOUTON                            |                                                      |
| 19        | 581 90 21-01    | GUIDE                             |                                                      |
| 20        | 532 43 61-19    | PROTECTEUR                        |                                                      |
| 21        | 817 49 04-16    | VIS                               |                                                      |
| 24        | 000 00 00-00    | W/O DESCRIPTION                   | B&S 9P702-0101-H1 FOR SERVICE & PARTS 1-800-233-3723 |
| 25        | 532 15 04-06    | BOULON                            |                                                      |
| 26        | 532 40 91-49    | ÉCROU                             |                                                      |
| 27        | 581 01 03-05    | ROUE COMPLÈTE                     |                                                      |
| 28        | 532 40 16-38    | BOULON                            |                                                      |
| 30        | 532 41 31-41    | ARM SUPPORT                       |                                                      |
| 31        | 532 08 78-77    | BOUTON                            |                                                      |
| 32        | 532 40 98-89    | SELECTOR SPRING                   |                                                      |
| 33        | 873 80 05-00    | LOCK NUT                          |                                                      |
| 34        | 532 40 16-30    | RONDELLE                          |                                                      |
| 36        | 532 18 41-93    | BOULON                            |                                                      |
| 37        | 874 78 05-12    | VIS                               |                                                      |
| 38        | 532 40 16-29    | RONDELLE D'ESPACEMENT             |                                                      |
| 39        | 532 15 53-77    | ÉCROU                             |                                                      |
| 40        | 532 43 50-59    | SUPPORT                           |                                                      |
| 44        | 532 40 92-65    | CHÂSSIS                           |                                                      |
| 45        | 532 18 21-66    | DECAL                             |                                                      |
| 46        | 581 36 71-01    | ADAPTATEUR                        |                                                      |
| 47        | 532 19 93-77    | MOWER BLADE                       |                                                      |
| 48        | 532 85 10-74    | RONDELLE                          |                                                      |
| 49        | 532 85 02-63    | RONDELLE                          |                                                      |
| 50        | 532 85 10-84    | VIS                               |                                                      |
| 59        | 532 17 50-71    | CLIPPING DEFLECTOR                |                                                      |
| 60        | 532 17 57-35    | CHARNIÈRE                         |                                                      |
| 61        | 532 19 30-00    | CHARNIÈRE                         |                                                      |
| 62        | 532 17 56-50    | BARRE                             |                                                      |
| 63        | 873 80 04-00    | ÉCROU                             |                                                      |
| 64        | 532 17 50-66    | BOUCHON                           |                                                      |
| 65        | 532 19 74-80    | JOINT TORIQUE                     |                                                      |
| 66        | 532 08 83-48    | RONDELLE                          |                                                      |
| 96        | 532 19 79-91    | COLLIER DE SERRAGE                |                                                      |
| 98        | 586 21 25-01    | BOULON                            |                                                      |
| 100       | 580 44 56-01    | COUVERCLE                         |                                                      |
| 101       | 532 18 16-98    | VIS                               |                                                      |
| 102       | 532 42 81-24    | FASTENER                          |                                                      |
|           | 532 18 21-91    | LABEL WARNING                     | NOT SHOWN-OPTIONAL 1                                 |
|           | 581 00 67-01    | SAC                               | BAG OF PARTS (INCLUDES KEY NUMBERS 6 & 98)           |



| Référence | Numéro de Pièce | Description                 | Remarque |
|-----------|-----------------|-----------------------------|----------|
| 1         | 585 04 07-02    | CÂBLE                       |          |
| 7         | 585 12 31-02    | REGLAGE                     |          |
| 11        | 581 00 92-05    | ROUE COMPLÈTE               |          |
| 12        | 812 00 00-58    | CIRCLIP                     |          |
| 13        | 532 40 38-49    | PIGNON                      |          |
| 14        | 581 84 04-01    | PARE-POUSSIÈRE              |          |
| 15        | 532 40 48-45    | PAWL, DRIVE                 |          |
| 16        | 532 06 77-25    | RONDELLE                    |          |
| 18        | 532 08 78-77    | BOUTON                      |          |
| 25        | 532 43 17-11    | SUPPORT                     |          |
| 26        | 532 16 34-09    | VIS                         |          |
| 28        | 532 43 26-63    | CARTER                      |          |
| 29        | 532 19 41-49    | COURROIE                    |          |
| 32        | 586 98 97-01    | POULIE                      |          |
| 33        | 532 40 91-48    | ÉCROU                       |          |
| 35        | 532 43 81-51    | VIS DE REGLAGE              | LH       |
| 36        | 532 40 48-33    | GEARCASE ASSEMBLY, COMPLETE |          |
| 38        | 873 80 04-00    | ÉCROU                       |          |
| 40        | 532 40 65-58    | RESSORT                     |          |
| 41        | 532 43 81-48    | VIS DE REGLAGE              | RH       |
| 54        | 580 95 34-04    | BAC DE RAMASSAGE COMPLET    |          |
| 57        | 532 41 19-50    | CADRE                       |          |