



SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

M53-190ER, 96141026600, 2013-02



Référence	Numéro de Pièce	Description	Remarque
1	580 63 87-02	POIGNÉE	
2	532 19 60-05	POIGNÉE	
3	532 40 54-16	RESSORT	RH
4	532 19 47-88	GUIDE	
5	532 13 20-04	ÉCROU	
7	532 19 15-74	VIS	
8	532 44 50-19	BOUTON	
9	532 42 65-05	CONTRÔLE DE PRESENCE DE L'OPERATEUR	
10	532 18 88-21	BOULON	
11	532 75 11-53	ÉCROU	
12	532 05 17-93	AXE	
13	532 40 54-15	RESSORT	LH
14	532 17 88-48	VIS	
15	532 43 00-34	SUPPORT	
16	532 40 88-88	DÉFLECTEUR	
17	532 18 41-93	BOULON	
18	532 19 81-70	BOUCHON	
19	532 40 97-33	KIT.HSG.21.AW/VS.RGD.M*SUBS/2*	
20	532 19 40-29	SUPPORT	LH
21	532 19 40-31	SUPPORT	RH
22	532 42 88-67	BOULON	
23	532 16 31-83	BOULON	
24	873 80 05-00	LOCK NUT	
25	532 16 13-33	PLAQUE	
26	532 16 34-09	VIS	
29	532 44 03-86	CÂBLE	
30	532 42 11-76	ADAPTATEUR	
31	532 19 93-77	MOWER BLADE	
32	532 85 10-74	RONDELLE	
33	532 85 02-63	RONDELLE	
34	532 85 10-84	VIS	
37	532 15 04-06	BOULON	
38	000 00 00-00	W/O DESCRIPTION	B&S 122T05-1615-H1 FOR SERVICE & PARTS 1-800-233-3723
39	581 00 29-05	BAC DE RAMASSAGE COMPLET	
40	532 41 19-51	CADRE	
41	532 18 21-66	DECAL	
42	817 06 04-10	VIS	
45	532 19 13-41	PORTE*RPL.PAR 532183058	
46	532 19 12-10	DEFLEC*RPL.PAR 532169699428	
47	532 08 83-49	ÉCROU	
48	532 42 90-01	SUPPORT	
61	532 16 34-09	VIS	
62	532 40 80-02	BOX.BATTERY.21RD.RWGD *SUBS/2*	
63	532 18 95-89	BATTERIE	
64	532 19 24-36	CHARGEUR DE BATTERIE	
65	532 44 66-94	BOULON	
66	580 91 55-02	HARNAIS COMPLET	
67	580 91 52-03	BOUTON	
69	532 42 59-37	FUSIBLE	
96	532 19 79-91	COLLIER DE SERRAGE	
100	580 27 36-01	COUVERCLE	
101	581 79 50-01	VIS ITXPANT	
102	532 44 66-95	ÉCROU	
103	532 42 81-24	FASTENER	
	532 18 21-34	DECALC."WARNING"	NOT SHOWN



Référence	Numéro de Pièce	Description	Remarque
1	581 07 68-01	CABLE D'ENTRAINEMENT	
2	580 65 93-02	REGLAGE	
11	532 40 65-58	RESSORT	
13	532 41 92-13	BOITE A VITESSE	
14	532 40 57-03	POULIE	
15	532 08 83-48	RONDELLE	
16	532 40 71-47	BARRE	
17	532 40 96-16	RESSORT	
18	532 41 88-66	RESSORT	
19	532 19 00-69	BOUTON	
20	812 00 00-22	BAGUE DE RETENUE	
21	532 40 48-38	ROULEMENT	
23	532 16 45-55	SUPPORT	
24	817 06 04-10	VIS	
25	532 43 26-70	CARTER	INCLUDES SCREW & PUSHNUT
28	812 00 00-58	CIRCLIP	
29	581 84 04-01	PARE-POUSSIÈRE	
31	532 40 48-45	PAWL, DRIVE	
32	581 68 55-05	ROUE	
33	532 40 91-48	ÉCROU	
34	532 85 12-26	RONDELLE	
35	532 41 09-22	ARBRE	
36	532 41 09-33	ARBRE	
37	532 16 14-63	SUPPORT	
38	532 16 34-09	VIS	
39	532 40 70-59	SHOULDER BOLT SEMI GIMLET PT.	
40	581 00 94-05	ROUE COMPLÈTE	
41	532 40 48-35	PIGNON	
42	532 19 74-80	JOINT TORIQUE	
44	532 40 65-57	COURROIE	
47	532 06 77-25	RONDELLE	
50	532 41 37-22	BRACKET.BELT.KEEPE/AUT*SUBS/2*	