



SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

M53-625 CMDWE, 96141025200, 2011-11



Référence	Numéro de Pièce	Description	Remarque
1	532 42 77-38	POIGNÉE	
2	532 43 45-39	POIGNÉE	
3	532 19 84-64	COMMANDE	
4	532 40 19-94	CABLE.MZR/HSG.51.62 *SUBS/2*	
5	532 19 15-74	VIS	
6	532 44 50-19	BOUTON	
7	532 05 17-93	AXE	
8	532 06 64-26	HOOP	
9	532 40 69-85	DÉFLECTEUR	
10	532 12 84-15	RIVET	
11	532 41 05-40	SUPPORT	LH
12	532 41 05-42	SUPPORT	RH
13	817 06 04-10	VIS	
14	532 43 45-13	SUPPORT	LH
15	532 43 45-12	SUPPORT	RH
16	532 40 54-17	RESSORT	LH
17	532 40 54-18	RESSORT	RH
18	532 13 20-04	ÉCROU	
19	532 19 47-88	GUIDE	
20	532 43 61-19	PROTECTEUR	
21	817 49 04-16	VIS	
22	532 40 95-67	HARNAIS	
23	532 19 48-48	PROTÈGE-ÉCROU	
24	000 00 00-00	W/O DESCRIPTION	B&S 122T05-1615-H1 FOR SERVICE & PARTS 1-800-233-3723
25	532 15 04-06	BOULON	
26	532 40 91-49	ÉCROU	
27	532 43 31-18	ROUE	
28	532 40 16-38	BOULON	
29	532 41 11-90	PANEL.TRIM.21.FWGD.ES *SUBS/2*	
30	532 41 31-41	ARM SUPPORT	REAR, RIGHT
31	532 08 78-77	BOUTON	
32	532 40 98-89	SELECTOR SPRING	
33	873 80 05-00	LOCK NUT	
34	532 40 16-30	RONDELLE	
35	532 14 18-41	VIS	
36	532 18 41-93	BOULON	
37	874 78 05-12	VIS	
38	532 40 16-29	RONDELLE D'ESPACEMENT	
39	532 15 53-77	ÉCROU	
40	532 42 90-01	SUPPORT	
42	532 17 55-51	BOULON	
44	532 40 93-64	CHÂSSIS	
45	532 18 21-66	DECAL	
46	532 43 46-25	ADAPTATEUR	
47	532 19 93-77	MOWER BLADE	
48	532 85 10-74	RONDELLE	
49	532 85 02-63	RONDELLE	
50	532 85 10-84	VIS	
51	532 18 96-86	COMMANDE	
52	532 18 95-89	BATTERIE	
53	532 18 61-59	VIS	
54	532 18 62-37	BOÎTE	
55	532 18 03-31	TOUCHE	
57	532 12 51-62	PLAQUE	
58	532 75 06-34	VIS	
65	532 19 74-80	JOINT TORIQUE	
66	532 08 83-48	RONDELLE	
67	532 19 24-36	CHARGEUR DE BATTERIE	
96	532 19 79-91	COLLIER DE SERRAGE	
97	817 41 13-08	VIS	
98	872 25 05-05	BOULON	
	532 18 21-34	DECALC."WARNING"	NOT SHOWN
	532 18 21-91	LABEL WARNING	NOT SHOWN
	532 42 59-37	FUSIBLE	NOT SHOWN



Référence	Numéro de Pièce	Description	Remarque
1	532 19 46-53	COMMANDE	
7	532 19 84-53	GUIDE-CHAÎNE	
11	532 40 29-36	ROUE	
12	812 00 00-58	CIRCLIP	
13	532 40 38-49	PIGNON	
14	532 18 94-03	PARE-POUSSIÈRE	
15	532 40 48-45	PAWL, DRIVE	
16	532 06 77-25	RONDELLE	
17	532 42 18-36	ROULEMENT	
18	532 08 78-77	BOUTON	
19	532 15 04-95	PIN RETAINING SCREW	
28	532 43 26-63	CARTER	
29	532 17 54-36	COURROIE EN V	
33	532 40 91-48	ÉCROU	
35	532 43 84-85	VIS DE REGLAGE	LH
36	532 41 52-25	GEARBOX	
38	873 80 04-00	ÉCROU	
40	532 13 70-90	RESSORT	
41	532 43 84-86	VIS DE REGLAGE	RH
54	532 40 19-05	SAC	
57	532 41 19-50	CADRE	