


# SPARE PARTS LIST

LAWN MOWERS: CONSUMER  
WALK-BEHINDS


M56-140WF, 96764810100, 2016-10



## CHASSIS

M56-140WF, 96764810100, 2016-10

| Référence | Numéro de Pièce | Description                       | Remarque                                                    |
|-----------|-----------------|-----------------------------------|-------------------------------------------------------------|
| 1         | 585 85 48-05    | POIGNÉE                           |                                                             |
| 2         | 532 42 09-39    | STOP CABLE                        |                                                             |
| 3         | 532 43 00-34    | SUPPORT                           |                                                             |
| 4         | 532 14 50-06    | COLLIER DE SERRAGE                |                                                             |
| 6         | 532 19 19-38    | BOUTON                            |                                                             |
| 7         | 532 17 88-48    | VIS                               |                                                             |
| 8         | 587 47 83-03    | ENSEMBLE DE BRAS DE CAUTIONNEMENT |                                                             |
| 9         | 532 42 63-00    | DOOR ASY                          |                                                             |
| 10        | 532 42 30-63    | RONDELLE                          |                                                             |
| 11        | 532 42 55-75    | HAIR PIN COTTER                   |                                                             |
| 13        | 532 43 75-16    | BOUCHON                           |                                                             |
| 17        | 532 42 73-07    | PLAQUE                            |                                                             |
| 18        | 581 91 26-01    | BOUTON                            |                                                             |
| 19        | 581 90 21-01    | GUIDE                             |                                                             |
| 20        | 532 42 24-67    | PROTECTEUR                        |                                                             |
| 21        | 532 41 99-49    | RESSORT                           |                                                             |
| 22        | 532 14 18-41    | VIS                               |                                                             |
| 23        | 873 97 05-00    | ÉCROU                             |                                                             |
| 24        | 532 41 99-48    | RESSORT                           |                                                             |
| 25        | 532 40 91-49    | ÉCROU                             |                                                             |
| 26        | 532 41 99-45    | VIS                               |                                                             |
| 27        | 581 01 03-05    | ROUE COMPLÈTE                     |                                                             |
| 28        | 586 21 25-01    | BOULON                            |                                                             |
| 31        | 532 70 10-37    | BOUTON                            |                                                             |
| 32        | 532 44 11-92    | CLIQUET DE VERROUILLAGE           |                                                             |
| 33        | 532 43 26-42    | MULCH DOOR                        |                                                             |
| 34        | 532 43 81-34    | SUPPORT                           |                                                             |
| 35        | 532 43 11-40    | VIS DE REGLAGE                    |                                                             |
| 36        | 532 17 57-35    | CHARNIÈRE                         |                                                             |
| 38        | 532 42 61-29    | DÉFLECTEUR                        |                                                             |
| 39        | 585 90 07-02    | SUPPORT                           |                                                             |
| 40        | 585 90 08-02    | SUPPORT                           |                                                             |
| 41        | 532 15 04-06    | BOULON                            |                                                             |
| 42        | 532 19 30-00    | CHARNIÈRE                         |                                                             |
| 43        | 532 19 17-30    | ÉCROU                             |                                                             |
| 44        | 581 70 83-24    | CARTER COMPLET                    |                                                             |
| 45        | 532 17 56-50    | BARRE                             |                                                             |
| 46        | 581 35 24-01    | ADAPTATEUR                        |                                                             |
| 47        | 586 17 98-01    | COUTEAU                           |                                                             |
| 48        | 532 85 10-74    | RONDELLE                          |                                                             |
| 49        | 532 85 02-63    | RONDELLE                          |                                                             |
| 50        | 532 85 10-84    | VIS                               |                                                             |
| 51        | 532 43 05-99    | PLAQUE                            |                                                             |
| 52        | 532 18 21-66    | DECAL                             |                                                             |
| 53        | 817 00 05-10    | BOULON                            |                                                             |
| 54        | 532 08 83-48    | RONDELLE                          |                                                             |
| 55        | 532 19 17-30    | ÉCROU                             |                                                             |
| 56        | 817 41 13-12    | VIS                               |                                                             |
| 57        | 532 15 53-77    | ÉCROU                             |                                                             |
| 58        | 585 90 82-02    | POIGNÉE                           |                                                             |
| 59        | 532 19 15-74    | VIS                               |                                                             |
| 62        | 532 43 50-59    | SUPPORT                           |                                                             |
| 64        | 000 00 00-00    | W/O DESCRIPTION                   | B&S 9P702-0101-H1 FOR<br>SERVICE & PARTS 1-800-<br>233-3723 |
| 65        | 532 19 74-80    | JOINT TORIQUE                     |                                                             |
| 68        | 532 43 11-41    | VIS DE REGLAGE                    |                                                             |
| 84        | 532 42 81-24    | FASTENER                          |                                                             |
| 96        | 532 19 79-91    | COLLIER DE SERRAGE                |                                                             |
| 104       | 580 44 56-01    | COUVERCLE                         |                                                             |
| 105       | 532 18 16-98    | VIS                               |                                                             |
|           | 532 18 21-91    | LABEL WARNING                     | NOT SHOWN                                                   |
|           | 532 42 38-49    | SAC                               | NOT SHOWN                                                   |



| Référence | Numéro de Pièce | Description              | Remarque                          |
|-----------|-----------------|--------------------------|-----------------------------------|
| 1         | 588 47 92-01    | CÂBLE                    |                                   |
| 7         | 532 19 84-53    | GUIDE-CHAÎNE             |                                   |
| 11        | 581 00 92-05    | ROUE COMPLÈTE            |                                   |
| 12        | 812 00 00-58    | CIRCLIP                  |                                   |
| 13        | 532 40 38-49    | PIGNON                   |                                   |
| 14        | 581 84 04-01    | PARE-POUSSIÈRE           |                                   |
| 15        | 532 40 48-45    | PAWL, DRIVE              |                                   |
| 16        | 532 06 77-25    | RONDELLE                 |                                   |
| 18        | 532 70 10-37    | BOUTON                   |                                   |
| 25        | 532 43 17-11    | SUPPORT                  |                                   |
| 26        | 532 16 34-09    | VIS                      |                                   |
| 28        | 587 99 78-01    | CARTER                   | Includes Mounting Screw & Pushnut |
| 29        | 532 40 91-48    | ÉCROU                    |                                   |
| 32        | 586 98 97-01    | POULIE                   |                                   |
| 33        | 532 19 68-53    | COURROIE                 |                                   |
| 35        | 581 49 79-07    | VIS DE REGLAGE           | LT FRT                            |
| 36        | 589 60 06-01    | TRANSMISSION             |                                   |
| 38        | 532 43 81-30    | ÉCROU                    |                                   |
| 40        | 532 40 65-58    | RESSORT                  |                                   |
| 41        | 581 49 79-08    | VIS DE REGLAGE           | RT FRT                            |
| 54        | 580 94 73-06    | BAC DE RAMASSAGE COMPLET |                                   |
| 57        | 585 05 47-02    | CADRE                    |                                   |