


SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS


M56-150F, 96764820100, 2016-10



CHASSIS

M56-150F, 96764820100, 2016-10

Référence	Numéro de Pièce	Description	Remarque
1	585 86 48-05	POIGNÉE	
2	532 42 09-39	STOP CABLE	
3	532 43 00-34	SUPPORT	
4	532 14 50-06	COLLIER DE SERRAGE	
6	532 19 19-38	BOUTON	
7	532 17 88-48	VIS	
8	583 87 24-01	REGLAGE	
9	532 42 63-00	DOOR ASY	
10	532 42 30-63	RONDELLE	
11	532 42 55-75	HAIR PIN COTTER	
13	532 43 75-16	BOUCHON	
17	532 42 73-07	PLAQUE	
18	581 91 26-01	BOUTON	
19	581 90 21-01	GUIDE	
20	532 42 24-67	PROTECTEUR	
21	532 41 99-49	RESSORT	
22	532 14 18-41	VIS	
23	873 97 05-00	ÉCROU	
24	532 41 99-48	RESSORT	
25	532 40 91-48	ÉCROU	
26	532 41 99-45	VIS	
27	532 19 79-85	WHEEL & TIRE ASSEMBLY	
28	586 21 25-01	BOULON	
31	532 70 10-37	BOUTON	
32	532 44 11-92	CLIQUET DE VERROUILLAGE	
33	532 43 26-42	MULCH DOOR	
34	532 43 81-34	SUPPORT	
35	532 43 11-39	VIS DE REGLAGE	
36	532 17 57-35	CHARNIÈRE	
38	532 42 61-29	DÉFLECTEUR	
39	585 90 07-02	SUPPORT	
40	585 90 08-02	SUPPORT	
41	532 15 04-06	BOULON	
42	532 19 30-00	CHARNIÈRE	
43	532 19 17-30	ÉCROU	
44	532 43 18-29	CARTER	
45	532 17 56-50	BARRE	
46	581 35 24-01	ADAPTATEUR	
47	586 17 98-01	COUTEAU	
48	532 85 10-74	RONDELLE	
49	532 85 02-63	RONDELLE	
50	532 85 10-84	VIS	
51	532 43 05-99	PLAQUE	
52	532 18 21-66	DECAL	
53	817 00 05-10	BOULON	
55	532 19 17-30	ÉCROU	
56	817 41 13-12	VIS	
57	532 15 53-77	ÉCROU	
58	585 90 82-02	POIGNÉE	
59	532 19 15-74	VIS	
62	532 43 50-59	SUPPORT	
64	588 84 35-06	MOTEUR	RATO RV150 10100-Z180310
68	532 43 11-38	VIS DE REGLAGE	
84	532 42 81-24	FASTENER	
96	532 19 79-91	COLLIER DE SERRAGE	
	532 18 21-91	LABEL WARNING	NOT SHOWN
	532 42 38-49	SAC	NOT SHOWN



ENTRAÎNEMENT

M56-150F, 96764820100, 2016-10

Référence	Numéro de Pièce	Description	Remarque
1	588 47 92-01	CÂBLE	
7	532 19 84-53	GUIDE-CHAÎNE	
11	581 00 92-05	ROUE COMPLÈTE	
12	812 00 00-58	CIRCLIP	
13	532 40 38-49	PIGNON	
14	581 84 04-01	PARE-POUSSIÈRE	
15	532 40 48-45	PAWL, DRIVE	
16	532 06 77-25	RONDELLE	
18	532 70 10-37	BOUTON	
25	532 43 17-11	SUPPORT	
26	532 16 34-09	VIS	
28	587 99 78-01	CARTER	Includes Mounting Screw & Pushnut
29	532 40 91-48	ÉCROU	
32	586 98 97-01	POULIE	
33	532 19 68-53	COURROIE	
35	581 49 79-07	VIS DE REGLAGE	LT FRT
36	532 42 47-41	GEARBOX	
38	532 43 81-30	ÉCROU	
40	532 40 65-58	RESSORT	
41	581 49 79-08	VIS DE REGLAGE	RT FRT
54	580 94 73-06	BAC DE RAMASSAGE COMPLET	
57	585 05 47-02	CADRE	