



# SPARE PARTS LIST

LAWN MOWERS: CONSUMER  
WALK-BEHINDS

M60B53 HW, 96141014100, 2007-04



| Référence | Numéro de Pièce | Description                 |
|-----------|-----------------|-----------------------------|
| 1         | 532 19 84-59    | POIGNÉE                     |
| 2         | 532 15 36-05    | POIGNÉE                     |
| 3         | 532 19 84-64    | COMMANDE                    |
| 4         | 532 18 35-67    | CÂBLE                       |
| 5         | 532 19 15-74    | VIS                         |
| 6         | 532 19 19-38    | BOUTON                      |
| 7         | 532 05 17-93    | AXE                         |
| 8         | 532 06 64-26    | HOOP                        |
| 9         | 532 40 69-85    | DÉFLECTEUR                  |
| 10        | 532 12 84-15    | RIVET                       |
| 11        | 532 41 05-40    | SUPPORT                     |
| 12        | 532 41 05-42    | SUPPORT                     |
| 13        | 817 06 04-10    | VIS                         |
| 14        | 532 18 25-43    | SUPPORT DE POIGNÉE          |
| 15        | 532 18 25-45    | SUPPORT DE POIGNÉE          |
| 16        | 532 40 54-17    | RESSORT                     |
| 17        | 532 40 54-18    | RESSORT                     |
| 18        | 532 13 20-04    | ÉCROU                       |
| 19        | 532 19 47-88    | GUIDE                       |
| 20        | 532 41 05-36    | PROTECTION                  |
| 21        | 532 05 45-83    | VIS                         |
| 25        | 532 15 04-06    | BOULON                      |
| 26        | 532 14 52-12    | ÉCROU                       |
| 27        | 532 40 29-35    | ROUE                        |
| 28        | 532 16 08-28    | BOULON                      |
| 30        | 532 40 25-71    | SUPPORT                     |
| 31        | 532 08 78-77    | BOUTON                      |
| 32        | 532 19 01-57    | SELECT*RPL.PAR 532175060004 |
| 33        | 873 80 05-00    | LOCK NUT                    |
| 34        | 532 40 25-72    | SUPPORT                     |
| 36        | 532 18 41-93    | BOULON                      |
| 37        | 874 78 05-12    | VIS                         |
| 38        | 819 11 22-06    | RONDELLE                    |
| 39        | 532 19 85-41    | ÉCROU                       |
| 40        | 532 19 09-39    | MOUNTING BRACKET, DEBRI     |
| 41        | 532 19 23-25    | VIS                         |
| 43        | 532 40 58-45    | CARTER DE COURROIE          |
| 44        | 532 40 93-64    | CHÂSSIS                     |
| 45        | 532 18 21-66    | DECAL                       |
| 46        | 532 40 46-33    | ADAPTATEUR                  |
| 47        | 532 19 93-77    | MOWER BLADE                 |
| 48        | 532 85 10-74    | RONDELLE                    |
| 49        | 532 85 02-63    | RONDELLE                    |
| 50        | 532 85 10-84    | VIS                         |
| 57        | 532 12 51-62    | PLAQUE                      |
| 58        | 532 75 06-34    | VIS                         |
| 65        | 532 19 74-80    | JOINT TORIQUE               |
| 66        | 532 08 83-48    | RONDELLE                    |
| 96        | 532 19 79-91    | COLLIER DE SERRAGE          |
| - -       | 532 18 21-34    | DECALC."WARNING"            |



| Référence | Numéro de Pièce | Description         |
|-----------|-----------------|---------------------|
| 1         | 532 19 46-53    | COMMANDE            |
| 2         | 532 19 10-39    | ROULEMENT           |
| 3         | 532 17 52-62    | VIS                 |
| 5         | 532 17 54-36    | COURROIE EN V       |
| 6         | 532 15 04-95    | PIN RETAINING SCREW |
| 7         | 532 19 84-53    | GUIDE-CHAÎNE        |
| 9         | 532 08 39-23    | ÉCROU               |
| 11        | 532 40 29-36    | ROUE                |
| 12        | 812 00 00-58    | CIRCLIP             |
| 13        | 532 40 38-49    | PIGNON              |
| 14        | 532 18 94-03    | PARE-POUSSIÈRE      |
| 15        | 532 19 10-17    | PAWL, DRIVE         |
| 16        | 532 06 77-25    | RONDELLE            |
| 18        | 532 08 78-77    | BOUTON              |
| 28        | 532 18 14-68    | CARTER              |
| 35        | 532 40 90-97    | SUPPORT             |
| 36        | 532 19 92-05    | GEARBOX             |
| 38        | 873 80 04-00    | ÉCROU               |
| 40        | 532 13 70-90    | RESSORT             |
| 41        | 532 40 90-98    | SUPPORT             |
| 54        | 532 19 48-53    | GRASSBAG            |
| 55        | 532 17 57-39    | DRIVESHAFT COVER    |
| 57        | 532 40 18-02    | CADRE               |
| 32        | 532 41 03-63    | DECAL               |
| 60        | 532 18 34-97    | POT                 |
| 61        | 532 18 34-98    | CARTER              |
| 62        | 532 18 34-99    | ENGRENAGE           |
| 63        | 532 18 35-00    | LEVIER              |
| 64        | 532 18 35-01    | RESSORT             |
| 65        | 532 18 35-02    | ARBRE               |
| 66        | 532 18 35-03    | DOG, MOVABLE        |
| 67        | 532 18 35-04    | DOG, FIXED          |
| 68        | 532 18 35-05    | WIRE, FORMED        |
| 69        | 532 18 35-06    | ROULEMENT À BILLES  |
| 70        | 532 18 35-07    | FOURCHE             |
| 71        | 532 18 35-08    | SEAL, OUTPUT SHAFT  |
| 72        | 532 18 35-09    | RONDELLE            |
| 73        | 532 18 35-10    | SEAL, CASE          |
| 74        | 532 18 35-11    | BUSHING             |
| 75        | 532 19 66-13    | ARBRE               |
| 76        | 532 18 35-13    | VIS                 |
| 77        | 532 18 35-14    | SEAL, INPUT SHAFT   |
| 78        | 532 19 98-52    | POULIE              |
| 79        | 532 19 94-19    | STYLO               |