



SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

MC550 F, 96142010100, 2011-11



Référence	Numéro de Pièce	Description	Remarque
1	532 42 79-75	HANDLE UPPER	
2	532 18 35-67	CÂBLE	
3	532 12 51-62	PLAQUE	
4	532 16 66-49	MULCHER PLUG	
5	532 06 64-26	HOOP	
6	532 19 19-38	BOUTON	
7	532 75 06-34	VIS	
8	532 41 48-06	REGLAGE	
9	532 40 84-92	PORTE COMPLETE	
10	532 12 84-15	RIVET	
12	817 06 04-10	VIS	
14	532 19 70-76	PLATE.BACK	
15	532 41 13-34	SIDE BAFFLE	
16	532 17 71-33	PLAQUE	
17	532 14 89-41	PLAQUE	
18	532 13 20-04	ÉCROU	
19	532 19 47-88	GUIDE	
20	532 41 31-60	SKIRT.REAR.22RD/SD.FO/*SUBS/2*	
21	532 40 54-21	RESSORT	LH
24	532 40 54-23	RESSORT	RH
25	532 40 91-48	ÉCROU	
26	532 18 41-93	BOULON	
27	532 41 21-73	ROUE	REAR
28	532 17 47-19	BOULON	
29	532 40 16-30	RONDELLE	
30	532 40 78-71	AXE	
31	532 43 63-48	BOUTON	
32	532 40 64-28	RESSORT	
33	532 19 60-53	MULCHER DOOR	
34	532 40 16-29	RONDELLE D'ESPACEMENT	
35	532 41 06-24	WHEEL ADJUSTING BRACKET	RH
36	532 17 57-35	CHARNIÈRE	
37	532 42 88-67	BOULON	
38	532 40 30-73	DÉFLECTEUR	
39	532 19 70-28	BRKT.ASM.HANDLE.LT	LH
40	532 19 70-27	RT HANDLE BRKT	RH
41	532 15 04-06	BOULON	
42	532 19 30-00	CHARNIÈRE	
43	873 80 04-00	ÉCROU	
44	532 41 71-23	CARTER COMPLET	
45	532 17 56-50	BARRE	
46	532 19 59-63	ADAPTATEUR	
47	532 40 67-13	COUTEAU	
48	532 85 10-74	RONDELLE	
49	532 85 02-63	RONDELLE	
50	532 85 10-84	VIS	
51	532 17 00-31	PLAQUE	
52	532 40 47-63	DECAL	
53	817 60 04-06	VIS	
55	873 93 06-00	ÉCROU	
56	532 08 86-52	VIS	
57	532 05 17-93	AXE	
58	532 43 45-14	POIGNÉE	
59	532 19 15-74	VIS	
64	000 00 00-00	W/O DESCRIPTION	B&S 9P702-0024-F1 FOR SERVICE AND PARTS CALL 1-800-233-3723
68	532 41 06-23	WHEEL ADJUSTING BRACKET LH	LH
69	532 19 79-91	COLLIER DE SERRAGE	
71	532 42 90-01	SUPPORT	
	532 40 47-64	DECAL	NOT SHOWN
11	532 15 00-50	VIS	



Référence	Numéro de Pièce	Description	Remarque
1	532 19 46-53	COMMANDE	INCLUDES CABLE
7	532 43 52-81	REGLAGE	
11	532 19 79-86	WHEEL & TIRE ASSEMBLY	FRONT
12	812 00 00-58	CIRCLIP	
13	532 40 38-49	PIGNON	
14	532 18 94-03	PARE-POUSSIÈRE	
15	532 40 48-45	PAWL, DRIVE	
16	532 06 77-25	RONDELLE	
17	532 19 10-39	ROULEMENT	
18	532 43 63-48	BOUTON	
19	532 15 04-95	PIN RETAINING SCREW	
27	532 17 52-62	VIS	
28	532 40 33-42	CARTER	
29	532 40 91-48	ÉCROU	
33	532 14 65-27	COURROIE	
35	532 43 84-85	VIS DE REGLAGE	LH INCLUDES KNOB & BEARING
36	532 41 52-26	BOITE A VITESSE	
38	873 80 04-00	ÉCROU	
40	532 13 70-90	RESSORT	
41	532 43 84-86	VIS DE REGLAGE	RH INCLUDES KNOB & BEARING
54	532 44 07-31	GRASSBAG	
57	532 41 19-52	GRASSBAG	