


SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

MC625 RX, 96132006600, 2010-11



Référence	Numéro de Pièce	Description	Remarque
1	532 43 63-38	REGLAGE	
2	532 19 55-47	POIGNÉE	
3	532 17 42-91	POIGNÉE	
4	532 19 47-88	GUIDE	
5	532 13 20-04	ÉCROU	
6	532 19 15-74	VIS	
7	532 06 64-26	HOOP	
8	874 78 05-12	VIS	
9	532 15 41-32	SUPPORT	
10	532 16 57-54	PORTE	
11	532 18 32-81	CÂBLE	
12	532 75 06-34	VIS	
13	532 43 00-34	SUPPORT	
14	532 19 19-38	BOUTON	
15	532 05 17-93	AXE	
18	817 60 04-06	VIS	
19	532 40 66-89	AXE	FRONT, LEFT
20	532 40 66-90	AXE	FRONT, RIGHT
21	532 41 86-55	KIT SKIRT 21 DOMED W/LIP	
22	532 40 64-28	RESSORT	
23	532 41 06-03	DÉFLECTEUR	
25	532 41 39-60	SUPPORT DE POIGNÉE	LH
26	532 41 39-62	SUPPORT DE POIGNÉE	RH
28	532 41 44-41	SUPPORT	FRONT, LEFT
29	532 41 44-40	SUPPORT	FRONT, RIGHT
30	532 40 16-29	RONDELLE D'ESPACEMENT	
31	532 16 57-60	DÉFLECTEUR	
32	532 41 05-95	RESSORT	
33	532 43 63-48	BOUTON	
34	532 41 06-00	AXE	REAR, LEFT
35	532 42 65-89	ÉCROU	
36	532 40 16-38	BOULON	
37	532 43 64-33	ROUE	
39	532 40 91-49	ÉCROU	
40	532 41 19-49	CADRE	
41	532 08 86-52	VIS	
42	532 40 54-21	RESSORT	LH
43	532 40 54-23	RESSORT	RH
44	532 18 41-93	BOULON	
45	532 15 04-06	BOULON	
46	532 40 47-63	DECAL	
47	532 75 11-53	ÉCROU	
48	532 41 06-01	AXE	REAR, RIGHT
49	532 43 67-10	ROUE	
50	532 43 85-83	GRASSBAG	
51	532 14 72-86	BARRE	
52	532 41 39-80	KIT	
53	532 85 10-84	VIS	
54	532 85 02-63	RONDELLE	
55	532 85 10-74	RONDELLE	
56	532 40 67-12	MOWER BLADE	
57	532 41 83-73	ADAPTATEUR	
58	532 15 21-24	RESSORT	
59	000 00 00-00	W/O DESCRIPTION	B&S 122L02-1533-ED FOR SERVICE & PARTS 1-800-233-3723
61	532 40 91-48	ÉCROU	
62	873 80 04-00	ÉCROU	
65	532 08 83-48	RONDELLE	
66	532 19 74-80	JOINT TORIQUE	
67	532 19 79-91	COLLIER DE SERRAGE	
73	532 40 16-30	RONDELLE	
74	532 12 50-78	RONDELLE	
75	532 41 36-93	KIT	
76	532 41 05-89	BAFFLE.REAR.PLASTIC.21.RD.ECON	
77	817 41 13-12	VIS	
	532 40 47-64	DECAL	NOT SHOWN