



SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

MM4756 SMD, 96121001302, 2007-04



Référence	Numéro de Pièce	Description
1	532 40 32-98	POIGNÉE
2	532 17 51-48	CÂBLE
3	532 75 06-34	VIS
4	532 12 51-62	PLAQUE
5	532 06 64-26	HOOP
6	532 19 18-56	BOUTON
8	532 41 31-85	CONTROL BAR
9	532 19 58-00	SUPPORT
10	532 17 09-75	SUPPORT
11	532 19 57-99	SUPPORT
12	532 17 09-77	SUPPORT
14	532 14 97-41	VIS
16	532 05 45-83	VIS
17	532 17 71-41	SUPPORT ROD
18	532 13 20-04	ÉCROU
19	532 19 47-88	GUIDE
20	532 15 41-47	PROTECTOR
24	532 06 91-80	ÉCROU
25	532 40 91-49	ÉCROU
27	532 40 31-22	ROUE
28	532 14 27-48	BOULON
29	532 40 16-30	RONDELLE
30	532 40 65-82	AXE
31	532 08 78-77	BOUTON
32	532 40 64-28	RESSORT
33	532 15 18-89	PROTECTEUR
34	532 40 16-29	RONDELLE D'ESPACEMENT
35	532 41 08-07	SUPPORT
36	532 15 41-32	SUPPORT
38	532 17 65-09	DEFL ECTOR, DISCHARGE
39	532 40 33-82	SUPPORT
40	532 40 33-81	SUPPORT
41	532 15 04-06	BOULON
42	532 15 21-24	RESSORT
43	873 80 04-00	ÉCROU
44	532 41 00-54	PLATEAU DE COUPE
45	532 14 72-86	BARRE
46	532 19 59-63	ADAPTATEUR
47	532 19 93-79	MOWER BLADE
48	532 85 10-74	RONDELLE
49	532 85 02-63	RONDELLE
50	532 85 10-84	VIS
52	532 18 21-66	DECAL
54	532 08 83-48	RONDELLE
55	532 19 09-39	MOUNTING BRACKET, DEBRI
56	532 08 58-25	VIS
57	532 05 17-93	AXE
58	532 15 50-44	POIGNÉE
59	532 19 15-74	VIS
60	874 76 06-12	BOULON
61	532 75 15-92	LOCKNUT 3/8-16 RL508A/B
62	532 40 58-43	SHEILD
63	532 19 23-25	VIS
67	532 19 74-80	JOINT TORIQUE
72	532 19 79-91	COLLIER DE SERRAGE
--	532 18 21-34	DECALC."WARNING"
--	532 40 99-65	OPERATOR'S MANUAL
--	532 40 99-66	OPERATOR'S MANUAL



Référence	Numéro de Pièce	Description
1	532 19 46-53	COMMANDE
2	532 19 10-19	ROULEMENT
3	532 14 36-03	VIS
5	532 14 65-27	COURROIE
6	532 15 04-95	PIN RETAINING SCREW
7	532 19 84-53	GUIDE-CHAÎNE
9	532 40 91-48	ÉCROU
11	532 19 80-88	ROUE
12	812 00 00-58	CIRCLIP
13	532 40 38-49	PIGNON
14	532 18 94-03	PARE-POUSSIÈRE
15	532 19 10-17	PAWL, DRIVE
16	532 06 77-25	RONDELLE
18	532 08 78-77	BOUTON
28	532 19 58-11	CARTER
35	532 40 88-00	COMMANDE
36	532 19 92-06	GEARBOX
38	873 80 04-00	ÉCROU
40	532 13 70-90	RESSORT
41	532 40 88-01	COMMANDE
60	532 18 34-97	POT
61	532 18 34-98	CARTER
62	532 18 34-99	ENGRENAGE
63	532 18 35-00	LEVIER
64	532 18 35-01	RESSORT
65	532 18 35-02	ARBRE
66	532 18 35-03	DOG, MOVABLE
67	532 18 35-04	DOG, FIXED
68	532 18 35-05	WIRE, FORMED
69	532 18 35-06	ROULEMENT À BILLES
70	532 18 35-07	FOURCHE
71	532 18 35-08	SEAL, OUTPUT SHAFT
72	532 18 35-09	RONDELLE
73	532 18 35-10	SEAL, CASE
74	532 18 35-11	BUSHING
75	532 19 65-61	ARBRE
76	532 18 35-13	VIS
77	532 18 35-14	SEAL, INPUT SHAFT
78	532 19 98-52	POULIE
79	532 19 94-19	STYLO