


SPARE PARTS LIST


SNOW BLOWERS/THROWERS

MC621, 96182000500, 2010-09



Référence	Numéro de Pièce	Description	Remarque
1	532 42 05-78	TÊTE (ÉCROU) DE CYLINDRE	
2	532 42 05-79	PUSH ROD SERVICE KIT	
3	532 42 05-80	VALVE COVER SERVICE KIT	
4	532 43 65-67	CYLINDRE	
5	532 42 05-82	PISTON COMPLET	
6	532 42 05-83	BIELLE	
7	532 42 05-84	ARBRE À CAMES	
8	532 42 92-35	VOLANT COMPLET	
9	532 42 05-86	VOLANT	
10	532 44 66-42	VILEBREQUIN	
13	532 43 65-63	SILENCIEUX COMPLET	
14	532 43 65-64	RÉSERVOIR DE CARBURANT COMPLET	
15	532 42 92-34	FUEL	
16	532 42 49-42	RÉSERVOIR À ESSENCE	
17	585 02 04-02	CARBURATEUR	
18	532 44 39-34	BOBINE D'ALLUMAGE	
19	532 42 49-55	CDI BOX	
20	532 42 49-39	BOUGIE D'ALLUMAGE	
21	532 42 49-57	ON/OFF SWITCH	
22	000 00 00-00	W/O DESCRIPTION	NOT REQUIRED FOR THIS ENGINE
23	532 43 80-14	JEU DE TUYAUX	
24	532 42 92-59	SPEED CONTROL BRACKET	
25	532 42 96-46	ENGRENAGE	
26	581 76 87-01	CARBURATEUR	
27	532 42 06-02	GOVERNOR	
28	532 43 69-67	RECOIL	
29	532 42 49-66	STARTER CUP SMALL	
30	580 96 05-01	BLOWER HOUSING	
30	581 19 20-01	BLOWER HOUSING ASSY	
31	532 42 06-06	CARTER MOTEUR	
31	532 44 37-73	CARTER	
32	532 42 95-99	SEAL KIT	
34	532 43 69-66	BOTTES	
35	532 43 64-66	LANCEUR	
36	532 42 96-01	JEU DE JOINTS	
37	532 42 09-61	JAUGE	
38	532 42 96-91	ROCKER ARM KIT	
39	532 42 92-24	STARTER	
40	532 42 95-98	NON REMOVABLE PLUG	
42	000 00 00-00	W/O DESCRIPTION	NOT REQUIRED FOR THIS ENGINE
43	580 35 34-01	RENIFLARD	
47	532 42 49-69	HIGH OIL FILL	
47	581 00 72-01	TUBE ASSY	
48	532 42 92-84	HARNAIS	
49	532 43 54-95	BOUCHON D	
50	532 43 65-61	BOÎTE	
51	532 43 71-19	ÉCRAN	
52	532 42 49-49	FUEL PRIMER BULB ASSY W/HOSE	
53	532 42 49-54	KEY START ASSY	
54	532 44 30-59	KIT	
55	532 43 26-86	EXTENDED OIL DRAIN TUBE	
56	585 77 33-01	ÉCRAN	
57	000 00 00-00	W/O DESCRIPTION	NOT REQUIRED FOR THIS ENGINE
58	532 42 49-60	GOVERNOR	
59	532 43 65-62	SKIRT	
60	000 00 00-00	W/O DESCRIPTION	NOT REQUIRED FOR THIS ENGINE
61	532 43 27-52	FUEL KNOB-SNOW	
62	532 44 38-99	POIGNÉE DE DÉMARRAGE	
65	581 37 28-01	POUSOIR DE SOUPAPE	


Référence	Numéro de Pièce	Description	Remarque
69	532 42 49-51	CARB STUDS AND COUPLINGS KIT	
70	580 35 36-01	CARBURATEUR	
72	000 00 00-00	W/O DESCRIPTION	NOT REQUIRED FOR THIS ENGINE
74	581 76 88-01	CARTER DE SILENCIEUX	
77	532 43 26-88	BOLT KIT	
78	581 45 93-01	SUPPORT	
79	585 77 37-01	CARTER DE CARBURATEUR	
80	587 17 86-01	ÉCRAN	
81	585 29 72-01	CLAVETTE	
82	585 02 05-03	RONDELLE D'ESPACEMENT	
85	586 32 56-01	TAMIS	
86	586 32 73-01	BOULON	
87	586 32 69-01	BOULON	
88	586 32 68-01	GOIJON	
89	000 00 00-00	W/O DESCRIPTION	NOT REQUIRED FOR THIS ENGINE
91	587 52 57-01	CARTER	
97	593 30 19-01	PROTECTEUR	
9999	586 32 62-01	GICLEUR	
9999	579 80 64-01	BOULON	



MOTEUR


MC621, 96182000500, 2010-09

Référence	Numéro de Pièce	Description	Remarque
3	532 44 42-77	SILENCIEUX COMPLET	
6	585 02 04-02	CARBURATEUR	"INCLUDES BRACKET, SPACER, AND NUTS"
8	532 43 71-23	AMPOULE	
10	532 43 71-24	LANCEUR COMPLET	
10A	532 43 71-25	LANCEUR	
11	532 42 49-54	KEY START ASSY	
17	532 43 69-67	RECOIL	HEX STYLE - BLACK & INCLUDES SCREWS
18	532 43 69-68	COUPE	
19	532 42 49-68	SNOW STARTER CHIP	
20	532 42 49-71	BLOW.HSG ASSY ELEC	ELECTRIC BLACK & INCLUDES SCREWS
20A	532 42 92-30	BLOWER HOUSING, ELECTRIC,BLACK	ELECTRIC BLACK
21	532 43 71-19	ÉCRAN	
22	532 42 49-75	SHLD ELEC START FLYWHEEL	
22A	532 42 95-96	SHIELD. FLYWHEEL - MANUAL START	MANUAL START
23	532 42 05-80	VALVE COVER SERVICE KIT	INCLUDES SCREWS
26	532 42 92-35	VOLANT COMPLET	
26A	532 42 05-85	VOLANT	
27	532 44 40-91	TUBE	
28	532 42 05-86	VOLANT	
29A	532 44 39-34	BOBINE D'ALLUMAGE	
30	532 42 06-06	CARTER MOTEUR	INCLUDES SCREWS
31	532 42 09-61	JAUGE	
34	532 43 69-66	BOTTES	
36	532 42 06-01	GOVERNOR ARM SERVICE KIT	
37	532 42 06-02	GOVERNOR	
38	532 42 96-46	ENGRENAGE	
39	532 42 05-84	ARBRE À CAMES	
40	532 42 05-78	TÊTE (ÉCROU) DE CYLINDRE	INCLUDES SCREWS
41	532 42 49-39	BOUGIE D'ALLUMAGE	
44	532 42 05-82	PISTON COMPLET	
46	532 42 92-60	VAPOR SHIELD	
46A	532 44 42-75	ÉCRAN	
47	532 42 95-99	SEAL KIT	
48	532 44 42-76	HARNAIS	
49	532 42 96-00	VILEBREQUIN	
50	532 42 92-59	SPEED CONTROL BRACKET	
52	532 42 96-91	ROCKER ARM KIT	
53	532 42 05-79	PUSH ROD SERVICE KIT	
56	532 42 96-01	JEU DE JOINTS	
57	532 43 80-14	JEU DE TUYAUX	
62	532 43 54-95	BOUCHON D	
65	532 43 54-95	BOUCHON D	



SSST-Chute asm_5

Référence	Numéro de Pièce	Description
1	532 43 48-77	TUBE
2	532 43 76-40	PLAQUE
3	532 43 76-35	PLAQUE
4	817 41 13-12	VIS
5	532 43 76-42	POIGNÉE
6	873 97 05-00	ÉCROU
7	532 43 48-79	RESSORT
8	532 08 13-28	BOULON
9	532 43 48-78	BRAS
10	532 13 20-04	ÉCROU
11	532 43 76-26	VIS D'AVANCE
15	532 43 73-18	BOULON
16	532 43 76-55	TUBE
17	532 19 19-38	BOUTON
18	532 43 76-43	DÉFLECTEUR
19	819 13 13-16	RONDELLE
20	819 13 24-16	RONDELLE
21	532 42 88-67	BOULON




SSST-Handle asm_1

POIGNEE


MC621, 96182000500, 2010-09

Référence	Numéro de Pièce	Description
1	532 43 76-47	REGLAGE
2	532 43 76-46	POIGNÉE
3	532 43 48-06	CABLE DE CONTRÔLE
4	532 19 19-38	BOUTON
5	532 19 15-74	VIS
6	532 14 50-06	COLLIER DE SERRAGE




SSST-Auger asm_1

Référence	Numéro de Pièce	Description
1	872 11 04-07	BOULON
2	532 43 76-20	AXE
3	532 19 96-87	VIS
4	532 43 76-18	PLAQUE
5	532 13 20-04	ÉCROU
6	819 09 10-16	RONDELLE
7	532 43 74-59	COUTEAU
8	532 43 76-17	VIS D'AVANCE
9	532 43 76-21	ROULEMENT
10	532 43 76-22	ROULEMENT
11	817 60 04-06	VIS
12	872 11 04-04	BOULON
13	532 43 81-30	ÉCROU
14	812 00 00-28	COLLIER DE SERRAGE



SSST-Shroud asm_12


Référence	Numéro de Pièce	Description
1	532 43 76-27	CARTER
2	532 43 76-30	CARTER
3	532 43 76-34	CARTER
4	532 43 02-20	ENJOLIVEUR
5	532 43 62-35	PRIMER
6	532 43 54-07	CARTER
7	532 43 76-48	CARTER
8	532 43 76-31	PLAQUE
9	817 41 13-12	VIS
10	817 49 04-12	VIS
11	532 43 48-80	RÉSERVOIR COMPLET
12	532 14 68-48	BANDE
14	532 43 54-09	TOUCHE
15	532 43 48-68	COLLIER DE SERRAGE
16	532 43 62-76	POIGNÉE DE DÉMARRAGE
17	532 19 66-88	ÉCROU
18	532 43 76-19	PROTECTEUR
19	532 43 80-39	BOULON
20	819 09 10-16	RONDELLE



CHASSIS

MC621, 96182000500, 2010-09

Référence	Numéro de Pièce	Description
1	532 43 48-56	MOTEUR
2	532 43 76-06	CADRE
3	532 43 76-16	ROUE
4	532 43 54-17	ÉCROU
5	532 43 55-78	VIS
6	532 15 04-06	BOULON
7	532 19 17-30	ÉCROU
8	872 14 04-05	BOULON
9	532 43 55-35	RACLOIR
10	532 43 48-57	RONDELLE D'ESPACEMENT
11	532 43 48-74	LEVIER
12	817 41 13-12	VIS



Référence	Numéro de Pièce	Description
1	532 43 48-60	RONDELLE D'ESPACEMENT
2	532 43 45-02	HOLDER
3	532 42 64-90	POULIE
4	532 85 10-74	RONDELLE
5	532 43 72-61	COURROIE
6	532 43 08-17	BOULON
7	532 43 48-59	RESSORT
8	532 43 76-09	BRAS
9	532 16 60-43	POULIE
10	817 06 06-20	VIS
11	532 19 90-92	RONDELLE D'ESPACEMENT
13	532 43 53-83	POULIE