


Ref #	Part #	Description	Qty	Context Note	Foot Note
188	793480	SCREW		(Control Bracket)	
202	590517	LINK, Mechanical Governor			
209	590541	SPRING, Governor			
222	590560	BRACKET, Control			
222A	596458	BRACKET, Control		Used After Code Date 17010100	
222A	590561	BRACKET, Control		Used Before Code Date 17010200	
227	590520	LEVER, Governor Control			
236	591292	LINK, Lockout			
265	690798	CLAMP, Casing			
265A	691024	CLAMP, Casing			
267	692577	SCREW		(Casing Clamp)	
268	691025	CASING, Control Wire		(Cut To Required Length)	
269	691026	WIRE, Control		(Cut To Required Length)	
270	691027	NUT		(Control Wire Casing)	
271	691028	LEVER, Control			
333	593872	ARMATURE, Magneto			
334	691061	SCREW		(Magneto Armature)	
337	692051	PLUG, Spark		(Resistor)	
356	692390	WIRE, Stop			
356C	796798	WIRE, Stop			
383	19576S	WRENCH, Spark Plug			
505	793515	NUT		(Governor Control Lever)	
562	793514	BOLT		(Governor Lever)	
621	692310	SWITCH, Stop			
635	692076	BOOT, Spark Plug			
745	691146	SCREW		(Brake)	
745A	690859	SCREW		(Brake)	
922	692135	SPRING, Brake			
923	691487	BRAKE			

332 

668 

455 




455A 

363 





23  1005 
23A 

850  37  78 


Ref #	Part #	Description	Qty	Context Note	Foot Note
23	590544	FLYWHEEL			
23A	592005	FLYWHEEL			
37	594729	GUARD, Flywheel			
78	793480	SCREW		(Flywheel Guard)	
332	690662	NUT		(Flywheel)	
363	19619	PULLER, Flywheel			
455	590545	CUP, Flywheel		Used Before Code Date 14082500	
455A	593960	CUP, Flywheel		(To Be Used With Reference 608 And 770C)	
				Used After Code Date 14082400	
668	590546	SPACER			
850	100106	SEALANT, Liquid			
1005	592050	FAN, Flywheel			



Ref #	Part #	Description	Qty	Context Note	Foot Note
58	591108	ROPE, Starter			
60	691915	GRIP, Starter Rope			
60A	281434S	GRIP, Starter Rope			
60B	799716	GRIP, Starter Rope			
304	593961	HOUSING, Blower			
304A	593962	HOUSING, Blower			
304D	596457	HOUSING, Blower			
305	590586	SCREW		(Blower Housing)	
455	590545	CUP, Flywheel		Used Before Code Date 14082500	
455A	593960	CUP, Flywheel		(To Be Used With Reference 608 And 770C) Used After Code Date 14082400	
608	593959	STARTER, Rewind		(To Be Used With Reference 455A) (Not To Be Used With Reference 455) Used After Code Date 14082400	
770D	595355	KIT, Rewind/Blower Housing			
930	590585	GUARD, Rewind		Used Before Code Date 15041300	





BRIGGS & STRATTON






Ref #	Part #	Description	Qty	Context Note	Foot Note
187	791766	LINE, Fuel		(Cut To Required Length)	
300B	590565	MUFFLER			
601	791850	CLAMP, Hose			
613	590562	SCREW		(Muffler)	
832B	592709	GUARD, Muffler			
836	690661	SCREW		(Muffler Guard)	
957	799585	CAP, Fuel Tank		Used Before Code Date 16082900	
957B	692046	CAP, Fuel Tank			
957C	596250	CAP, Fuel Tank			
972A	591947	TANK, Fuel			

Ref #	Part #	Description	Qty	Context Note	Foot Note
1	592048	CYLINDER ASSEMBLY			
3	299819S	SEAL, Oil		(Magneto Side)	
4	590569	SUMP, Engine			
7	799586	GASKET, Cylinder Head		Used Before Code Date 18070100	
7	84001992	GASKET, Cylinder Head		Used After Code Date 18063000	
12	799587	GASKET, Crankcase			
16	590538	CRANKSHAFT			
20	391483S	SEAL, Oil		(PTO Side)	
22	692551	SCREW		(Crankcase Cover/Sump)	
22A	590763	SCREW		(Crankcase Cover/Sump)	
24	222698S	KEY, Flywheel			
25	591975	PISTON ASSEMBLY		(Standard)	
26	591976	SET, Ring		(Standard)	
27	691588	LOCK, Piston Pin			
28	699659	PIN, Piston		(Standard)	
29	590518	ROD, Connecting			
32	691664	SCREW		(Connecting Rod)	
43	697799	SLINGER, Governor/Oil		Used Before Code Date 16071100	
43	594560	SLINGER, Governor/Oil		Used After Code Date 16071000	
46	592968	CAMSHAFT			
163	799580	GASKET, Air Cleaner		(Air Cleaner)	
227	590520	LEVER, Governor Control			
358	595350	GASKET SET, Engine		(Service Kits may include extra parts not specific to this engine.) Used Before Code Date 18070100	
358	84001272	GASKET SET, Engine		(Service Kits may include extra parts not specific to this engine.) Used After Code Date 18063000	
404	690272	WASHER		(Governor Crank)	
505	793515	NUT		(Governor Control Lever)	
522	590580	PLUG, Dipstick/Fill			
523	796503	DIPSTICK			
524	691876	SEAL, O-Ring			
562	793514	BOLT		(Governor Lever)	
598	593291	SHIM, End Play		(Crankshaft or Camshaft Bearing)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
615	690340	RETAINER, Governor Shaft			
616	590516	CRANK, Governor			
623	799581	SEAL, O-Ring		(Carburetor Spacer)	
718	690959	PIN, Locating		(Crankcase Cover)	
741	796210	GEAR, Timing			
842	691031	SEAL, O-Ring		(Dipstick Tube)	
847	590572	DIPSTICK/TUBE ASSEMBLY			
868	590534	SEAL, Valve		Used Before Code Date 18070100	
868	84001271	SEAL, Valve		Used After Code Date 18063000	
1022	591255	GASKET, Rocker Cover			
1036		Label-Emissions		(Available From A Briggs & Stratton Authorized Dealer)	
1263	697124	REED, Breather			
1264	793453	SCREW		(Breather Reed)	
1319	794467	LABEL, Warning			
1319A	797669	LABEL, Warning			





Ref #	Part #	Description	Qty	Context Note	Foot Note
5	595351	HEAD, Cylinder		Used Before Code Date 18070100	
5	84001270	HEAD, Cylinder		Used After Code Date 18063000	
7	799586	GASKET, Cylinder Head		Used Before Code Date 18070100	
7	84001992	GASKET, Cylinder Head		Used After Code Date 18063000	
11	590522	TUBE, Breather			
13	590512	SCREW		(Cylinder Head)	
33	590531	VALVE, Exhaust			
34	590530	VALVE, Intake		Used Before Code Date 18070100	
34	84001987	VALVE, Intake		Used After Code Date 18063000	
35	590532	SPRING, Valve		(Intake)	
36	590532	SPRING, Valve		(Exhaust)	
40	590528	RETAINER, Valve			
45	590514	TAPPET, Valve			
155	590529	PLATE, Cylinder Head			
163	799580	GASKET, Air Cleaner		(Air Cleaner)	
192	590535	ADJUSTER. Rocker Arm			
238	590533	CAP, Valve			
318	793480	SCREW		(Mounting Bracket)	
535	799579	FILTER, Air Cleaner Foam			
623	799581	SEAL, O-Ring		(Carburetor Spacer)	
868	590534	SEAL, Valve		Used Before Code Date 18070100	
868	84001271	SEAL, Valve		Used After Code Date 18063000	
875B	595663	BASE, Air Cleaner		Used After Code Date 16071000	
875B	590584	BASE, Air Cleaner		Used Before Code Date 16071100	
914	591103	SCREW		(Rocker Cover)	
968B	595660	COVER, Air Cleaner			
971	590552	SCREW		(Air Cleaner Base to Carburetor/Throttle Body)	
976	594281	PRIMER, Carburetor			
1022	591255	GASKET, Rocker Cover			
1023	595349	COVER, Rocker			
1026	590515	ROD, Push			
1029	590526	ARM, Rocker			
1029A	590527	ARM, Rocker			