







Copyright © Briggs & Stratton, U.S.A. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
3	299819S	SEAL-OIL		(Magneto Side)	
7	793455	GASKET, Cylinder Head			
9	793439	GASKET, Breather			
12	793445	GASKET, Crankcase		(.015)(Standard)	
20	399781S	SEAL-OIL		(PTO Side)	
51	692555	GASKET, Intake		(2 Required)	
163	691894	GASKET, Air Cleaner		(Air Cleaner)	
309A	84004559	MOTOR, Starter		Used Before Code Date 19021500	
309A	84004560	MOTOR, Starter		Used After Code Date 19021400	
358	793623	GASKET SET, Engine			
513	795100	CLUTCH-DRIVE		Used Before Code Date 13092500	
742	795094	RETAINER-E RING		Used After Code Date 08123100 Used Before Code Date 13092500	
742	93941	RETAINER, E Ring		Used Before Code Date 09010100	
783	795099	GEAR-PINION		Used Before Code Date 13092500	
783A	795096	GEAR-PINION		Used Before Code Date 13092500	
868	793507	SEAL, Valve			
883	793497	GASKET, Exhaust			
937	798330	SPLINE, Starter		Used Before Code Date 13092500	
1009	794099	SCREW		(Starter Motor)	
1022	793437	GASKET, Rocker Cover			
1095	793624	GASKET SET, Valve			



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
51	692555	GASKET, Intake		(2 Required)	
104	698536	PIN, Float Hinge		Used Before Code Date 12111900	
104B	592486	PIN, Float Hinge		Used After Code Date 12111800	
105	698537	VALVE, Float Needle		Used Before Code Date 12111900	
105B	592491	VALVE, Float Needle		Used After Code Date 12111800	
117A	793694	JET, Main		(Standard) Used Before Code Date 12111900	
117B	592490	JET, Main		(Standard) Used After Code Date 12111800	
118A	793695	JET, Main		(High Altitude) Used Before Code Date 12111900	
118B	592142	JET, Main		(High Altitude) Used After Code Date 12111800	
121	793622	KIT, Carburetor Overhaul			
121B	592483	KIT, Carburetor Overhaul			
122	793456	SPACER, Carburetor			
125A	793493	CARBURETOR		Used Before Code Date 12111900	
125B	595509	CARBURETOR		Used After Code Date 12111800	
133	698539	FLOAT, Carburetor		Used Before Code Date 12111900	
133B	592487	FLOAT, Carburetor		Used After Code Date 12111800	
137	698538	GASKET, Float Bowl		Used Before Code Date 12111900	
137B	592485	GASKET, Float Bowl		Used After Code Date 12111800	
163	691894	GASKET, Air Cleaner		(Air Cleaner)	
217	797864	SPRING, Choke Return		Used Before Code Date 12111900	
217B	592484	SPRING, Choke Return		Used After Code Date 12111800	
254	592493	DRAIN, Carburetor Bowl		Used After Code Date 12111800	
276	793627	WASHER, Sealing		Used Before Code Date 12111900	
276B	592489	WASHER, Sealing		Used After Code Date 12111800	
365	793458	SCREW		(Carburetor)	
623	793628	SEAL, O-Ring		(Carburetor Spacer)	
950	793465	SCREW		(Float Bowl) Used Before Code Date 12111900	
950B	592488	SCREW		(Float Bowl) Used After Code Date 12111800	
975	793464	BOWL, Float		Used Before Code Date 12111900	
975B	592492	BOWL, Float		Used After Code Date 12111800	



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
1	84004558	CYLINDER ASSEMBLY		Used Before Code Date 19021500	
1	84004557	CYLINDER ASSEMBLY		Used After Code Date 19021400	
2	796961	KIT, Bushing/Seal		(Magneto Side)	
3	299819S	SEAL-OIL		(Magneto Side)	
4	793509	SUMP, Engine			
5	592536	HEAD, Cylinder			
7	793455	GASKET, Cylinder Head			
9	793439	GASKET, Breather			
11	793447	TUBE, Breather			
12	793445	GASKET, Crankcase		(.015)(Standard)	
13	793451	SCREW		(Cylinder Head)	
15	691680	PLUG-OIL DRAIN			
16	793616	CRANKSHAFT			
20	399781S	SEAL-OIL		(PTO Side)	
22	793450	SCREW		(Crankcase Cover/Sump)	
24	222698S	KEY, Flywheel			
25	793519	PISTON ASSEMBLY		(Standard)	
25	793518	PISTON ASSEMBLY		(.020 Oversize)	
26	793517	SET, Ring		(.020 Oversize)	
26	793435	SET, Ring		(Standard)	
27	691588	LOCK, Piston Pin			
28	298909	PIN-PISTON/STD		(Standard)	
29	793510	ROD, Connecting			
32	691664	SCREW		(Connecting Rod)	
32A	695759	SCREW		(Connecting Rod)	
33	793505	VALVE, Exhaust			
34	793504	VALVE, Intake			
35	793506	SPRING, Valve		(Intake)	
36	793506	SPRING, Valve		(Exhaust)	
40	793503	RETAINER, Valve			
51	692555	GASKET, Intake		(2 Required)	
75	691736	WASHER		(Flywheel)	
219	793512	GEAR, Governor			
238	793535	CAP, Valve			
332	690662	NUT		(Flywheel) (SAE)	
337	692720	PLUG, Spark		(EMS)	
371	794574	GEAR, Cam			
383	19576S	WRENCH, Spark Plug			
423	592511	STUD		(Control Guard)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
598	592587	SHIM, End Play		(Crankshaft or Camshaft Bearing)	
635	66538S	BOOT, Spark PLug			
718	690959	PIN, Locating		(Cylinder)	
741	793446	GEAR, Timing			
787	793513	ARM, Lever			
793	793511	SET, Screw/Nut			
868	793507	SEAL, Valve			
883	793497	GASKET, Exhaust			
914	794451	SCREW		(Rocker Cover)	
1022	793437	GASKET, Rocker Cover			
1023	793436	COVER, Rocker			
1036		Label-Emissions		(Available From A Briggs & Stratton Authorized Dealer)	
1263	697124	REED, Breather			
1264	793453	SCREW		(Breather Reed)	
1319	794467	LABEL, Warning			
1319A	797669	LABEL, Warning			
1330	277527	MANUAL, Repair			
1375	793442	COVER, Breather Reed			
1376	699851	SCREW		(Breather Reed Cover)	







Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
23	595414	FLYWHEEL			
37	793473	GUARD, Flywheel			
37A	794106	GUARD, Flywheel			
58	697316	ROPE, Starter		(88 5/8)	
60	281434S	GRIP, Starter Rope		(Standard Grip)	
60A	799716	GRIP, Starter Rope		(Ergonomic Grip)	
75	691736	WASHER		(Flywheel)	
78	793480	SCREW		(Flywheel Guard)	
81	691740	LOCK, Muffler Screw			
258	699481	SCREW		(Control Guard)	
300B	793679	MUFFLER			
304	793486	HOUSING, Blower		(Rewind Start)	
304	794105	HOUSING, Blower		(Electric Start)	
332	690662	NUT		(Flywheel) (SAE)	
332A	591988	NUT		(Flywheel) (Metric)	
363	19069	PULLER, Flywheel			
423	592511	STUD		(Control Guard)	
592	793481	NUT		(Rewind Starter)	
608	593958	STARTER, Rewind		(Do Not Use With Instart Engines)	
613	793469	SCREW		(Muffler)	
613A	793495	SCREW		(Muffler)	
613B	793680	SCREW		(Muffler)	
660	592446	GUARD, Control			
662	793478	STUD		(Rewind Starter)	
662A	793479	STUD		(Rewind Starter)	
791	593576	CHARGER, Battery		(Instart)(United Kingdom)	
791	593562	CHARGER, Battery		(Instart)(Europe)	
832	793499	GUARD, Muffler			
832B	793681	GUARD, Muffler			
836	793500	SCREW		(Muffler Guard)	
857	793533	TRIM, Blower Housing Cover			
921	793531	HOUSING, Blower			
969	690700	SCREW		(Blower Housing)	
1511	593560	BATTERY		(InStart)(Europe/Australia /Japan)	
1512	593993	SCREEN		(Instart)	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
202	793433	LINK, Mechanical Governor			
209	793430	SPRING, Governor			
216	793494	LINK, Choke			
222	793487	BRACKET, Control			
227	793516	LEVER, Governor Control			
265	691024	CLAMP, Casing			
265A	690798	CLAMP, Casing			
267	691044	SCREW		(Casing Clamp)	
291	793498	THERMOSTAT			
333	592445	ARMATURE, Magneto			
334	793454	SCREW		(Magneto Armature)	
356	692390	WIRE, Stop			
404	690272	WASHER		(Governor Crank)	
474	794103	ALTERNATOR			
505	793515	NUT		(Governor Control Lever)	
562	793514	BOLT		(Governor Lever)	
578	398153	WIRE ASSEMBLY			
578A	794104	WIRE ASSEMBLY			
578C	594198	WIRE ASSEMBLY			
578B	796980	WIRE ASSEMBLY			
615	690340	RETAINER, Governor Shaft			
616	793448	CRANK, Governor			
621	692310	SWITCH, Stop			
635	66538S	BOOT, Spark PLug			
729	799133	CLIP, Wire			
745	793491	SCREW		(Brake)	
789	593995	HARNESS, Wiring			
789A	593996	HARNESS, Wiring			
789B	593997	HARNESS, Wiring			
789C	595412	HARNESS, Wiring			
843	691884	SLEEVE, Lever			
851	493880S	TERMINAL-SPARK PLUG			
883	793497	GASKET, Exhaust			
910	794101	STUD		(Alternator)	
922	692135	SPRING, Brake			
923	796635	BRAKE			
925	793678	COVER, Linkage			
925A	796979	COVER, Linkage			
925B	595409	COVER, Linkage			
942	793673	BRACKET, Brake			
1119	794100	SCREW		(Alternator)	
1208	699776	SCREW		(Brake Bracket)	
1513	593994	MODULE, Starter		(Instart)	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
11	793447	TUBE, Breather			
51	692555	GASKET, Intake		(2 Required)	
163	691894	GASKET, Air Cleaner		(Air Cleaner)	
187	791766	LINE, Fuel		(Cut To Required Length)	
425	793460	SCREW		(Air Cleaner Cover)	
445	792038	FILTER, A/C Cartridge			
523	793475	DIPSTICK			
524	793476	SEAL, O-Ring		(Dipstick Tube)	
525	793477	TUBE, Dipstick			
535	793676	FILTER, Air Cleaner Foam			
601	791850	CLAMP-HOSE			
670	793485	SPACER, Fuel Tank			
842	691031	SEAL, O-Ring		(Dipstick Tube)	
847	793474	DIPSTICK/TUBE ASSEMBLY			
875	793462	BASE, Air Cleaner			
875A		Base-Air Cleaner		(No Longer Available)(For Replacement, Order Reference 875)	
957	692046	CAP, Fuel Tank		(Standard Cap)	
957A	796577	CAP-FUEL TANK		(Tethered Cap)	
958	698183	VALVE-FUEL SHUT OFF			
968	793428	COVER, Air Cleaner			
968A	793432	COVER, Air Cleaner			
968B	793532	COVER, Air Cleaner			
971	591307	SCREW		(Air Cleaner Base to Carburetor/Throttle Body)	
972	793472	TANK, Fuel		(Standard Cap)	
972A	799291	TANK, Fuel		(Tethered Cap)	
1059	793471	KIT, Screw/Washer		(Fuel Tank)	