





Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
3	299819S	SEAL, Oil		(Magneto Side)	
7	697230	GASKET-CYLINDER HEAD			
9	699833	GASKET-BREATHER			
12	692232	GASKET, Crankcase			
20	399781S	SEAL, Oil		(PTO Side)	
20A	691952	SEAL, Oil		(PTO Side) (Auxiliary PTO)	
51	692668	GASKET, Intake			
51A	697735	GASKET, Intake			
51B	692555	GASKET, Intake		(2 Required)	
104	691242	PIN, Float Hinge			
121	792383	KIT, Carburetor Overhaul			
122	692799	SPACER, Carburetor			
127	694468	PLUG, Welch		(Bowl Vent)	
127A	691739	PLUG-WELCH			
134	398188	KIT-NEEDLE/SEAT			
137	693981	GASKET-FLOAT BOWL			
163	691894	GASKET, Air Cleaner		(Air Cleaner)	
163A	692667	GASKET, Air Cleaner		(Air Cleaner)	
276	271716	WASHER-SEALING			
358	792384	GASKET SET, Engine			
524	692296	SEAL-DIPSTICK TUBE		(Dipstick Tube)	
585	691879	GASKET-BREA PASSAGE			
633	693867	SEAL, Choke/Throttle Shaft			
633A	691321	SEAL-CHOKE/THR SHAFT		(Throttle Shaft)	
842	691031	SEAL, O-Ring		(Dipstick Tube)	
868	692044	SEAL, Valve			
883	691893	GASKET-EXHAUST			
977	792385	SET, Carburetor Gasket			
993	694088	GASKET-CYL HD PLATE			
1022	691890	GASKET-ROCKER COVER			
1095	792386	GASKET SET, Valve			



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
5	795501	HEAD, Cylinder		Used After Code Date 05110100	
5	695276	HEAD, Cylinder		Used Before Code Date 05110200	
7	697230	GASKET-CYLINDER HEAD			
13	691137	SCREW		(Cylinder Head)	
33	499642	VALVE, Exhaust			
34	499641	VALVE, Intake			
35	691304	SPRING, Valve		(Intake)	
36	691304	SPRING, Valve		(Exhaust)	
40	692194	RETAINER, Valve			
45	690977	TAPPET, Valve			
51	692668	GASKET, Intake			
51A	697735	GASKET, Intake			
51B	692555	GASKET, Intake		(2 Required)	
122	692799	SPACER, Carburetor			
192	694543	ADJUSTER-ROCKER ARM			
238	691300	CAP, Valve			
337	692720	PLUG, Spark		(EMS)	
337	692051	PLUG, Spark		(Resistor)	
383	19374S	WRENCH, Spark Plug			
619	691108	SCREW		(Cylinder Head Plate)	
635	66538S	BOOT, Spark PLug			
635A	692927	BOOT, Spark Plug			
718	690959	PIN, Locating			
830	694544	STUD-ROCKER ARM		(Rocker Arm)	
868	692044	SEAL, Valve			
883	691893	GASKET-EXHAUST			
886	696268	KIT, Cylinder Head/Plate Gasket			
914	691108	SCREW		(Rocker Cover)	
993	694088	GASKET-CYL HD PLATE			
1022	691890	GASKET-ROCKER COVER			
1023	499624	COVER, Rocker			
1026	692045	ROD, Push			
1029	691230	ARM, Rocker			
1034	691343	GUIDE, Push Rod			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
51	692668	GASKET, Intake			
51B	692555	GASKET, Intake		(2 Required)	
95	691636	SCREW		(Throttle Valve)	
97	499682	SHAFT, Throttle		(Metal)	
97	790121	SHAFT, Throttle		(Plastic)	
98	398185	KIT-IDLE SPEED		(Idle Speed) (Lmt 26, 27, 28, 31)	
104	691242	PIN, Float Hinge			
108	691182	VALVE-CHOKE			
109	499779	SHAFT, Choke			
109A	499681	SHAFT, Choke			
117	498978	JET, Main		(Standard) Used After Code Date 99030700 Used Before Code Date 03110700	
117	498981	JET, Main		(Standard) Used After Code Date 03110600	
117	692677	JET, Main		(Standard) Used Before Code Date 99030800	
117A	498978	JET, Main		(Standard) Used Before Code Date 02050600	
117A	694250	JET, Main		(Standard) Used After Code Date 02050500	
118	498975	JET, Main		(High Altitude) Used After Code Date 99080300 Used Before Code Date 03110700	
118	497315	JET, Main		(High Altitude) Used Before Code Date 99080800	
118	497466	JET, Main		(High Altitude) Used After Code Date 03110600	
118A	498975	JET, Main		(High Altitude) Used Before Code Date 02050600	
118A	497466	JET, Main		(High Altitude) Used After Code Date 02050500	
122	692799	SPACER, Carburetor			
122A	792382	SPACER, Carburetor			
125	790120	CARBURETOR		(Primer)	
127	694468	PLUG, Welch		(Bowl Vent)	
127A	691739	PLUG-WELCH			
130	691203	VALVE, Throttle			
130	696564	VALVE, Throttle		(Used With Plastic Throttle Shaft)	
130A	691181	VALVE-THROTTLE			
133	398187	FLOAT- CARBURETOR			
134	398188	KIT-NEEDLE/SEAT			
137	693981	GASKET-FLOAT BOWL			


Ref #	Part #	Description	Qty	Context Note	Foot Note
163A	692667	GASKET, Air Cleaner		(Air Cleaner)	
187	791766	LINE, Fuel		(Cut To Required Length)	
190	690940	SCREW		(Fuel Tank)	
217	690354	SPRING, Choke Return			
240	298090S	FILTER, Fuel			
276	271716	WASHER-SEALING			
365	691129	SCREW		(Carburetor) Used After Code Date 05110100	
365	691136	SCREW		(Carburetor) Used Before Code Date 05110200	
601	791850	CLAMP, Hose			
601A	691038	CLAMP, Hose			
633	693867	SEAL, Choke/Throttle Shaft			
633A	691321	SEAL-CHOKE/THR SHAFT		(Throttle Shaft)	
670	692294	SPACER, Fuel Tank			
692	690572	SPRING, Detent			
957	692046	CAP, Fuel Tank		(Plastic)	
957B	699985	CAP, Fuel Tank		(Plastic)	
958	698183	VALVE, Fuel Shut Off		(Plastic)	
972	699374	TANK, Fuel		(Plastic)	
975	493640	BOWL, Float			
1059	696293	KIT, Screw/Washer		(Touch N Mow)	
1059	692311	KIT, Screw/Washer			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
51	692668	GASKET, Intake			
51A	697735	GASKET, Intake			
51B	692555	GASKET, Intake		(2 Required)	
122	692799	SPACER, Carburetor			
188	693168	SCREW		(Control Bracket)	
202	691303	LINK, Mechanical Governor			
209A	691851	SPRING, Governed Idle			
211	692434	SPRING-GOVERNED IDLE			
222C	692617	BRACKET-CONTROL		Used Before Code Date 05110200	
222C	792398	BRACKET, Control		Used After Code Date 05110100	
227	691467	LEVER, Governor Control			
236	691826	LINK, Lockout			
265	690798	CLAMP, Casing			
265A	691024	CLAMP, Casing			
267	691044	SCREW		(Casing Clamp)	
268	691025	CASING, Control Wire		(Cut To Required Length)	
269	691026	WIRE, Control		(Cut To Required Length)	
270	691027	NUT		(Control Wire Casing)	
271	691028	LEVER, Control			
333	802574	ARMATURE, Magneto			
334	691061	SCREW		(Magneto Armature)	
341	690368	STUD		(Mounting Bracket)	
347	691396	SWITCH, Rocker			
356	692390	WIRE, Stop			
356A	499690	WIRE-STOP			
356B	692151	WIRE, Stop			
356C	693010	WIRE, Stop			
356D	695283	WIRE ASSEMBLY			
404	690272	WASHER		(Governor Crank)	
472	693809	KNOB, Choke Shaft			
474	691991	ALTERNATOR			
493	692877	BRACKET, Mounting			
505	691251	NUT		(Governor Control Lever)	
532	692851	NUT		(Mounting Bracket)	
562	691119	BOLT		(Governor Control Lever)	
564A	693808	SCREW		(Control Cover)	
578	398153	WIRE ASSEMBLY			
604A	693807	COVER, Control			
615	690340	RETAINER, Governor Shaft			
616	698801	CRANK-GOVERNOR			
621	692310	SWITCH, Stop			
745	691648	SCREW		(Brake)	
789	696547	HARNESS, Wiring		Used After Code Date 00040600	
789	691372	HARNESS, Wiring		Used Before Code Date 00040700	

Ref #	Part #	Description	Qty	Context Note	Foot Note
789A	696546	HARNESS, Wiring		Used After Code Date 00040600	
789A	690790	HARNESS, Wiring		Used Before Code Date 00040700	
843	691884	SLEEVE, Lever			
851	493880S	TERMINAL-SPARK PLUG			
910	691094	STUD		(Alternator)	
922	691831	SPRING-BRAKE			
922A	692135	SPRING, Brake			
923	796387	BRAKE		Used After Code Date 08043000	
923A	695891	BRAKE			
935	499421	SWITCH, Interlock		Used Before Code Date 08050100	
990	695951	SET, Key		(Touch N Mow)	
1119	692979	SCREW		(Alternator)	
1160	690345	SCREW		(Interlock Switch)	




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
1	499678	CYLINDER ASSEMBLY		Used Before Code Date 04040500	
1	790363	CYLINDER ASSEMBLY		Used After Code Date 04040400	
2	399269	KIT, Bushing/Seal		(Magneto Side)	
3	299819S	SEAL, Oil		(Magneto Side)	
4	493279	SUMP, Engine			
4A	493365	SUMP, Engine		(Auxiliary PTO)	
8	495786	BREATHER ASSEMBLY			
9	699833	GASKET-BREATHER			
10	691125	SCREW		(Breather Assembly)	
11A	499675	TUBE, Breather			
12	692232	GASKET, Crankcase			
15	691680	PLUG, Oil Drain		(Square Socket)	
15A	691093	PLUG, Oil Drain		(Hex Socket)	
16	691457	CRANKSHAFT			
17	692517	BEARING, Ball			
20	399781S	SEAL, Oil		(PTO Side)	
20A	691952	SEAL, Oil		(PTO Side) (Auxiliary PTO)	
22	691092	SCREW		(Crankcase Cover/Sump)	
24	222698S	KEY, Flywheel			
25	791325	PISTON ASSEMBLY		(.020 Oversize) Used Before Code Date 07090400	
25	792004	PISTON ASSEMBLY		(Standard) Used Before Code Date 07090400	
25	795429	PISTON ASSEMBLY		(Standard) Used After Code Date 07090300	
25	795430	PISTON ASSEMBLY		(.020 Oversize) Used After Code Date 07090300	
26	795432	SET, Ring		(.020 Oversize) Used After Code Date 07090300	
26	795431	RING SET		(Standard) Used After Code Date 07090300	
26	692786	SET, Ring		(.020 Oversize) Used Before Code Date 05030800	
26	791324	SET, Ring		(.020 Oversize) Used After Code Date 05030700 Used Before Code Date 07090400	
26	791969	SET, Ring		(Standard) Used After Code Date 05030700 Used Before Code Date 07090400	
26	499631	SET, Ring		(Standard) Used Before Code Date 05030800	
27	691866	LOCK-PISTON PIN			

Ref #	Part #	Description	Qty	Context Note	Foot Note
28	499423	PIN-PISTON/STD		(Standard)	
29	499424	ROD, Connecting		(Standard)	
32	691664	SCREW		(Connecting Rod)	
32A	695759	SCREW		(Connecting Rod) Used After Code Date 00042200	
43	691997	SLINGER, Governor/Oil			
46	694039	CAMSHAFT		Used After Code Date 99030700	
46	694035	CAMSHAFT		Used Before Code Date 99030800	
46A	694034	CAMSHAFT		(Clockwise) Used Before Code Date 99030800	
46A	694033	CAMSHAFT		(Counterclockwise) Used Before Code Date 99030800	
46A	694038	CAMSHAFT		(Clockwise) Used After Code Date 99030700	
46A	694037	CAMSHAFT		(Counterclockwise) Used After Code Date 99030700	
83	691778	SHAFT, Auxiliary Drive			
101	691623	PIN, Shaft			
146	690979	KEY, Woodruff			
287	690940	SCREW		(Dipstick Tube)	
306	691232	SHIELD-CYLINDER			
307	690345	SCREW		(Cylinder Shield)	
357	692191	KEY, Drive Pulley			
374	691074	WASHER		(Camshaft)	
523	499621	DIPSTICK			
524	692296	SEAL-DIPSTICK TUBE		(Dipstick Tube)	
525	495265	TUBE, Dipstick			
529	692937	TUBE, Breather			
584	697734	COVER-BREA PASSAGE			
585	691879	GASKET-BREA PASSAGE			
684	690345	SCREW		(Breather Passage Cover)	
715	691147	SCREW		(Stop Shaft)	
718	690959	PIN, Locating			
721	690449	STOP, Shaft			
737	692511	SCREW		(Oil Filter Adapter)	
741	794388	GEAR, Timing		(Use Without Woodruff Key) Used After Code Date 07093000	
741	691830	GEAR-TIMING		(Uses Woodruff Key)	
741	790345	GEAR, Timing		(Use Without Woodruff Key) Used Before Code Date 07100100	


Ref #	Part #	Description	Qty	Context Note	Foot Note
743	690516	GEAR, Drive		(Clockwise)	
750	691683	SCREW		(Oil Pump Cover)	
842	691031	SEAL, O-Ring		(Dipstick Tube)	
847	692047	DIPSTICK/TUBE ASSY			
943	692514	SEAL, O-Ring		(Oil Pump Cover)	
965	692507	COVER, Oil Pump			
988	692515	GASKET, Oil Adapter			
1019	499691	KIT, Label			
1019	790231	KIT, Label		(Touch N Mow)	
1024	692508	PUMP, Oil			
1027	692513	FILTER-OIL			
1028	692516	ADAPTER, Oil Filter			
1055	692623	TUBE, Oil Pump			
1058	277102	MANUAL, Operator's			
1058	276347	MANUAL, Operator's		(Touch N Mow)	
1319	794467	LABEL, Warning			
1330	272147	MANUAL, Repair			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
23	697610	FLYWHEEL			
37	694086	GUARD, Flywheel			
55	691421	HOUSING, Rewind Starter			
58	697316	ROPE, Starter		(Cut To Required Length)	
59	396892	INSERT-GRIP			
60	281434S	GRIP, Starter Rope			
60A	393152	GRIP-STARTER ROPE			
65	690837	SCREW		(Rewind Starter)	
73	691221	SCREEN, Rotating			
78	691108	SCREW		(Flywheel Guard)	
304	499677	HOUSING, Blower			
305	691108	SCREW		(Blower Housing)	
309	695550	MOTOR, Starter		Used Before Code Date 07052900	
309A	795092	MOTOR, Starter		Used After Code Date 07052800	
310	692327	SCREW		(Starter Motor)	
332	690662	NUT		(Flywheel)	
363	19069	PULLER, Flywheel			
455	791960	CUP, Flywheel			
456	692299	PLATE-PAWL FRICTION			
459	281505S	PAWL-RATCHET			
510	795093	DRIVE, Starter			
513	692358	CLUTCH, Drive			
544	690786	ARMATURE, Starter			
545	492919	WASHER		(Starter Motor)	
592	690800	NUT		(Rewind Starter)	
597	691696	SCREW		(Pawl Friction Plate)	
608	497680	STARTER, Rewind			
651	691660	SCREW		(Starter Gear Cover)	
689	691855	SPRING-FRICTION			
697	691127	SCREW		(Drive Cap)	
727	692934	COVER, Starter Drive			
742	93941	RETAINER, E Ring			
783	691918	GEAR, Pinion		(19 Teeth)(Starter Drive)	
783A	691269	GEAR, Pinion		(12 Teeth)	
784	795095	COVER, Starter Gear			
785	692352	GASKET-STARTER COVER			
801	690782	CAP, Drive			
802	695267	CAP, End		Used After Code Date 00040600	
802	695975	HOUSING, Starter		Used Before Code Date 00040700	
803	695266	HOUSING, Starter		Used After Code Date 00040600	
803	695975	HOUSING, Starter		Used Before Code Date 00040700	

Ref #	Part #	Description	Qty	Context Note	Foot Note
853	695268	ADAPTER, Wire			
921A	699633	COVER-BLOWER HSG			
925	690595	COVER, Linkage		Used Before Code Date 07072300	
925	795403	COVER-LINKAGE		Used After Code Date 07072200	
930	691919	GUARD, Rewind			
930A	692675	GUARD, Rewind			
937	691325	SPLINE, Starter			
946	396526	GUIDE, Rope			
969	691138	SCREW		(Blower Housing)	
1005	691346	FAN, Flywheel			
1009	696255	SCREW		(Starter Motor)	
1036		Label-Emissions		(Available From A Briggs & Stratton Authorized Dealer)	
1210	498144	PULLEY/SPRING ASSY		(Pulley)	
1211	498144	PULLEY/SPRING ASSY		(Spring)	
1236	695959	STARTER, Mechanical			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
163	691894	GASKET, Air Cleaner		(Air Cleaner)	
259	691189	BRACKET, Casing Clamp			
300	692275	MUFFLER		(Super Quiet Lo Tone)	
300A	692276	MUFFLER		(Quiet Lo Tone)	
300C	694248	MUFFLER		(Super Quiet Power Lo Tone)	
300B	699769	MUFFLER		(Square Lo Tone)	
346	690661	SCREW		(Spark Arrestor)	
425A	690244	SCREW		(Air Cleaner Cover)	
443B	690255	SCREW		(Air Cleaner Primer Base)	
445A	697029	FILTER-A/C CARTRIDGE			
529	692937	TUBE, Breather			
613	691108	SCREW		(Muffler)	
613A	691140	SCREW		(Muffler)	
676	397931	DEFLECTOR, Muffler		(Direct Out)(3/4 Diameter)	
676A	393756	DEFLECTOR, Muffler		(Side Outlet)	
676B	396548	DEFLECTOR, Muffler		(Single Louver)	
676C	497682	DEFLECTOR, Muffler		(Direct Out)(1 3/16 Diameter)	
676D	697915	DEFLECTOR, Muffler		(Square Lo Tone)	
677	690661	SCREW		(Muffler Deflector)	
832	691466	GUARD-MUFFLER		(Super Lo Tone)	
832A	692984	GUARD, Muffler		(Quiet Lo Tone)	
832C	695593	GUARD, Muffler		(Square Lo Tone)	
836	691147	SCREW		(Muffler Guard)	
836A	697551	SCREW		(Muffler Guard)	
836B	692198	SCREW		(Muffler Guard)	
883	691893	GASKET-EXHAUST			
966B	690243	BASE-A/C PRIMER		(Primer)	
967A	273356S	FILTER-A/C FOAM			
968A	691342	COVER, Air Cleaner			
968B	692435	COVER-AIR CLEANER			
976	694395	PRIMER, Carburetor			
994	692957	ARRESTOR-SPARK			
994A	398067	ARRESTOR-SPARK			