







Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
3	299819S	SEAL-OIL		(Magnet Side)	
4	493279	SUMP, Engine			
7	796475	GASKET, Cylinder Head			
12	692232	GASKET, Crankcase			
15	691680	PLUG-OIL DRAIN		(Square Socket)	
17	798538	BEARING-BALL			
20	399781S	SEAL-OIL		(PTO Side)	
22	691092	SCREW		(Crankcase Cover/Sump)	
51	796596	GASKET, Intake			
163	691894	GASKET, Air Cleaner		(Air Cleaner)	
358	592173	GASKET SET, Engine			
523	796503	DIPSTICK			
524	692296	SEAL-DIPSTICK TUBE		(Dipstick Tube)	
525	796502	TUBE, Dipstick			
623	793628	SEAL, O-Ring		(Carburetor Spacer)	
718	690959	PIN, Locating			
737	692511	SCREW		(Oil Filter Adapter)	
750	691147	SCREW		(Oil Pump Cover)	
842	691031	SEAL, O-Ring		(Dipstick Tube)	
847	796501	DIPSTICK/TUBE ASSEMBLY			
868	795440	SEAL-VALVE			
883	793497	GASKET, Exhaust			
943	692514	SEAL, O-Ring		(Oil Pump Cover)	
965	692507	COVER, Oil Pump			
988	692515	GASKET, Oil Adapter			
993	796473	GASKET, Cylinder Head Plate			
1022	796480	GASKET, Rocker Cover			
1024	692508	PUMP, Oil			
1027	795990	FILTER, Oil			
1028	796522	ADAPTER, Oil Filter			
1055	796524	TUBE, Oil Pump			




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
333A	595554	ARMATURE, Magneto		(180 Degree Ignition Terminal)	
334	793454	SCREW		(Magneto Armature)	
337	692720	PLUG, Spark		(EMS)	
337	692051	PLUG, Spark		(Resistor)	
347A	592694	SWITCH, Rocker			
356	692390	WIRE, Stop			
362	799646	SHIELD, Spark Plug			
365	793458	SCREW		(Carburetor)	
383	19576S	WRENCH, Spark Plug			
621	692310	SWITCH, Stop			
635	66538S	BOOT, Spark PLug			
697	691127	SCREW		(Starter Motor) (Drive Cap)	
742	93941	RETAINER, E Ring			
851	493880S	TERMINAL-SPARK PLUG			
851A	692424	TERMINAL, Spark Plug			
853A	695897	ADAPTER, Wire			
910	796498	STUD		(Alternator)	
1119	794100	SCREW		(Alternator)	
1212	796537	STUD		(Blower Housing)	
1212B	797002	STUD		(Blower Housing) (Used With Alternator Only)	




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
187	791766	LINE, Fuel		(Cut To Required Length)	
240	298090S	FILTER, Fuel			
523	796503	DIPSTICK			
524	692296	SEAL-DIPSTICK TUBE		(Dipstick Tube)	
525	796502	TUBE, Dipstick			
601	791850	CLAMP-HOSE			
670	793485	SPACER, Fuel Tank			
842	691031	SEAL, O-Ring		(Dipstick Tube)	
847	796501	DIPSTICK/TUBE ASSEMBLY			
957	799585	CAP, Fuel Tank			
957A	692046	CAP, Fuel Tank			
957C	796577	CAP-FUEL TANK			
972	590949	TANK, Fuel			
1059	793471	KIT, Screw/Washer			




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
81	691740	LOCK, Muffler Screw			
300A	798940	MUFFLER			
613	796496	SCREW		(Muffler)	
676A	799187	DEFLECTOR, Muffler			
832A	593411	GUARD, Muffler			
836	793500	SCREW		(Muffler Guard)	
883	793497	GASKET, Exhaust			
994	690813	ARRESTOR, Spark			




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
5	796471	HEAD, Cylinder			
7	796475	GASKET, Cylinder Head			
13	799277	SCREW		(Cylinder Head)	
33	499642	VALVE, Exhaust			
34	795443	VALVE, Intake			
35	691304	SPRING, Valve		(Intake)	
36	691304	SPRING, Valve		(Exhaust)	
40	692194	RETAINER, Valve			
45	690977	TAPPET, Valve			
51	796596	GASKET, Intake			
163	691894	GASKET, Air Cleaner		(Air Cleaner)	
192	796631	ADJUSTER, Rocker Arm			
238	691300	CAP, Valve			
337	692720	PLUG, Spark		(EMS)	
337	692051	PLUG, Spark		(Resistor)	
383	19576S	WRENCH, Spark Plug			
623	793628	SEAL, O-Ring		(Carburetor Spacer)	
635	66538S	BOOT, Spark PLug			
718	690959	PIN, Locating			
830	796472	STUD, Rocker Arm		(Rocker Arm)	
868	795440	SEAL-VALVE			
883	793497	GASKET, Exhaust			
886	799492	KIT, Cylinder Head/Plate Gasket			
914	794451	SCREW		(Rocker Cover)	
993	796473	GASKET, Cylinder Head Plate			
1022	796480	GASKET, Rocker Cover			
1023	796479	COVER, Rocker			
1026	796481	ROD, Push			
1029	691230	ARM, Rocker			
1034	691343	GUIDE-PUSH ROD			
1095	592174	GASKET SET, Valve			








Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
202	796657	LINK, Mechanical Governor			
209	796483	SPRING, Governor			
211	799508	SPRING, Governed Idle			
216A	798944	LINK, Choke			
222	796482	BRACKET, Control		(Manual Friction, Remote, & Fixed Speed Control)	
222A	799448	BRACKET, Control			
227	796487	LEVER, Governor Control			
265	690798	CLAMP, Casing			
267	691044	SCREW		(Casing Clamp)	
268	691025	CASING, Control Wire		(Cut To Required Length)	
269	691026	WIRE, Control		(Cut To Required Length)	
270	691027	NUT		(Control Wire Casing)	
271	691028	LEVER, Control			
291A	798938	THERMOSTAT			
419	799623	SPRING, Governor		(Return)	
505	793515	NUT		(Governor Control Lever)	
562	793514	BOLT		(Governor Lever)	
621	692310	SWITCH, Stop			
745	793491	SCREW		(Brake)	
843	691884	SLEEVE, Lever			
883	793497	GASKET, Exhaust			
922	692135	SPRING, Brake			
923	796635	BRAKE			




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
51	796596	GASKET, Intake			
51A	590398	GASKET, Intake			
104	797622	PIN-FLOAT HINGE			
117	799227	JET, Main		(Standard)	
118	799606	JET, Main		(High Altitude)	
121	592172	KIT, Carburetor Overhaul			
122	796595	SPACER, Carburetor			
125	799226	CARBURETOR			
133	797626	FLOAT, Carburetor			
134	799177	KIT, Needle/Seat			
137	797625	GASKET, Float Bowl			
163	691894	GASKET, Air Cleaner		(Air Cleaner)	
202	796657	LINK, Mechanical Governor			
216A	798944	LINK, Choke			
217	799179	SPRING, Choke Return			
276	797632	WASHER, Sealing			
365	793458	SCREW		(Carburetor)	
623	793628	SEAL, O-Ring		(Carburetor Spacer)	
975	797631	BOWL, Float			




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
1	798947	CYLINDER ASSEMBLY			
3	299819S	SEAL-OIL		(Magnet Side)	
16	797909	CRANKSHAFT			
24	222698S	KEY, Flywheel			
25	590404	PISTON ASSEMBLY		(Standard)	
25	590405	PISTON ASSEMBLY		(.020 Oversize)	
26	590403	SET, Ring		(.020 Oversize) Used After Code Date 11063000	
26	797304	SET, Ring		(Standard) Used Before Code Date 11070100	
26	797305	SET, Ring		(.020 Oversize) Used Before Code Date 11070100	
26	590402	SET, Ring		(Standard) Used After Code Date 11063000	
27	691588	LOCK, Piston Pin			
28	298909	PIN-PISTON/STD			
29	796470	ROD, Connecting			
32	691664	SCREW		(Connecting Rod)	
32A	695759	SCREW		(Connecting Rod)	
43	796650	SLINGER, Governor/Oil			
46	694039	CAMSHAFT			
404	690272	WASHER		(Governor Crank)	
598	592587	SHIM, End Play		(Crankshaft or Camshaft Bearing)	
615	690340	RETAINER, Governor Shaft			
616	798327	CRANK, Governor			
718	690959	PIN, Locating			
741	797521	GEAR, Timing			
1036		Label-Emissions		(Available From A Briggs & Stratton Authorized Dealer)	
1263	697124	REED, Breather			
1264	793453	SCREW		(Breather Reed)	
1319	794467	LABEL, Warning			
1319A	797669	LABEL, Warning			
1330	279000	MANUAL, Repair			
1375	796476	COVER, Breather Reed			
1376	794451	SCREW		(Breather Reed Cover)	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
23	590420	FLYWHEEL		(Aluminum)	
37	590921	GUARD, Flywheel			
37B	799155	GUARD, Flywheel			
58	697316	ROPE, Starter		(Cut To Required Length)	
60	281434S	GRIP, Starter Rope			
60A	799716	GRIP, Starter Rope			
75	691736	WASHER		(Flywheel)	
78	793480	SCREW		(Flywheel Guard)	
304	796692	HOUSING, Blower		(Rewind Start)	
332	690662	NUT		(Flywheel)	
363	19069	PULLER, Flywheel			
455	796615	CUP, Flywheel			
608	796497	STARTER, Rewind			
668	797373	SPACER			
668A	797383	SPACER			
925	796531	COVER, Linkage			
1005	796614	FAN, Flywheel			
1212	796537	STUD		(Blower Housing)	
1212A	793479	STUD		(Blower Housing)	
1212B	797002	STUD		(Blower Housing) (Used With Alternator Only)	
1335	793481	NUT		(Blower Housing)	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
11	796478	TUBE, Breather			
163	691894	GASKET, Air Cleaner		(Air Cleaner)	
265	690798	CLAMP, Casing			
267	691044	SCREW		(Casing Clamp)	
347A	592694	SWITCH, Rocker			
445	795066	FILTER, A/C Cartridge			
535	797301	FILTER, Air Cleaner Foam			
536	799025	CLEANER, Air			
564	690351	SCREW		(Control Cover)	
564A	799026	SCREW		(Control Cover)	
604	799024	COVER, Control			
875	796492	BASE, Air Cleaner			
967	796254	FILTER, Pre Cleaner			
968	796493	COVER, Air Cleaner			
971	690349	SCREW		(Air Cleaner Base to Carburetor/Throttle Body)	
971A	798294	SCREW		(Air Cleaner Base to Carburetor/Throttle Body)	