


135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
161	691735	Base-Air Cleaner	467	691668	Knob-Air Cleaner	967	491435	Filter-Pre Cleaner (Rectangular)
163	2719356	Air Cleaner Gasket (Standard, Oval)	536	494279	Cleaner-Air (Rectangular)	967A	271466	Filter-Pre Cleaner (Round)
163A	2711396	Air Cleaner Gasket (1 5/8" O.D. Round)	649	231332	Stud (Air Cleaner Cover, 1/4" Diameter)	968	692321	Cover-Air Cleaner (Rectangular)
163B	690580	Air Cleaner Gasket (1 15/16" O.D. Round)	----- Note -----			968A	493822	Cover-Air Cleaner (Canister)
425	694515	Screw (Air Cleaner Cover)	691248 Stud (Air Cleaner Cover, 1/2" Diameter) Used on Type No(s). 0185, 0263, 1263.			971	690370	Screw (Air Cleaner Base)
445	396424	Filter-Air Cleaner Cartridge (Canister)	855	690599	Adapter-Air Cleaner			
445A	491588	Filter-Air Cleaner Cartridge (Rectangular)						

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2610-18


Assemblies include all parts shown in frames.
18

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
161	691735	BASE, Air Cleaner			
163	271935S	GASKET, Air Cleaner		(Standard)(Oval)	
163A	271139S	GASKET, Air Cleaner		(1 5/8 Outside Diameter)	
163B	690580	GASKET, Air Cleaner		(1 15/16 Outside Diameter)	
425	694515	SCREW		(Air Cleaner Cover)	
445	396424S	FILTER, A/C Cartridge		(Canister)	
445A	491588S	FILTER, A/C Cartridge		(Rectangular)	
467	691668	KNOB, Air Cleaner Cover			
536	494279	CLEANER-AIR		(Rectangular)	
649	231332	STUD		(Air Cleaner Cover)	
855	690599	ADAPTER, Air Cleaner			
967	491435S	FILTER, Pre Cleaner		(Rectangular)	
967A	271466	FILTER, Pre Cleaner		(Round)	
968	794784	COVER, Air Cleaner			
968A	493822	COVER, Air Cleaner			
971	690370	SCREW		(Air Cleaner Base to Carburetor/Throttle Body)	

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
24	691732	Key-Flywheel	356E	692390	Wire-Stop	668	690531	Spacer
333	397358	Armature-Magneto	359	691077	Washer (Ground Terminal)	729	690588	Clip-Wire (Snap in, Nylon)
334	690306	Screw (Magneto Armature)	373	691612	Nut (Ground Terminal)	851	493880s	Terminal-Spark Plug
334A	691621	Screw (Magneto Armature)	474	494254	Alternator (Magneto Armature)	892	690646	Switch-Key
347	691995	Switch-Rocker	507	691972	Insulator	920	691656	Solenoid-Starter
356	398808	Wire-Stop	520	691084	Terminal-Ground	990	691959	Key Set
356A	690650	Wire-Stop	578	692306	Wire Assembly	1054	280275	Tie-Cable
356B	690817	Wire-Stop	627	690474	Bracket-Stopswitch	1119	691183	Screw (Alternator)
356D	690818	Wire-Stop						

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-15

Assemblies include all parts shown in frames.


04/12/2012

15

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
24	222698S	KEY, Flywheel			
333	397358	ARMATURE-MAGNETO			
334	690306	SCREW		(Magneto Armature)	
334A	691621	SCREW		(Magneto Armature)	
347	691995	SWITCH-ROCKER			
356	398808	WIRE, Stop		(Cut To Required Length)	
356A	690650	WIRE, Stop			
356B	690817	WIRE-STOP			
356E	692390	WIRE, Stop			
359	691077	WASHER		(Ground Terminal)	
373	691612	NUT		(Ground Terminal)	
474	494254	ALTERNATOR			
507	691972	INSULATOR			
520	691084	TERMINAL, Ground			
578	692306	WIRE ASSEMBLY			
627	690474	BRACKET-STOPSWITCH			
668	690531	SPACER			
729	690588	CLIP, Wire		(Snap In)(Nylon)	
851	493880S	TERMINAL-SPARK PLUG			
892	690646	SWITCH, Key			
920	691656	SOLENOID, Starter			
990	691959	SET, Key			
1054	280275	TIE, Cable			
1119	691183	SCREW		(Alternator)	

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
12	692213	Gasket-Crankcase (Standard)			0284, 0285, 0289, 0293, 0295, 0304, 0306, 0309, 0310, 0315, 0316, 0320, 0324, 0603, 0611, 0615, 0616, 0620, 0625, 0670, 0671, 0704, 0706, 0727, 0728, 0757, 0758, 0759, 0780, 0784, 1003, 1004, 1005, 1011, 1016, 1020, 1025, 1070, 1071, 1105, 1119, 1127, 1128, 1142, 1153, 1154, 1157, 1158, 1159, 1169, 1171, 1180, 1194, 1231, 1232, 1236, 1245, 1258, 1259, 1260, 1261, 1263, 1271, 1276, 1281, 1284, 1289, 1299, 1304, 1310, 1315, 1320, 1324, 1329, 1336, 1337, 1338			0209, 0214, 0216, 0232, 0236, 0254, 0260, 0265, 0269, 0295, 0309, 0310, 0320, 0324, 0611, 0670, 0671, 0728, 0757, 0758, 0780, 1011, 1070, 1071, 1128, 1154, 1157, 1158, 1169, 1173, 1180, 1194, 1232, 1260, 1261, 1265, 1309, 1310, 1320, 1324, 1336, 1337, 1338, 1343
18		Cover-Crankcase (See Previous Page)			091952 Seal-Oil (PTO Side)			692019 Seal-Oil (PTO Side)
19	495660	Kit-Bushing/Seal (PTO Side)			Used on Type No(s): 0001, 0003, 0004, 0005, 0015, 0016, 0020, 0025, 0105, 0114, 0117, 0118, 0119, 0127, 0132, 0136, 0142, 0145, 0150, 0153, 0156, 0157, 0158, 0159, 0171, 0175, 0178, 0182, 0183, 0185, 0193, 0194, 0195, 0209, 0210, 0214, 0222, 0237, 0238, 0245, 0253, 0254, 0258, 0260, 0262, 0263, 0265, 0269, 0271, 0274, 0276, 0281,			Used on Type No(s): 0026, 0115, 0129, 0151, 0160, 0162, 0163, 0164, 0166, 0199, 0211, 0244, 0252, 0292, 0327, 0626, 0752, 1026, 1115, 1129, 1160, 1252, 1292, 1327
20	495307	Seal-Oil (PTO Side)			Used on Type No(s): 0011, 0070, 0071, 0108, 0120, 0121, 0124, 0141, 0154, 0157, 0158, 0169, 0173, 0174, 0180, 0182, 0194, 0198, 0202, 0203, 0204, 0205, 0206, 0207,	21	281658	Cap-Oil Fill
						22	691551	Screw (Crankcase Cover)
						170	691120	Stud (Crankcase Cover, Install in #1 and/or #2 Positions)
						415	691363	Plug (Crankcase Cover)
						1194	691876	Seal-O Ring (Plug)

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-8


Assemblies include all parts shown in frames.
8

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
12	692213	GASKET, Crankcase		(Standard)	
12	270125	GASKET, CRANKCASE		(.005)	
12	270126	GASKET- CRKCSE/009		(.009)	
18	694350	COVER, Crankcase		(Plain Bearing)	
18	694377	COVER, Crankcase		(Gear Reduction)	
18		Cover-Crankcase		(NO LONGER AVAILABLE)	
18	694319	COVER, Crankcase			
20	294606S	SEAL, Oil		(PTO Side) (PTO Side)(1-3/8 Outside Diameter With Spring)	
20	691952	SEAL, Oil		(PTO Side) (Auxiliary PTO)(1 Outside Diameter With Spring)	
21	281658S	CAP, Oil Fill			
22	692551	SCREW		(Crankcase Cover/Sump)	
170	691120	STUD		(Crankcase Cover/Sump) (Install In Positions 1 And/Or 2)	
309	690658	MOTOR, Starter			
415	691363	PLUG		(Crankcase Cover/Sump)	
1194	691876	SEAL, O-Ring		(Plug)	

135200 to 135299



1058 OWNER'S MANUAL

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1		Cylinder Assembly (See previous page)	13	691640	Screw (Cylinder Head)	869	691705	Seat-Valve (Intake)
2	399269	Kit-Bushing/Seal (Magneto Side) (Used After Code Date 94012300).	13A	691659	Screw (Cylinder Head)	870	691701	Seat-Valve (Exhaust)
		----- Note ----- 297565 Kit-Bushing/ Seal (Magneto Side) (Used Before Code Date 94012400).	14	691690	Stud (Cylinder Head)	871	262001	Bushing-Valve Guide (Exhaust)
3	299819s	Seal-Oil (Magneto Side)	15	691686	Plug-Oil Drain (Standard)			----- Note ----- 63709 Bushing- Valve Guide (Intake)
5	691716	Head-Cylinder	306	694514	Shield-Cylinder	989	221828	Stopswitch-Spark Plug Used on Type No(s). 1011, 1012.
7	272157s	Gasket-Cylinder Head	307	691660	Screw (Cylinder Shield)	1058	274266	Owner's Manual (Emission)
8	699448	Breather Assembly	308	690473	Cover-Cylinder Head (Full)			----- Note ----- 276646 Owner's Manual (Non Emission)
9	27549	Gasket-Breather	337	802592s	Plug-Spark			
10	691666	Screw (Breather Assembly)	383	69038	Wrench-Spark Plug			
11	231550	Tube-Breather	527	691741	Clamp-Tube			
		----- Note ----- 230722 Tube-Breather Used on Type No(s). 0299. 690517 Tube-Breather Used on Type No(s). 1011, 1012.	529	692189	Grommet (90 Degree)			
			529A	692187	Grommet (120 Degree)			
			552	690508	Bushing- Governor Crank			
			635	66538	Boot-Spark Plug			
			718	690959	Pin-Locating			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095


2810-3

Assemblies include all parts shown in frames.

04/12/2012

Ref #	Part #	Description	Qty	Context Note	Foot Note
1	497144	CYLINDER ASSEMBLY			
2	796961	KIT, Bushing/Seal		(Magneto Side) Used After Code Date 94012300	
2	297565	KIT, Bushing/Seal		(Magneto Side) Used Before Code Date 94012400	
3	299819S	SEAL, Oil		(Magneto Side)	
5	691716	HEAD, Cylinder			
7	272157S	GASKET-CYLINDER HEAD			
8	791779	BREATHER ASSEMBLY			
9	27549S	GASKET, Breather			
10	691666	SCREW		(Breather Assembly)	
11	231550	TUBE, Breather			
13	691640	SCREW		(Cylinder Head)	
13A	691659	SCREW		(Cylinder Head)	
14	691690	STUD		(Cylinder Head)	
15	691686	PLUG-OIL DRAIN		(Standard)	
306	694514	SHIELD-CYLINDER			
307	691660	SCREW		(Cylinder Shield)	
308	690473	COVER, Cylinder Head			
337	796112S	PLUG, Spark			
383	89838S	WRENCH, Spark Plug			
527	691741	CLAMP, Hose			
529	692189	GROMMET		(90 Degree)	
529A	692187	GROMMET		(120 degree)	
552	690508	BUSHING, Governor Crank			
635	66538S	BOOT, Spark PLug			
718	690959	PIN, Locating			
1058	272646	MANUAL, Operator's		(Non Emission)	
1058	274266	MANUAL, Operator's		(Emission)	

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51A	273113	Gasket-Intake	191	692241	Gasket-Fuel Tank	633	691869	Seal-Choke/Throttle
90		Carburetor (See Previous Page)	203	691906	Crank-Bell (Standard, Nylon)			Shaft (Choke Shaft)
95	691437	Screw (Throttle Valve)	205	691776	Screw (Bell Crank)	689	691783	Spring-Friction (Idle Screw)
97	692325	Shaft-Throttle	212	691812	Link-Throttle	692	690572	Spring-Detent (Used On Part
110A	690401	Washer (Choke Shaft)	365	690953	Screw (Carburetor)			498298 Carburetor)
		(Brass)	392	691823	Spring-Pump Diaphragm	718A	690296	Pin-Locating (Pump Cover)
127	691718	Plug-Weich	393	691213	Screen-Carburetor	987	695273	Seal-Throttle Shaft (Foam)
127A	691742	Plug-Weich	394	272538	Diaphragm-Carburetor	1149	691624	Screw (Throttle Shaft)
130	691743	Valve-Throttle	432	690766	Cap-Spring			(Idle Speed Adjusting Only)
141	497230	Kit-Choke Shaft (Used After Code Date 94083100).	434	691713	Cover-Diaphragm			
		----- Note -----	435	691619	Screw (Diaphragm Cover)			
		491177 Kit-Choke Shaft (Used Before Code Date 94090100).	611	691770	Pipe-Fuel			
149	691592	Spring-Needle Valve	612	391813	Tube-Pick Up (Uses Clip Spring)			
173	691777	Valve-Idle Modure (Idle)			----- Note -----			
					297219 Tube-Pick Up (Uses Spiral Pin) Used on Type No(s). 0214.			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-11

Assemblies include all parts shown in frames.

04/12/2012

Ref #	Part #	Description	Qty	Context Note	Foot Note
90	498298	CARBURETOR			
95	691437	SCREW		(Throttle Valve)	
97	692325	SHAFT-THROTTLE			
110A	690401	WASHER		(Choke Shaft) (Brass)	
127	691718	PLUG, Welch			
127A	691742	PLUG, Welch			
130	691743	VALVE, Throttle			
141	497230	KIT, Choke Shaft		Used After Code Date 94083100	
149	691592	SPRING-NEEDLE VALVE			
173	691777	VALVE, Idle Mixture			
191	692241	GASKET, Fuel Tank			
203	691906	CRANK, Bell		(Standard)(Nylon)	
205	691776	SCREW		(Bell Crank)	
212	691812	LINK, Throttle			
365	690953	SCREW		(Carburetor/Throttle Body)	
392	691823	SPRING, Pump Diaphragm			
393	691213	SCREEN, Carburetor			
394	272538S	DIAPHRAGM, Carburetor			
432	690766	CAP-SPRING			
434	691713	COVER-DIAPHRAGM			
435	691619	SCREW		(Diaphragm Cover)	
611	691770	PIPE-FUEL			
612	391813	TUBE-PICK UP		(Uses Spring Clip)	
633	691869	SEAL, Choke/Throttle Shaft			
689	691783	SPRING-FRICTION		(Idle Speed Adjusting Only)	
692	690572	SPRING, Detent		(Used On Part 498298 Carburetor)	
718A	690296	PIN-LOCATING		(Pump Cover)	
987	695273	SEAL, Choke/Throttle Shaft		(Foam)	
1149	691624	SCREW		(Throttle Shaft) (Idle Speed Adjusting Only)	

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-14


Assemblies include all parts shown in frames.
14

04/12/2012

Ref #	Part #	Description	Qty	Context Note	Foot Note
153	490589	SCREW		(Carburetor)	
202	691814	LINK, Mechanical Governor			
203A	691965	CRANK, Bell		(Steel)()	
203A	691744	CRANK, Bell		(Steel)	
205A	691683	SCREW	(Bell Crank)	(Standard)(Nylon)	
206	690325	NUT, Governor Adjusting		(Governor Idle)	
206A	691771	NUT, Governor Adjusting		(Fixed Speed)	
208	691813	ROD, Governor Control		(Non Threaded)	
208A	691820	ROD, Governor Control			
208B	691821	ROD, Governor Control		(Fixed Speed)	
216A	691271	LINK, Choke		(Choke A Matic)	
217	691815	SPRING, Choke Return			
218	691722	WASHER		(Choke Link)	
224	690320	SCREW		(Collar/Screw Kit)	
232	691819	SPRING/LINK, Governor			
265	691024	CLAMP, Casing			
266	691414	CONTROL, Throttle		(Remote Governor/Idle)	
267	690804	SCREW		(Casing Clamp)	
268	691025	CASING, Control Wire		(Cut To Required Length)	
269	691026	WIRE, Control		(Cut To Required Length)	
270	691027	NUT		(Control Wire Casing)	
271	691028	LEVER, Control			
275	691683	SCREW		(Throttle Control)	
275A	691646	SCREW		(Throttle Control)	
280	691184	BRACKET, Rod			
344	691645	SCREW		(Cable Clamp)	
367	691660	SCREW		(Wire Clip)	
410	691274	LINK, Control			
414	691721	WASHER		(Bell Crank)	
542	691683	SCREW		(Link Bracket)	
587	690769	CLAMP, Cable			
629	690457	SPRING, Throttle Return		(Throttle Return)	
689B	692522	SPRING, Friction		(Governor Control Rod)	
725	690440	SHIELD, Heat		(Fuel Tank)	
729A	690471	CLIP, Wire			
779	691828	LINK, Bell Crank			
780A	691211	ANCHOR, Spring		(Governor Idle)	
831	691683	SCREW		(Spring Anchor)	
951	690436	LEVER, Choke			
951	691180	LEVER, Choke			
995	691756	BRACKET, Link			

Ref #	Part #	Description	Qty	Context Note	Foot Note
1012	490507	RETAINER, Link			
1303	690594	CLAMP, Speed Control		(Throttle Control)	

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51	27355	Gasket-Intake Used on Type No(s). 0299, 1101, 1012, 1309.	205C	691630	(Steel, Long) Screw (Bell Crank)	680	691089	(Choke Shaft) Washer (Felt)
90A	397135	Carburetor Used on Type No(s). 1011, 1012. ----- Note ----- 299437 Carburetor Used on Type No(s). 0299. 498298 Carburetor Used on Type No(s). 1309.	212A	691786	Link-Throttle Used on Type No(s). 0299, 1101, 1012, 1309.	680A	691607	Washer (Choke Lever) (Spring)
95	691437	Screw (Throttle Valve)	232A	690498	Spring-Governor Link Used on Type No(s). 0299, 1101, 1012, 1309.	689	691783	Washer (Choke Lever) (Flat)
97A	691946	Shaft-Throttle Used on Type No(s). 0299, 1101, 1012, 1309.	276	691608	Spring-Friction (6 Coil, Closed Ends, Idle Screw)	718A	690296	Pin-Locating (Pump Cover)
110A	690401	Washer (Choke Shaft) (Brass)	352	690257	Seal-O Ring (High Speed Valve)	817	691606	Seal-Throttle Valve (High Speed Valve)
112	691091	Screw (Choke Lever)	392A	692206	Nut-Needle Valve (High Speed Valve)	912	690504	Connector-Vacuum Tube
120	692134	Seat-Needle Valve	393	691213	Seal-Throttle Shaft (Felt)	919	692783	Tube Lever-Choke
127B	691585	Plug-Welch	394	272538	Seal-Throttle Shaft (Felt)	951	691180	Seal-Throttle Shaft (Felt)
130A	211203	Valve-Throttle	432	690766	----- Note ----- 270167 Seal-Throttle Shaft (Felt) Used on Type No(s). 0299.	987A	692279	Screw (Throttle Shaft) (Idle Speed Adjusting Only)
141A	397134	Kit-Choke Shaft	434	691713	Screw (Throttle Shaft) (Idle Speed Adjusting Only)	1149	691624	Valve-High Speed
149	691592	Spring-Needle Valve	435	691619		1227	299060	
173A	690266	Valve-Idle Mixture (Main)	611	691770				
203A	691965	Crank-Bell	612	391813				
			612A	497413				
			633	691869				

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-12


Assemblies include all parts shown in frames.
12

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
51	273113S	GASKET, Intake			
95	691437	SCREW		(Throttle Valve)	
110A	690401	WASHER		(Choke Shaft) (Brass)	
112	691091	SCREW		(Choke Lever)	
120	692134	SEAT-NEEDLE VALVE			
127B	691585	PLUG-WELCH			
130A	211203	VALVE, THROTTLE			
141A	397134	KIT, Choke Shaft			
149	691592	SPRING-NEEDLE VALVE			
173A	690266	VALVE-IDLE MIXTURE		(Main)	
203A	691965	CRANK, Bell		(Steel)()	
203A	691744	CRANK, Bell		(Steel)	
205C	691630	SCREW		(Bell Crank)	
232A	690498	SPRING-GOVERNOR LINK			
276	691608	WASHER-SEALING			
352	690257	WASHER		(High Speed Valve)	
393	691213	SCREEN, Carburetor			
394	272538S	DIAPHRAGM, Carburetor			
432	690766	CAP-SPRING			
434	691713	COVER-DIAPHRAGM			
435	691619	SCREW		(Diaphragm Cover)	
611	691770	PIPE-FUEL			
612	391813	TUBE-PICK UP		(Uses Spring Clip)	
612A	497413S	TUBE-PICK UP		(Uses Spiral Pin)(1/4)	
633	691869	SEAL, Choke/Throttle Shaft			
680	691089	WASHER		(Choke Lever) (Spring)	
680A	691607	WASHER		(Choke Lever) (Flat Washer)	
689	691783	SPRING-FRICTION		(Idle Speed Adjusting Only)	
718A	690296	PIN-LOCATING		(Pump Cover)	
817	691606	SEAL-O RING		(High Speed Valve)	
912	690504	NUT-NEEDLE VALVE			
919	692783	CONNECTOR, Vacuum Tube			
951	690436	LEVER, Choke			
951	691180	LEVER, Choke			
987A	692279	SEAL-THROTTLE SHAFT		(Felt)(5/8)	
1149	691624	SCREW		(Throttle Shaft) (Idle Speed Adjusting Only)	
1227	299060	VALVE, High Speed		(Threaded)	

135200 to 135299




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
37	691732	Guard-Flywheel	305	692198	Screw (Blower Housing)	729A	690471	Clip-Wire (Steel)
78	691660	Screw (Flywheel Guard)	367	691660	Screw (Wire Clip)	732	691097	Screw (Starter Drive Cover)
215	691745	Guide-Air (Rewind Start)	727	690600	Cover-Starter Drive	1036		Label-Emission (Available from A Briggs & Stratton Authorized Dealer)
		----- Note -----						
		690472 Guide-Air (Electric Start)						
304	495759	Housing-Blower						

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

Ref #	Part #	Description	Qty	Context Note	Foot Note
37	691732	GUARD- FLYWHEEL			
78	691660	SCREW		(Flywheel Guard)	
215	690472	GUIDE, Air			
215	691745	GUIDE-AIR		(Rewind Starter)	
304	495759	HOUSING- BLOWER			
305	692198	SCREW		(Blower Housing)	
367	691660	SCREW		(Wire Clip)	
727	690600	COVER, Starter Drive			
729A	690471	CLIP, Wire			
732	691097	SCREW		(Starter Drive Cover)	
1036		Label-Emissions		(Available From A Briggs & Stratton Authorized Dealer)	

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309	690658	Motor-Starter	697	693972	Screw (Drive Cap)	801	690835	Cap-Drive
310	690323	Bolt (Starter Motor)	697A	690298	Screw (Drive Cap)	802	691286	Cap-End
311	497608	Set-Brush				803		Housing-Starter (No Longer Available)
510	499308	Drive-Starter	783	692353	Gear-Pinion (Starter Drive Cover)	1051	691265	Ring-Retaining
513	692024	Clutch-Drive	797	691029	Nut (Brush Retainer)	1090	691293	Retainer-Brush
544	692966	Armature-Starter				1195	691075	Washer (Drive Cap)

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-25


Assemblies include all parts shown in frames.
25

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
309	690658	MOTOR, Starter			
310	690323	SCREW		(Starter Motor)	
311	497608	SET, Brush			
510	499308	DRIVE-STARTER			
513	692024	CLUTCH, Drive			
544	692966	ARMATURE, Starter			
697	693972	SCREW		(Starter Motor) (Drive Cap)	
697A	690298	SCREW		(Starter Motor) (Drive Cap)	
783	692353	GEAR-PINION			
797	691029	NUT		(Brush Retainer)	
801	690835	CAP, Drive			
802	691286	CAP, End			
803		Housing-Starter		(NO LONGER AVAILABLE)	
1051	691265	RING, Retaining			
1090	691293	RETAINER, Brush			
1195	691075	WASHER		(Drive Cap)	

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
16	492088	Crankshaft (No Longer Available) ----- Note ----- 397095 Crankshaft Used on Type No(s). 0049, 0107, 0155, 0215, 0243, 0277, 0649, 1049, 1215. 397103 Crankshaft Used on Type No(s). 0020, 0117, 0132, 0258, 0620, 0728, 0759, 1299, 1020, 1128, 1231, 1258, 1299. 494035 Crankshaft Used on Type No(s). 0026, 0115, 0129, 0151, 0160, 0162, 0163, 0164, 0166, 0199, 0211, 0244, 0252, 0292, 0297, 0327, 0626, 0729, 0752, 1327, 1026, 1115, 1129, 1160, 1252, 1292, 1340. 692140 Crankshaft Used on Type No(s). 1080, 1314. 495642 Crankshaft Used on Type No(s). 0080, 0314. 495643 Crankshaft Used on Type No(s). 0038, 0059, 0072, 0075, 0082, 0083, 0093, 0126, 0228, 0241, 0251, 0291, 0311, 0312, 0638, 0791, 1038, 1072, 1075, 1093, 1291, 1312.		495644 Crankshaft Used on Type No(s). 0035, 0084, 0131, 0247, 0301, 0326, 0635, 1035, 1084, 1301, 1326, 1328, 1333. 495645 Crankshaft Used on Type No(s). 0009, 0018, 0019, 0027, 0029, 0036, 0073, 0106, 0116, 0125, 0128, 0131, 0133, 0134, 0139, 0143, 0161, 0165, 0168, 0176, 0179, 0181, 0186, 0192, 0200, 0208, 0212, 0217, 0227, 0230, 0249, 0250, 0256, 0264, 0268, 0283, 0288, 0299, 0303, 0317, 0318, 0636, 0700, 0717, 0730, 0762, 0779, 0788, 1009, 1012, 1019, 1027, 1029, 1036, 1050, 1073, 1106, 1139, 1143, 1161, 1179, 1186, 1200, 1217, 1250, 1268, 1283, 1288, 1317, 1318. 495649 Crankshaft Used on Type No(s). 0003, 0007, 0060, 0144, 0146, 0148, 0152, 0167, 0171, 0177, 0178, 0183, 0188, 0189, 0190, 0191, 0196, 0197, 0213, 0240, 0255, 0272, 0273, 0289, 0300, 0305, 0603, 0607, 0660, 0767, 0790, 0815, 1003, 1007, 1060, 1146,		1167, 1171, 1190, 1197, 1289, 1330. 499764 Crankshaft Used on Type No(s). 0079, 0140, 0223, 0263, 0294, 0298, 0302, 0307, 0308, 0679, 0702, 0913, 1008, 1079, 1140, 1223, 1263, 1308, 1313. 499765 Crankshaft Used on Type No(s). 0014, 0253. 692142 Crankshaft Used on Type No(s). 0740, 0814, 1261. 17 692007 Bearing-Ball 24 222698s Key-Flywheel 146 690979 Key-Timing (Used with Timing Gear 691847) ----- Note ----- 499047 Key-Timing (Used with Timing Gear 261696) 357 692191 Key-Drive Pulley 357A 690339 Key-Drive Pulley (Woodruff) 741 691847 Gear-Timing (Uses Woodruff Key) ----- Note ----- 261696 Gear-Timing (Uses Locating Pin)		

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095


2610-6

Assemblies include all parts shown in frames.
6

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
17	692007	BEARING-BALL			
24	222698S	KEY, Flywheel			
146	499047	PIN, Locating		(Used With Timing Gear 261696)	
146	690979	KEY, Woodruff		(Used With Timing Gear 691847)	
357	692191	KEY, Drive Pulley			
357A	690339	KEY, Drive Pulley		(Woodruff)	
741	261696	GEAR, TIMING		(Plain Bearing) (Uses Locating Pin)	
741	691847	GEAR, Timing		(Uses Woodruff Key)	

135200 to 135299

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	497144	Cylinder Assembly ----- Note ----- 494955 Cylinder Assembly Used on Type No(s). 0011, 0013, 0022, 0025, 0026, 0059, 0072, 0075, 0080, 0082, 0083, 0084, 0093, 0115, 0121,			0126, 0138, 0157, 0162, 0163, 0164, 0166, 0168, 0181, 0205, 0215, 0225, 0226, 0236, 0241, 0244, 0247, 0248, 0251, 0252, 0256, 0259, 0264, 0277, 0291, 0292, 0297, 0299, 0312, 0314,			0327, 0611, 0625, 0626, 0752, 0757, 0762, 0791, 1011, 1012, 1025, 1026, 1072, 1075, 1080, 1094, 1093, 1115, 1157, 1215, 1252, 1291, 1292, 1312, 1314, 1327, 1328, 1333, 1337, 1340.

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095


2810-2

Assemblies include all parts shown in frames.

04/12/2012

Ref #	Part #	Description	Qty	Context	Note	Foot	Note
1	497144	CYLINDER ASSEMBLY					

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
216	691824	Link-Choke (Manual)	404	691691	Washer (Governor Crank)	614	691620	Pin-Cotter
222A	690816	Bracket-Control (Gear and Rack) Used on Type No(s). 0214.	485	692295	Knob-Control (Slide)	615	93307	Retainer-E Ring
226A	399109	Rod-Hand Choke (Rod Assembly)	485A	391908	Knob-Control	616	692016	Crank-Governor
227	690653	Lever-Governor Control	505	691251	Nut (Governor Control Lever)	620	490649	Bracket-Control (Panel)
		----- Note -----	562	691119	Bolt (Governor Control Lever) (Round)	621	692310	Switch-Stop
		692357 Lever-Governor Control Used on Type No(s). 0299, 1011, 1012.				688	690395	Cap-Friction
367	94025	Screw (Wire Clip)				689A	690529	Spring-Friction (Conical Spring, Hand Choke Control)
						729A	93784	Clip-Wire (Clamp, Steel)
						1197	92484	Screw (Hand Choke Rod)

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-13


Assemblies include all parts shown in frames.
13

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
216	691824	LINK, Choke		(Manual)	
226A	399109	ROD, Choke		(Rod Assembly)	
227	690653	LEVER, Governor Control			
367	691660	SCREW		(Wire Clip)	
404	691691	WASHER		(Governor Crank)	
485	692295	KNOB, Air Cleaner Cover		(Slide)	
485A	391908	KNOB, Air Cleaner Cover		(Round)	
505	691251	NUT		(Governor Control Lever)	
562	691119	BOLT		(Governor Control Lever)	
614	691620	PIN, Cotter			
615	93307	RETAINER, Governor Shaft			
616	692016	CRANK-GOVERNOR			
620	490649	BRACKET, Control			
621	692310	SWITCH, Stop			
688	690395	CAP, Friction			
689A	690529	SPRING, Friction		(Hand Choke Control)	
729A	690471	CLIP, Wire			
1197	92484	SCREW		(Hand Choke Rod)	

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
18	694377	Cover-Crankcase (Gear Reduction) ----- Note ----- 694375 Cover-Crankcase (Auxiliary PTO)		694350	Cover-Crankcase (Plain Bearing)		694319	Cover-Crankcase (Ball Bearing)



Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2610-7


Assemblies include all parts shown in frames.
7

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
18		Cover-Crankcase		(NO LONGER AVAILABLE)	
18	694319	COVER, Crankcase			
18	694350	COVER, Crankcase		(Plain Bearing)	
18	694377	COVER, Crankcase		(Gear Reduction)	

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
90	498298	Carburetor			1159, 1161, 1167, 1169, 1171, 1173, 1179, 1180, 1190, 1194, 1196, 1197, 1200, 1215, 1216, 1217, 1219, 1223, 1231, 1232, 1238, 1242, 1245, 1246, 1250, 1258, 1259, 1261, 1268, 1271, 1276, 1281, 1283, 1284, 1288, 1289, 1289, 1299, 1301, 1304, 1308, 1310, 1313, 1314, 1315, 1317, 1318, 1320, 1324, 1326, 1328, 1329, 1330, 1333, 1336, 1337, 1338, 1340, 1342, 1343, 1345,			0788, 0790, 0814, 0815, 0913, 1003, 1004, 1005, 1007, 1008, 1009, 1011, 1019, 1020, 1023, 1025, 1027, 1029, 1035, 1036, 1049, 1050, 1060, 1070, 1071, 1073, 1079, 1080, 1084, 1105, 1106, 1119, 1127, 1128, 1129, 1139, 1140, 1142, 1143, 1146, 1147, 1153, 1154, 1157, 1158, 1159, 1161, 1167, 1169, 1171, 1173, 1179, 1180, 1190, 1194, 1196, 1197, 1200, 1215, 1216, 1217, 1219, 1223, 1231, 1232, 1238, 1242, 1245, 1246, 1250, 1258, 1259, 1261, 1268, 1271, 1276, 1281, 1283, 1284, 1288, 1289, 1289, 1299, 1301, 1304, 1308, 1313, 1314, 1315, 1317, 1318, 1320, 1324, 1326, 1328, 1329, 1330, 1333, 1336, 1337, 1338, 1340, 1342, 1343, 692725 Jet-Pilot (High Altitude)
		----- Note ----- 495951 Carburetor Used on Type No(s). 0185, 0263. 495425 Carburetor Used on Type No(s). 0214. 498298 Carburetor Used on Type No(s). 0309, 0603, 0607, 0611, 0615, 0616, 0620, 0623, 0625, 0626, 0635, 0636, 0638, 0649, 0660, 0670, 0671, 0679, 0700, 0702, 0704, 0717, 0706, 0727, 0728, 0729, 0730, 0740, 0747, 0752, 0757, 0758, 0759, 0762, 0767, 0772, 0779, 0780, 0784, 0788, 0790, 0814, 0815, 0913, 1003, 1004, 1005, 1007, 1008, 1009, 1011, 1019, 1020, 1023, 1025, 1027, 1029, 1035, 1036, 1049, 1050, 1060, 1070, 1071, 1073, 1079, 1080, 1084, 1105, 1106, 1119, 1127, 1128, 1129, 1139, 1140, 1142, 1143, 1146, 1147, 1153, 1154, 1157, 1158,	147	691250	Jet-Pilot (Standard) Used on Type No(s). 0309, 0603, 0607, 0611, 0615, 0616, 0620, 0623, 0625, 0626, 0635, 0636, 0638, 0649, 0660, 0670, 0671, 0679, 0700, 0702, 0704, 0717, 0706, 0727, 0728, 0729, 0730, 0740, 0747, 0752, 0757, 0758, 0759, 0762, 0767, 0772, 0779, 0780, 0784,			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-10

Assemblies include all parts shown in frames.
10

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context	Note	Foot	Note
90	498298	CARBURETOR					
147	692725	JET, Pilot					

135200 to 135299**219****220****46**

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
46	691164	Camshaft (Used After Code Date 96112400). ----- Note ----- 691166 Camshaft (Used After Code Date 96112400). Used on Type No(s). 0173, 0214, 0309, 0611, 0670, 0671, 0728, 0757, 0758, 0780, 1011, 1070, 1071, 1128, 1154, 1157, 1158, 1169, 1180, 1194, 1232, 1261, 1265, 1309, 1310, 1320, 1324, 1336, 1337, 1338, 1343.			691166 Camshaft (Used Before Code Date 96112500). Used on Type No(s). 0070, 0071, 0108, 0120, 0121, 0124, 0141, 0154, 0157, 0158, 0169, 0174, 0180, 0182, 0194, 0198, 0202, 0203, 0204, 0205, 0206, 0207, 0209, 0216, 0232, 0236, 0254, 0260, 0265, 0269, 0295, 0309, 0310, 0320, 0322, 0324, 0611, 0670, 0671, 0757, 0758, 0780. 692526 Camshaft (Used Before Code Date 96112500). Used on Type No(s). 0173, 0214.	219	494845	Gear-Governor ----- Note ----- 391737 Gear- Governor (Used Before Code Date 91061000). 220 691724 Washer (Governor Gear)

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121


Valve Gasket Set-Reference 1095

2610-9**Assemblies include all parts shown in frames.****04/12/2012****9**

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
46	691166	CAMSHAFT		Used Before Code Date 96112500	
219	391737	GEAR, Governor		Used Before Code Date 91061000	
219	494845	GEAR, Governor		Used After Code Date 91060900	
220	691724	WASHER		(Governor Gear)	

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
15A	691682	Plug-Oil Drain Plug (Flush)	82	690369	Screw (Gear Reduction Case)	86	690608	Cover-Gear
20A	299819	Seal-Oil (PTO Side) (53/64" I.D. Without Spring)	82A	699164	Screw (Gear Reduction Case)	87	691582	Seal-Gear Reduction
79	690605	Case-Gear Reduction	83	690374	Shaft-Auxiliary Drive	88	691600	Gasket-Gear Reduction Cover
80	691602	Gasket-Gear Case	84	691121	Plug-Breather	731	399183	Hood-Snow
			85	691117	Screw (Gear Cover to Gear Reduction)	1196	93977	Screw (Snow Hood)

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121


Valve Gasket Set-Reference 1095

2610-26Assemblies include all parts shown in frames.2604/12/2012

Ref #	Part #	Description	Qty	Context Note	Foot Note
15A	691682	PLUG-OIL DRAIN		(Flush)	
79	690605	CASE, Gear Reduction			
80	691602	GASKET, Gear Case			
82	690369	SCREW		(Gear Reduction Case)	
82A	699164	SCREW		(Gear Reduction Case)	
83	690374	SHAFT, Auxiliary Drive			
84	691121	PLUG-BREATHER			
85	691117	SCREW		(Gear Cover)	
86	690608	COVER, Gear			
87	691582	SEAL, Gear Reduction			
88	691600	GASKET, Gear Cover/Housing			
731	492291	HOOD, Snow			
1196	93977	SCREW		(Snow Hood)	

135200 to 135299

1330 REPAIR MANUAL



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3	299819	Seal-Oil (Magnetto Side)	51	27355	Gasket-Intake Used on Type No(s). 0299, 1101, 1012, 1309.	842	691031	Seal-O Ring (Dipstick Tube) (Used After Code Date 99031400).
7	272157	Gasket-Cylinder Head	51A	273113	Gasket-Intake	842A	691870	Seal-O Ring (Dipstick Tube) (Used Before Code Date 99031500).
9	27549	Gasket-Breather	163	271935	Gasket-Air Cleaner (Standard, Oval)	883	692237	Gasket-Exhaust
12	692213	Gasket-Crankcase (Standard)	191	692241	Gasket-Fuel Tank	978	273326	Gasket-OIL GARD®
		----- Note -----	191A	272996	Gasket-Fuel Tank	1194	691876	Seal-O Ring (Plug)
		270125 Gasket-Crankcase (.005" Thick)	191B	272409	Gasket-Fuel Tank Used on Type No(s). 0299, 1011, 1012.	1330	270962	Repair Manual
		270126 Gasket-Crankcase (.009" Thick)	358A	495603	Gasket Set-Engine			
20	495307	Seal-Oil (PTO Side)	524	691876	Seal-Dipstick Tube			
20A	299819	Seal-Oil (PTO Side)						

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-28


Assemblies include all parts shown in frames.
28

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
3	299819S	SEAL, Oil		(Magneto Side)	
7	272157S	GASKET-CYLINDER HEAD			
9	27549S	GASKET, Breather			
12	270125	GASKET, CRANKCASE		(.005)	
12	270126	GASKET- CRKCSE/009		(.009)	
12	692213	GASKET, Crankcase		(Standard)	
20	294606S	SEAL, Oil		(PTO Side) (PTO Side)(1-3/8 Outside Diameter With Spring)	
20	691952	SEAL, Oil		(PTO Side) (Auxiliary PTO)(1 Outside Diameter With Spring)	
51	273113S	GASKET, Intake			
163	271935S	GASKET, Air Cleaner		(Standard)(Oval)	
191	692241	GASKET, Fuel Tank			
191A	272996	GASKET, Fuel Tank			
358A	495603	GASKET SET, Engine			
524	691876	SEAL, O-Ring			
842	691031	SEAL, O-Ring		(Dipstick Tube) Used After Code Date 99031400	
842A	691870	SEAL, O-Ring		(Dipstick Tube) Used Before Code Date 99031500	
883	692237	GASKET-EXHAUST			
978	273326S	GASKET, Oil Gard			
1194	691876	SEAL, O-Ring		(Plug)	

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51	27355	Gasket-Intake Used on Type No(s). 0299, 1101, 1012, 1309.	173	691777	Valve-Idle Mixture (Idle)	394	272538	Diaphragm-Carburetor (Pump)
51A	273113	Gasket-Intake	173A	690266	Valve-Idle Mixture (Main)	817	691606	Seal-O Ring (High Speed Valve)
120	692134	Seat-Needle Valve	191	692241	Gasket-Fuel Tank	912	690504	Nut-Needle Valve
121	495606	Kit-Carburetor Overhaul	191A	272996	Gasket-Fuel Tank	1227	299060	Valve-High Speed
149	691592	Spring-Needle Valve	191B	272409	Gasket-Fuel Tank Used on Type No(s). 0299, 1011, 1012.			
163	271935	Gasket-Air Cleaner (Standard, Oval)	276	691608	Washer-Sealing			
163A	271139	Gasket-Air Cleaner (1 5/8" O.D. Round)	352	690257	Washer (High Speed Valve)			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-29


Assemblies include all parts shown in frames.
29

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
51	273113S	GASKET, Intake			
120	692134	SEAT-NEEDLE VALVE			
121	495606	KIT, Carburetor Overhaul			
149	691592	SPRING-NEEDLE VALVE			
163	271935S	GASKET, Air Cleaner		(Standard)(Oval)	
163A	271139S	GASKET, Air Cleaner		(1 5/8 Outside Diameter)	
173	691777	VALVE, Idle Mixture			
173A	690266	VALVE-IDLE MIXTURE		(Main)	
191	692241	GASKET, Fuel Tank			
191A	272996	GASKET, Fuel Tank			
276	691608	WASHER-SEALING			
352	690257	WASHER		(High Speed Valve)	
394	272538S	DIAPHRAGM, Carburetor			
817	691606	SEAL-O RING		(High Speed Valve)	
912	690504	NUT-NEEDLE VALVE			
1227	299060	VALVE, High Speed		(Threaded)	

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23		Flywheel (No Longer Available) (Rewind Start)	75	690582	Washer (Flywheel)	455	224250	Cup-Flywheel (Straight Side Cup) (Used Before Code Date 95020300).
23A	690820	Flywheel (With Ring Gear)	324	695161	Screen/Cup Assembly (Used After Code Date 95010800).	455A	494770	Cup-Flywheel (Straight Side Cup With Rotating Screen Ring)
73	224883	Screen-Rotating (Used Before Code Date 95020300).	332	690662	Nut (Flywheel)	726	495765	Gear-Ring (Includes Mounting Hardware)
73A	695161	Screen-Rotating (Used After Code Date 95010800).	363	19069	Flywheel Puller			
		----- Note ----- 224974 Screen- Rotating (No Longer Available) (Used Before Code Date 95010900).						

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-21

Assemblies include all parts shown in frames.
21

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
23A	690820	FLYWHEEL			
73	224883	SCREEN-ROTATING		Used Before Code Date 95020300	
73A	695161	SCREEN/CUP ASSEMBLY			
73A	224974	SCREEN, Rotating			
324	695161	SCREEN/CUP ASSEMBLY		(Tapered Side Cup And Rotating Screen Ring)	
324	695161	SCREEN/CUP ASSEMBLY		Used After Code Date 95010800	
332	690662	NUT		(Flywheel)	
363	19069	PULLER, Flywheel			
455	224250	CUP-FLYWHEEL		(Straight Side Cup) Used Before Code Date 95020300	
455A	494770	CUP, Flywheel		(Straight Side Cup)	
726	495765	GEAR, Ring		(Includes Mounting Hardware)	

135200 to 135299

209



209C



211



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
209	690376	Spring-Governor (Rich Red) ----- Note ----- 691816 Spring-Governor (Black) Used on Type No(s). 0004, 0016, 0020, 0027, 0029, 0119, 0124, 0127, 0141, 0142, 0143, 0176, 0177, 0185, 0189, 0195, 0203, 0209, 0217, 0232, 0240, 0242, 0254, 0260, 0262, 0263, 0265, 0268, 0276, 0281, 0309, 0315, 0324, 1003, 1035, 1080, 1084, 1155, 1171, 1246, 1283, 1326, 1328, 1333. 690549 Spring-Governor (Blue) Used on Type No(s). 0018, 0215, 0225, 0248, 0603, 0607, 0611, 0615, 0623, 0625, 0635, 0636, 0649, 0660, 0670, 0671, 0679, 0700, 0702, 0704, 0717, 0730, 0740, 0747, 0759, 0762, 0767, 0779, 0780, 0784, 0788, 0790, 0814, 0815, 0913, 1005, 1007, 1008, 1009, 1011, 1019, 1023, 1025, 1036, 1049, 1050, 1060, 1070, 1071, 1073, 1079, 1105, 1106, 1139, 1140, 1143, 1146, 1147, 1153, 1154, 1157, 1158, 1159, 1161, 1167, 1169, 1173, 1179, 1180, 1186, 1190, 1194, 1196, 1197, 1200,			1216, 1219, 1223, 1231, 1238, 1245, 1250, 1258, 1259, 1271, 1284, 1288, 1289, 1296, 1299, 1301, 1304, 1308, 1310, 1313, 1314, 1317, 1318, 1320, 1329, 1330. 691817 Spring-Governor (Green) Used on Type No(s). 0026, 0038, 0062, 0115, 0129, 0151, 0160, 0162, 0164, 0166, 0199, 0211, 0241, 0244, 0252, 0311, 0327, 0626, 0638, 0729, 0752, 0791, 1026, 1038, 1115, 1129, 1160, 1252, 1291, 1327, 1340.			690550 Spring-Governor (Yellow) Used on Type No(s). 0059, 0072, 0075, 0083, 0093, 0126, 0163, 0228, 0251, 0292, 0297, 0312, 1072, 1093, 1292, 1312, 1342. 691845 Spring-Governor (Silver) Used on Type No(s). 0616, 0620, 0706, 0727, 0728, 1004, 1016, 1020, 1027, 1029, 1119, 1127, 1128, 1142, 1217, 1232, 1242, 1260, 1261, 1263, 1265, 1268, 1276, 1281, 1309, 1315, 1324, 1343, 1345. 692896 Spring-Governor (Bright Orange) Used on Type No(s). 1215. 209C 692208 Spring-Governor (Green) Used on Type No(s). 0299, 1011, 1012. 211 691850 Spring-Governed Idle

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095


2810-16

Assemblies include all parts shown in frames.
16

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context	Note	Foot	Note
209	690376	SPRING, Governor		(Rich Red)			
211	691850	SPRING, Governed Idle					

135200 to 135299

★ NOTE: ALL FUN-KART APPLICATIONS USING MODEL SERIES
135200 ENGINES MUST USE 694315 FUEL TANK.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
180B	694315	Tank-Fuel ----- Note ----- 495370 Tank-Fuel Used on Type No(s). 0214.	190	692200	Screw (Fuel Tank)	916	691900	Rack-Governor Gear (Black)
180C	494600	Tank-Fuel Used on Type No(s). 0299, 1011, 1012.	190A	691687	Screw (Fuel Tank)			----- Note ----- 690583 Rack- Governor Gear (Natural)
181	394818s	Cap-Fuel Tank (Metal) (Threaded, Vented) ----- Note ----- 498156 Cap-Fuel Tank (Metal) (Threaded, Non Vented) Used on Type No(s). 0293.	190B	691685	Screw (Fuel Tank)			Used on Type No(s). 0016, 0019, 0071, 0147, 0148, 0185, 0195, 0200, 0213, 0214, 0216, 0232, 0260, 0263, 0306, 0310, 1016, 1071, 1147, 1200, 1232, 1260, 1263, 1310.
			191	692241	Gasket-Fuel Tank			
			191A	272996	Gasket-Fuel Tank			
			191B	272409s	Gasket-Fuel Tank Used on Type No(s). 0299, 1011, 1012.			
			621	692310	Switch-Stop	957	494559	Cap-Fuel Tank

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-17

Assemblies include all parts shown in frames.

04/12/2012

17

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context	Note	Foot	Note
180B	694315	TANK, Fuel		(Metal)			
181	394818S	CAP-FUEL TANK		(Metal)			
190	692200	SCREW		(Fuel Tank)			
190A	691687	SCREW		(Fuel Tank)			
190B	691685	SCREW		(Fuel Tank)			
191	692241	GASKET, Fuel Tank					
191A	272996	GASKET, Fuel Tank					
621	692310	SWITCH, Stop					
916	691900	RACK, Governor Gear		(Black)			

135200 to 135299

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
7	272157	Gasket-Cylinder Head	51A	273113	Gasket-Intake	1095	498529	Gasket Set-Valve
9	27549	Gasket-Breather	163	271935	Gasket-Air Cleaner (Standard, Oval)			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095


2810-30

Assemblies include all parts shown in frames.
30

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
7	272157S	GASKET-CYLINDER HEAD			
9	27549S	GASKET, Breather			
163	271935S	GASKET, Air Cleaner		(Standard)(Oval)	
1095	498529	GASKET SET, Valve			

135200 to 135299

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
346	690661	Screw (Spark Arrestor)	677	690661	Screw (Muffler Deflector)	836	691683	Screw (Muffler Guard)
648	691660	Screw (Muffler Guard Bracket)	725A	690440	Shield-Heat (Fuel Tank)	836A	690810	Screw (Muffler Guard)
669	690425	Bracket-Muffler Guard	832A	490534	Guard-Muffler (Super Lo Tone)	836B	690367	Screw (Muffler Guard)
676	393757	Deflector-Muffler (Side Out) (Deep)	832B	690625	Guard-Muffler (Lo Tone)	836C	691681	Screw (Muffler Guard)
		----- Note -----	832C	498257	Guard-Muffler (Round Lo Tone)	836D	690661	Screw (Muffler Guard)
		494423 Deflector-Muffler (Side Out) (Shallow)				994A	399541	Arrestor-Spark
		Used on Type No(s). 0029, 0167, 0190, 0225, 0248, 0276, 0767, 1029, 1276, 1167, 1190.						
676A	395700	Deflector-Muffler (Direct Out)						
676B	393758	Deflector-Muffler (Louvered)						

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2610-20



Assemblies include all parts shown in frames.
20

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
346	690661	SCREW		(Spark Arrestor)	
648	691660	SCREW		(Muffler Guard Bracket)	
669	690425	BRACKET, Muffler Guard			
676	796956	DEFLECTOR, Muffler			
676A	395700	DEFLECTOR, Muffler		(Direct Outlet) (Direct Out)	
676B	393758	DEFLECTOR, Muffler		(Louvered Outlet) (Louvered)	
677	690661	SCREW		(Muffler Deflector)	
725A	690466	SHIELD, Heat		(Muffler)	
832A	490534	GUARD, Muffler		(Super Lo Tone)	
832C	498257	MUFFLER		(Round Lo Tone)	
832B	690625	MUFFLER		(Lo Tone)	
836	691683	SCREW		(Muffler Guard)	
836A	690810	SCREW		(Muffler Guard)	
836B	690367	SCREW		(Muffler Guard)	
836D	690661	SCREW		(Muffler Guard)	
836C	691681	SCREW		(Muffler Guard)	
994A	399541	ARRESTOR, Spark			

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
81	691729	Lock-Muffer Screw	303	94089	Elbow-Exhaust	676	393757	Deflector-Muffer (Side Out) (Deep)
298	690453	Locknut-Muffer/Elbow	613	691351	Screw (Muffer)			----- Note -----
300A	691969	Muffer (Super Lo Tone)	613A	691413	Screw (Muffer)			494423 Deflector-Muffer (Side Out) (Shallow)
300B	494585	Muffer	613B	691632	Screw (Muffer)			Used on Type No(s). 0029, 0167, 0190, 0225, 0248, 0276, 0767, 1029, 1276, 1167, 1190.
		----- Note -----	613C	691665	Screw (Muffer)	676A	395700	Deflector-Muffer (Direct Out)
		(Heat Shield Supplied By Equipment Manufacturer) Used on Type No(s). 0185.	613D	690810	Screw (Muffer)	677	690661	Screw (Muffer Deflector)
300C	390918	Muffer (Lo Tone)	613E	692557	Screw (Muffer) Used on Type No(s). 1127.	725A	690466	Shield-Heat (Muffer)
		----- Note -----				883	692237	Gasket-Exhaust
		692304 Muffer (Lo Tone) Used on Type No(s). 0072, 0075, 0142, 0143, 0193, 0195, 0198, 0208, 0244, 0315, 0316, 1072, 1075, 1127, 1142, 1143, 1315.				981	690408	Brace-Muffer
300D	496892	Muffer (Round Lo Tone) Used on Type No(s). 0138, 0165, 0227, 0274.						

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-19


Assemblies include all parts shown in frames.
19

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
81	691729	LOCK, Muffler Screw			
298	690453	LOCKNUT		(Muffler and Elbow)	
300A	691969	MUFFLER		(Super Lo Tone)	
300B	494585	MUFFLER			
300C	390918S	MUFFLER		(Lo Tone)	
300D	496892	MUFFLER		(Round Lo Tone)	
303	94089	ELBOW, Exhaust		(45 Degree Street)	
613	691351	SCREW		(Muffler)	
613B	691632	SCREW		(Muffler)	
613C	691665	SCREW		(Muffler)	
613D	690810	SCREW		(Muffler)	
676	796956	DEFLECTOR, Muffler			
676A	395700	DEFLECTOR, Muffler		(Direct Outlet) (Direct Out)	
677	690661	SCREW		(Muffler Deflector)	
725A	690466	SHIELD, Heat		(Muffler)	
883	692237	GASKET-EXHAUST			
981	690408	BRACE, Muffler			

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
287		Screw (No Longer Available) (Dipstick Tube)	524	691876	Seal-Dipstick Tube	847	694381	Dipstick/Tube Assembly (Without Bracket) (Used After Code Date 99031400).
287A	691693	Screw (Dipstick Tube)	525	694379	Tube-Dipstick (31/32" ID Top) (Used After Code Date 99031400).	847A	691379	Dipstick/Tube Assembly (With Bracket) (Used Before Code Date 99031500).
338	690270	Gasket-Dipstick	525A	694531	Tube-Dipstick (1 1/64" ID Top) (Used Before Code Date 99031500).	847B	493955	Dipstick/Tube Assembly (Uses 691257 Dipstick Tube)
428	691612	Nut (OIL GARD® Kit)	525C	691257	Tube-Dipstick (Oil Filler Pipe Adapter) (3 1/8" Long)	898	691077	Washer (OIL GARD® Kit)
441	690448	Bracket-Oil Fill	661	690661	Screw (OIL GARD® Light Bracket)	978	273326	Gasket-OIL GARD®
523	499621	Dipstick (8 7/16" Flat Wire) (Used After Code Date 99031400).	789	398661	Harness-Wiring	979	691382	Cover-OIL GARD®
523A	691388	Dipstick (7 11/16" Spring) (Used Before Code Date 99031500).	842	691031	Seal-O Ring (Dipstick Tube) (Used After Code Date 99031400).	980	398182	Kit-OIL GARD®
523B	691942	Dipstick (4 13/16" Round Bar) ----- Note ----- 690777 Dipstick (8 11/16" Spring) Used on Type No(s). 0255, 0273, 0294, 0307, 0308, 1008, 1308.	842A	691870	Seal-O Ring (Dipstick Tube) (Used Before Code Date 99031500).	982	690351	Screw (OIL GARD Cover)
						982A	690350	Screw (OIL GARD Cover)
						983	398660	Light-Indicator
						984	692340	Bracket-OIL GARD® Light

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095


2610-27

Assemblies include all parts shown in frames.
27

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
287		Screw		(Dipstick Tube) (NO LONGER AVAILABLE)	
287A	691693	SCREW		(Dipstick Tube)	
338	690270	SEAL, O-Ring		(Dipstick Tube)	
428	691612	NUT		(Oil GARD Kit)	
441	690448	BRACKET-OIL FILL			
523	499621	DIPSTICK		Used After Code Date 99031400	
523A	691388	DIPSTICK		Used Before Code Date 99031500	
523B	691942	DIPSTICK			
524	691876	SEAL, O-Ring			
525	694379	TUBE, Dipstick		(31/32 Inside Diameter Top) Used After Code Date 99031400	
525A	694531	TUBE, Dipstick		(1 1/64 Inside Diameter Top) Used Before Code Date 99031500	
525C	691257	TUBE, Dipstick		(Oil Filler Pipe Adapter)(3 1/8)	
661	690661	SCREW		(Oil Gard Light Bracket)	
789	398661	HARNESS, Wiring			
842	691031	SEAL, O-Ring		(Dipstick Tube) Used After Code Date 99031400	
842A	691870	SEAL, O-Ring		(Dipstick Tube) Used Before Code Date 99031500	
847	694381	DIPSTICK/TUBE ASSEMBLY		(Without Bracket) Used After Code Date 99031400	
847A	691379	DIPSTICK/TUBE ASSY		(With Bracket) Used Before Code Date 99031500	
847B	493955	DIPSTICK/TUBE ASSEMBLY			
898	691077	WASHER		(Oil GARD Kit)	
978	273326S	GASKET, Oil Gard			
979	691382	COVER, Oil Guard			
980	398182	KIT, Oil Gard			
982	690351	SCREW		(Oil GARD)	
982A	690350	SCREW		(Oil GARD)	
983	398660	LIGHT, Indicator			
984	692340	BRACKET, Oil Guard Light			

135200 to 135299

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55	691422	Housing-Rewind Starter	65	690837	Screw (Rewind Starter)	689C	691855	Spring-Friction (Ratchet Pawl)
58	691921	Rope-Starter (Cut To Required Length)	456	692299	Plate-Pawl Friction	1210	498144	Pulley/Spring Assembly (Pulley)
59	395892	Insert-Grip	459	281505	Pawl-Ratchet	1211	498144	Pulley/Spring Assembly (Spring)
60	691915	Grip-Starter Rope (1 Piece)	592	690800	Nut (Rewind Starter)			
60A	393152	Grip-Starter Rope (2 Piece)	597	691696	Screw (Pawl Friction Plate)			
			608	497830	Starter-Rewind			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-23


Assemblies include all parts shown in frames.
23

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
55	691422	HOUSING, Rewind Starter			
58	691921	ROPE, Starter	(72)	(Cut To Required Length)	
59	396892	INSERT-GRIP			
60	691915	GRIP, Starter Rope		(1 Piece)	
60A	393152	GRIP-STARTER ROPE		(2 Piece)	
65	690837	SCREW		(Rewind Starter)	
456	692299	PLATE-PAWL FRICTION			
459	281505S	PAWL-RATCHET			
592	690800	NUT		(Rewind Starter)	
597	691696	SCREW		(Pawl Friction Plate)	
608	497830	HOUSING, Rewind Starter			
689	691783	SPRING-FRICTION		(Idle Speed Adjusting Only)	
1210	498144	PULLEY/SPRING ASSY		(Pulley)	
1211	498144	PULLEY/SPRING ASSY		(Spring)	

135200 to 135299



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55A		Housing-Rewind Starter (For Complete Rewind Starter Housing Service, See Ref 608, Previous Page)	60A	393152	Grip-Starter Rope	608A		Starter-Rewind (For Complete Rewind Starter Service, See Ref 608, Previous Page)
57A	491889	Rewind Starter Spring	65A	94686	Screw (Rewind Starter)	678	224278	Rewind Spacer
58A	280406	Starter Rope (Cut To Required Length)	101	262626	Shaft Pin	689D	262625	Friction Spring
59	396892	Insert-Grip	144	493824	Starter Pulley	1134	498144	Washer (Pawl Friction Plate)
			456A	224321	Plate-Pawl Friction	1140	280973	Washer (Rewind Starter)
			459A	492833	Pawl-Ratchet			
			592	690800	Nut (Rewind Starter)			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095


2810-24

Assemblies include all parts shown in frames.
24

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
55A		Housing-Rewind Starter		(For Complete Rewind Starter Housing Service, See Ref 608, PreviousPage)	
57A	491889	SPRING, Rewind Starter			
58A	280406S	ROPE, Starter		(Cut To Required Length)	
59	396892	INSERT-GRIP			
60A	393152	GRIP-STARTER ROPE		(2 Piece)	
65A	690759	SCREW		(Rewind Starter) (Rewind Starter)	
101	262626	PIN, Starter Grip			
144	493824	PULLEY/SPRING ASSEMBLY		(Pulley)	
456A	224321	PLATE, Pawl Friction			
459A	492833	SPRING, Ratchet			
592	690800	NUT		(Rewind Starter)	
608A		Starter-Rewind		(For Complete Rewind Starter Service, See Ref 608, Previous Page)	
678	224278	SPACER		(Rewind)	
689D	262625	SPRING, Friction		(Pawl Friction Plate)	
1134	224322	WASHER		(Pawl Friction Plate)	
1140	280973	WASHER		(Rewind Starter)	

135200 to 135299

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
33	211119s	Valve-Exhaust	35	690520	Spring-Valve (Intake)	40	692194	Retainer-Valve
34	261044s	Valve-Intake	36	692180	Spring-Valve (Exhaust)	40B	691760	Retainer-Valve (Exhaust)
						45	690509	Tappet-Valve

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095


2610-5

Assemblies include all parts shown in frames.
5

04/12/2012

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context	Note	Foot	Note
33	211119S	VALVE-EXHAUST					
34	261044S	VALVE-INTAKE					
35	690520	SPRING-VALVE		(Intake)			
36	692180	SPRING-VALVE		(Exhaust)			
40	692194	RETAINER, Valve					
40B	691760	RETAINER-VALVE		(Exhaust)			
45	690509	TAPPET, Valve					

135200 to 135299

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
25	790908	Piston Assembly (Standard) (Used After Code Date 99011100). ----- Note ----- 298904 Piston Assembly (Standard) (Used Before Code Date 99011200). 792532 Piston Assembly (.020" Oversize) (Used After Code Date 99011100). 298906 Piston Assembly (.020" Oversize) (Used Before Code Date 99011200). 298907 Piston Assembly (.030" Oversize) (Used Before Code Date 99011200).	26	498680	Ring Set (Standard) (Used After Code Date 99011100). ----- Note ----- 298982 Ring Set (Standard) (Used Before Code Date 99011200). 498682 Ring Set (.020" Oversize) (Used After Code Date 99011100). 298984 Ring Set (.020" Oversize) (Used Before Code Date 99011200). 498683 Ring Set (.030" Oversize) (Used After Code Date 99011100).	27	691588	Lock-Piston Pin
						28	298909	Pin-Piston (Standard) ----- Note ----- 298908 Pin-Piston (.005" Oversize)
						29	299430	Rod-Connecting
						30	691759	Dipper-Connecting Rod
						32	691664	Screw (Connecting Rod)

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

2810-4

Assemblies include all parts shown in frames.

04/12/2012

4

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
25	298906	PISTON ASSEMBLY		(.020 Oversize) Used Before Code Date 99011200	
25	298907	PISTON ASSEMBLY		(.030 Oversize) Used Before Code Date 99011200	
25	793214	PISTON ASSEMBLY		(Standard)	
26	298982	RING SET-STD		(Standard) Used Before Code Date 99011200	
26	298984	RING SET-020		(.020 Oversize) Used Before Code Date 99011200	
26	498680	RING SET-STD		(Standard) Used After Code Date 99011100	
26	498682	SET, Ring		(.020 Oversize) Used After Code Date 99011100	
26	498683	SET, Ring		(.030 Oversize) Used After Code Date 99011100	
27	691588	LOCK, Piston Pin			
28	298908	PIN, Piston		(.005 Oversize)	
28	298909	PIN, Piston			
29	299430	ROD, Connecting		(Standard)	
30	691759	DIPPER-CONN ROD			
32	691664	SCREW		(Connecting Rod)	