






Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
3	299819S	SEAL, Oil		(Magneto Side)	
4B	799476	SUMP, Engine			
7A	799275	GASKET, Cylinder Head			
12	692232	GASKET, Crankcase			
15	691680	PLUG, Oil Drain		(Square Socket)	
17	798538	BEARING, Ball			
20	399781S	SEAL, Oil		(PTO Side)	
22	691092	SCREW		(Crankcase Cover/Sump)	
51	796596	GASKET, Intake			
163	691894	GASKET, Air Cleaner		(Air Cleaner)	
358	592173	GASKET SET, Engine			
524	692296	SEAL-DIPSTICK TUBE		(Dipstick Tube)	
623	793628	SEAL, O-Ring		(Carburetor Spacer)	
718	690959	PIN, Locating			
737	692511	SCREW		(Oil Filter Adapter)	
750	691147	SCREW		(Oil Pump Cover)	
842	691031	SEAL, O-Ring		(Dipstick Tube)	
868	795440	SEAL-VALVE			
883	793497	GASKET, Exhaust			
943	692514	SEAL, O-Ring		(Oil Pump Cover)	
965	692507	COVER, Oil Pump			
988	692515	GASKET, Oil Adapter			
993	796473	GASKET, Cylinder Head Plate			
1022	796480	GASKET, Rocker Cover			
1024	692508	PUMP, Oil			
1027	795990	FILTER, Oil			
1028	796522	ADAPTER, Oil Filter			
1055	796524	TUBE, Oil Pump			
1430A	799494	GASKET, Breather/Reed			





Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
187	791766	LINE, Fuel		(Cut To Required Length)	
187A	796491	LINE, Fuel		(Formed Hose)	
240	298090S	FILTER, Fuel			
523	796503	DIPSTICK			
524	692296	SEAL-DIPSTICK TUBE		(Dipstick Tube)	
525	796502	TUBE, Dipstick			
601	791850	CLAMP, Hose			
670	793485	SPACER, Fuel Tank			
842	691031	SEAL, O-Ring		(Dipstick Tube)	
847	796501	DIPSTICK/TUBE ASSEMBLY			
957	799585	CAP, Fuel Tank			
957A	692046	CAP, Fuel Tank			
957C	796577	CAP-FUEL TANK			
958	698183	VALVE, Fuel Shut Off			
972	590477	TANK, Fuel			
1059	793471	KIT, Screw/Washer			




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
5	592175	HEAD, Cylinder			
7A	799275	GASKET, Cylinder Head			
13	799277	SCREW		(Cylinder Head)	
33	499642	VALVE, Exhaust			
34	795443	VALVE, Intake			
35	691304	SPRING, Valve		(Intake)	
36	691304	SPRING, Valve		(Exhaust)	
40	692194	RETAINER, Valve			
45	690977	TAPPET, Valve			
51	796596	GASKET, Intake			
163	691894	GASKET, Air Cleaner		(Air Cleaner)	
192	796631	ADJUSTER, Rocker Arm			
238	691300	CAP, Valve			
337	692720	PLUG, Spark		(EMS)	
383	19576S	WRENCH, Spark Plug			
623	793628	SEAL, O-Ring		(Carburetor Spacer)	
635A	692076	BOOT, Spark Plug			
718	690959	PIN, Locating			
830	796472	STUD, Rocker Arm		(Rocker Arm)	
868	795440	SEAL-VALVE			
883	793497	GASKET, Exhaust			
886	799492	KIT, Cylinder Head/Plate Gasket			
914	794451	SCREW		(Rocker Cover)	
993	796473	GASKET, Cylinder Head Plate			
1022	796480	GASKET, Rocker Cover			
1023	796479	COVER, Rocker			
1026	796481	ROD, Push			
1029	691230	ARM, Rocker			
1034	691343	GUIDE, Push Rod			
1095	592174	GASKET SET, Valve			







Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
81	691740	LOCK, Muffler Screw			
300B	799259	MUFFLER		Used Before Code Date 16112100	
300C	596409	MUFFLER		Used After Code Date 16112000	
613	799260	SCREW		(Muffler) Used Before Code Date 16112100	
613A	596410	SCREW		(Muffler) Used After Code Date 16112000	
676A	799187	DEFLECTOR, Muffler			
832	799262	GUARD, Muffler			
836	597516	SCREW		(Muffler Guard)	
837	799261	SPACER		(Muffler)	
883	793497	GASKET, Exhaust			




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
309	799241	MOTOR, Starter			
334	793454	SCREW		(Magneto Armature)	
337	692720	PLUG, Spark		(EMS)	
347	795333	SWITCH, Rocker			
356F	798332	WIRE, Stop			
365	793458	SCREW		(Carburetor/Throttle Body)	
383	19576S	WRENCH, Spark Plug			
474	794103	ALTERNATOR			
621	692310	SWITCH, Stop			
627	796702	BRACKET, Stopswitch			
635A	692076	BOOT, Spark Plug			
697	691127	SCREW		(Starter Motor) (Drive Cap)	
742	93941	RETAINER, E Ring			
851	493880S	TERMINAL-SPARK PLUG			
853A	695897	ADAPTER, Wire			
910	796498	STUD		(Alternator) Used Before Code Date 16082900	
910A	596414	STUD		(Alternator) Used After Code Date 16082800	
937	799420	SPLINE, Starter			
1119	794100	SCREW		(Alternator)	
1119A	596420	SCREW		(Alternator)	
1153	691186	WASHER		(Support Bracket)	
1212	799269	STUD		(Blower Housing) Used Before Code Date 12031900	
1212	591164	STUD		(Blower Housing) Used After Code Date 12031800	
1212B	591166	STUD		(Blower Housing) (Used With Alternator Only) Used After Code Date 12031800	
1212B	799263	STUD		(Blower Housing) (Used With Alternator Only) Used Before Code Date 12031900	




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
1	596413	CYLINDER ASSEMBLY		Used After Code Date 16082800	
1	799278	CYLINDER ASSEMBLY		Used Before Code Date 16082900	
3	299819S	SEAL, Oil		(Magneto Side)	
16	799473	CRANKSHAFT			
24	796335	KEY, Flywheel		(Steel)	
25	799271	PISTON ASSEMBLY		(.020 Oversize)	
25	799270	PISTON ASSEMBLY		(Standard)	
26	799273	SET, Ring		(.020 Oversize)	
26	799272	SET, Ring		(Standard)	
27	691588	LOCK, Piston Pin			
28	799274	PIN, Piston			
29	796470	ROD, Connecting			
32	691664	SCREW		(Connecting Rod)	
32A	695759	SCREW		(Connecting Rod)	
43	593912	SLINGER, Governor/ Oil			
46	694039	CAMSHAFT			
404	690272	WASHER		(Governor Crank)	
615	690340	RETAINER, Governor Shaft			
616	798327	CRANK, Governor			
718	690959	PIN, Locating			
741	797521	GEAR, Timing			
1036		Label-Emissions		(Available From A Briggs & Stratton Authorized Dealer)	
1263	697124	REED, Breather			
1264	793453	SCREW		(Breather Reed)	
1319	794467	LABEL, Warning			
1319A	797669	LABEL, Warning			
1375	799493	COVER, Breather Reed			
1376	794451	SCREW		(Breather Reed Cover)	
1430A	799494	GASKET, Breather/ Reed			




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
23B	591399	FLYWHEEL		(Cast Iron)	
24	796335	KEY, Flywheel		(Steel)	
37A	596408	GUARD, Flywheel			
58	697316	ROPE, Starter		(Cut To Required Length)	
60	281434S	GRIP, Starter Rope			
75	691736	WASHER		(Flywheel)	
78	793480	SCREW		(Flywheel Guard)	
304A	799475	HOUSING, Blower		Used Before Code Date 12031900	
304A	591170	HOUSING, Blower		Used After Code Date 12031800	
332	690662	NUT		(Flywheel)	
363	19069	PULLER, Flywheel			
455A	591400	CUP, Flywheel			
608	796497	STARTER, Rewind			
668	797373	SPACER			
668A	797383	SPACER			
925	796531	COVER, Linkage			
949	799474	GUARD, Debris Screen			
1005	799265	FAN, Flywheel			
1006	799264	RETAINER, Fan			
1212	591164	STUD		(Blower Housing) Used After Code Date 12031800	
1212	799269	STUD		(Blower Housing) Used Before Code Date 12031900	
1212A	799268	STUD		(Blower Housing) Used Before Code Date 12031900	
1212A	591165	STUD		(Blower Housing) Used After Code Date 12031800	
1212B	799263	STUD		(Blower Housing) (Used With Alternator Only) Used Before Code Date 12031900	
1212B	591166	STUD		(Blower Housing) (Used With Alternator Only) Used After Code Date 12031800	
1335	793481	NUT		(Blower Housing)	




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
202	796657	LINK, Mechanical Governor			
209	799267	SPRING, Governor			
216	796485	LINK, Choke			
222	796482	BRACKET, Control		(Manual Friction, Remote, & Fixed Speed Control)	
227	796487	LEVER, Governor Control			
265	690798	CLAMP, Casing			
267	691044	SCREW		(Casing Clamp)	
268	691025	CASING, Control Wire		(Cut To Required Length)	
269	691026	WIRE, Control		(Cut To Required Length)	
270	691027	NUT		(Control Wire Casing)	
271	691028	LEVER, Control			
291	799483	THERMOSTAT			
505	793515	NUT		(Governor Control Lever)	
562	793514	BOLT		(Governor Lever)	
621	692310	SWITCH, Stop			
745	793491	SCREW		(Brake)	
883	793497	GASKET, Exhaust			
922	692135	SPRING, Brake			
923	796635	BRAKE			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
51	796596	GASKET, Intake			
51A	590398	GASKET, Intake			
104	797622	PIN, Float Hinge			
117	498977	JET, Main		(Standard)	
118	692677	JET, Main		(High Altitude)	
121	796612	KIT, Carburetor Overhaul			
122	796595	SPACER, Carburetor			
125	799479	CARBURETOR			
127	694468	PLUG, Welch		(Bowl Vent)	
127A	797633	PLUG, Welch			
130	797630	VALVE, Throttle			
133	398187	FLOAT-CARBURETOR			
134	398188	KIT-NEEDLE/SEAT			
137	796610	GASKET, Float Bowl			
163	691894	GASKET, Air Cleaner		(Air Cleaner)	
202	796657	LINK, Mechanical Governor			
216	796485	LINK, Choke			
217	799179	SPRING, Choke Return			
276	271716	WASHER-SEALING			
365	793458	SCREW		(Carburetor/Throttle Body)	
623	793628	SEAL, O-Ring		(Carburetor Spacer)	
633	797629	SEAL, Choke/Throttle Shaft			
975	796611	BOWL, Float			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
11	796478	TUBE, Breather			
163	691894	GASKET, Air Cleaner		(Air Cleaner)	
265	690798	CLAMP, Casing			
267	691044	SCREW		(Casing Clamp)	
347	795333	SWITCH, Rocker			
445	795066	FILTER, A/C Cartridge			
497	691044	SCREW		(Stopswitch Bracket)	
627	796702	BRACKET, Stopswitch			
875	796492	BASE, Air Cleaner			
967	796254	FILTER, Pre Cleaner			
968	796493	COVER, Air Cleaner			
971	690349	SCREW		(Air Cleaner Base to Carburetor/Throttle Body)	