


Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
309C	593445	MOTOR, Starter		(230 Volt)	
333	796964	ARMATURE, Magneto			
334	699477	SCREW		(Magneto Armature)	
347	795333	SWITCH, Rocker			
356C	695630	WIRE, Stop			
356L	790552	WIRE, Stop			
442	795012	SCREW		(Starter Strap)	
474	797090	ALTERNATOR		(60W A/C ONLY)	
493B	691177	BRACKET, Mounting			
501	698315	REGULATOR			
526	690297	SCREW		(Regulator)	
578B	791956	WIRE ASSEMBLY			
578C	794819	WIRE ASSEMBLY			
697	795012	SCREW		(Starter Motor) (Drive Cap)	
697	795026	SCREW		(Starter Motor) (Drive Cap)	
727	698039	COVER-STARTER DRIVE			
732	699200	SCREW		(Starter Drive Cover)	
735	795901	CORD, Starter			
813	690635	CLAMP			
851	493880S	TERMINAL, Spark Plug			
892	791944	SWITCH, Key			
892A	798182	SWITCH, Key			
990	794696	KEY SET			
990A	798177	SET, Key			
1054	280275	TIE, Cable			
1059	793567	KIT-SCREW/WASHER			
1119	699772	SCREW		(Alternator)	
1403	699481	SCREW		(Wire Assembly)	



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
5	594701	HEAD, Cylinder		Used After Code Date 14090400	
5A	791720	HEAD, Cylinder		Used Before Code Date 14090500	
7B	791716	GASKET, Cylinder Head			
13	594518	SCREW		(Cylinder Head) Used After Code Date 14090400	
13	699482	SCREW		(Cylinder Head) Used Before Code Date 14090500	
33	499642	VALVE, Exhaust			
34	795443	VALVE, Intake			
35	691304	SPRING, Valve		(Intake)	
36	691304	SPRING, Valve		(Exhaust)	
40	692194	RETAINER, Valve			
45	690977	TAPPET, Valve			
51	692555	GASKET, Intake		(2 Required)	
122	791717	SPACER, Carburetor			
155	698214	PLATE, Cylinder Head		(SAE) Used Before Code Date 09061800	
155	797442	PLATE, Cylinder Head		(Metric) Used After Code Date 09061700	
192	694543	ADJUSTER- ROCKER ARM		(SAE) Used Before Code Date 09061800	
192	797440	ADJUSTER. Rocker Arm		(Metric) Used After Code Date 09061700	
238	691300	CAP, Valve			
337	793541	PLUG, Spark			
365	699484	SCREW		(Carburetor/Throttle Body)	
383	19576S	WRENCH, Spark Plug			
553	594515	RETAINER, Valve			
619	699481	SCREW		(Cylinder Head Plate)	
635	692076	BOOT, Spark Plug			
635A	798619	BOOT-SPARK PLUG			
830	797441	STUD, Rocker Arm		(Rocker Arm) (Metric) Used After Code Date 09061700 Used Before Code Date 14090400	
830	694544	STUD-ROCKER ARM		(Rocker Arm) (SAE) Used Before Code Date 09061800	
830	594230	STUD, Rocker Arm		(Rocker Arm) Used After Code Date 14090300	
868	795440	SEAL-VALVE			
914	699481	SCREW		(Rocker Cover) (Bottom)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
914A	594517	SCREW		(Rocker Cover) (Quantity 1 Top Or Center) Used After Code Date 15090400	
914A	692557	SCREW		(Rocker Cover) (Top) Used Before Code Date 09061800	
914A	797444	SCREW		(Rocker Cover) (Quantity 1 Top Or Center) Used After Code Date 09061700 Used Before Code Date 14090500	
914B	691108	SCREW		(Rocker Cover) (Center) Used Before Code Date 09061800	
993	694088	GASKET, Cylinder Head Plate			
1022	691890	GASKET- ROCKER COVER			
1023	499924	COVER, Rocker			
1026	790287	ROD, Push			
1029	691230	ARM, Rocker		(SAE) Used Before Code Date 09061800	
1029	797443	ARM, Rocker		(Metric) Used After Code Date 09061700	
1034	594229	GUIDE, Push Rod		Used After Code Date 14090300	
1034	691343	GUIDE, Push Rod		Used Before Code Date 14090400	
1095A	791798	GASKET SET, Valve			




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
12	699485	GASKET, Crankcase			
17	798538	BEARING, Ball			
18	699804	COVER, Crankcase			
20	692550	SEAL-OIL		(PTO Side)	
20A	691952	SEAL, Oil		(PTO Side) (Auxiliary Drive)	
21	281658S	CAP, Oil Fill			
22	594519	SCREW		(Crankcase Cover/Sump)	
219	693578	GEAR, Governor			
220	691724	WASHER		(Governor Gear)	
287	699234	SCREW		(Dipstick Tube)	
415	693463	PLUG			
523	693618	DIPSTICK			
524	281370S	SEAL, Dipstick Tube		(Dipstick Tube)	
742	692564	RETAINER, E Ring			
746	790278	GEAR-IDLER			
842	691031	SEAL, O-Ring		(Dipstick Tube)	
847	693617	DIPSTICK/TUBE ASSEMBLY			



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
55A	696710	HOUSING, Rewind Starter			
58	693389	ROPE, Starter		(Cut To Required Length)	
65A	699851	SCREW		(Rewind Starter)	
188	699479	SCREW		(Control Bracket)	
190	699220	SCREW		(Fuel Tank)	
209	692571	SPRING, Governor		(No Color)	
209A	691278	SPRING, Governor		(Platinum)	
222F	793100	BRACKET, Control			
222G	793109	BRACKET, Control			
227	794367	LEVER, Governor Control			
268	691025	CASING, Control Wire		(Cut To Required Length)	
269	691026	WIRE, Control		(Cut To Required Length)	
270	691027	NUT		(Control Wire Casing) (Control Wire Casing)	
271	691028	LEVER, Control			
271A	698038	LEVER, Control			
427	694255	NUT		(Control Bracket) (SAE)	
427	798458	NUT		(Control Bracket) (Metric)	
456	692299	PLATE-PAWL FRICTION			
458	699334	GRIP, Starter Rope			
459	281505S	PAWL-RATCHET			
485	695755	KNOB, Control			
504	695383	SET, Friction Washer			
505	691251	NUT		(Governor Control Lever)	
562	691119	BOLT		(Governor Control Lever)	
597	691696	SCREW		(Pawl Friction Plate)	
608A	699335	STARTER-REWIND		Used Before Code Date 10072000	
608B	797430	STARTER, Rewind		Used After Code Date 10071900	
621	692310	SWITCH, Stop			
632	692653	SPRING/LINK, Mechanical Governor			
668	694257	SPACER			
689	691855	SPRING-FRICTION			
773	694258	RETAINER			
930	696709	GUARD, Rewind			
1210	498144	PULLEY/SPRING ASSY		(Pulley)	
1211	498144	PULLEY/SPRING ASSY		(Spring)	
1230	699847	STUD		(Control Bracket)	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
51	692555	GASKET, Intake		(2 Required)	
51A	791718	GASKET, Intake			
95	691636	SCREW		(Throttle Valve)	
97C	797628	SHAFT, Throttle			
98C	797156	KIT, Idle Speed			
104C	797622	PIN, Float Hinge			
105A	797139	VALVE, Float Needle			
108	796993	VALVE, Choke			
109	791957	SHAFT, Choke			
109B	695729	SHAFT, Choke			
109C	791954	SHAFT, Choke			
117E	590906	JET, Main		(Standard) Used After Code Date 11080700	
117E	798930	JET, Main		(Standard) Used Before Code Date 11080800	
118E	590440	JET, Main		(High Altitude) Used After Code Date 11080700	
118E	590440	JET, Main		(High Altitude) Used Before Code Date 11080800	
118E	798661	JET, Main		(High Altitude) (High Altitude) Used Before Code Date 11080800	
121D	797634	KIT, Carburetor Overhaul			
122	791717	SPACER, Carburetor			
125	594014	CARBURETOR		Used Before Code Date 11080800	
125	594015	CARBURETOR		Used After Code Date 11080700	
127E	797633	PLUG, Welch			
130D	797630	VALVE, Throttle			
133B	797136	FLOAT, Carburetor			
137D	798932	GASKET, Float Bowl			
163B	696024	GASKET, Air Cleaner		(Flat Panel Air Cleaner)	
187	791766	LINE, Fuel		(Cut To Required Length)	
187A	791867	LINE, Fuel		(Molded) Used Before Code Date 10071000	
187A	798908	LINE, Fuel		(Molded) Used After Code Date 10070900	
187B	791874	LINE, Fuel		(Molded) Used Before Code Date 10071000	
187B	798907	LINE, Fuel		(Molded) Used After Code Date 10070900	
190	699220	SCREW		(Fuel Tank)	
209	692571	SPRING, Governor		(No Color)	
276C	797632	WASHER, Sealing			
318	798649	SCREW		(Mounting Bracket) (Metric)	
318	690370	SCREW		(Mounting Bracket) (SAE)	
365	699484	SCREW		(Carburetor/Throttle Body)	


Ref #	Part #	Description	Qty	Context Note	Foot Note
472	791958	KNOB, Choke Shaft			
472C	791948	KNOB, Choke Shaft			
528	793006	HOSE, Primer			
601	791850	CLAMP, Hose			
633	693867	SEAL, Choke/Throttle Shaft			
692B	797624	SPRING, Detent			
957	792647	CAP, Fuel Tank		(Fresh Start)	
957	795027	CAP, Fuel Tank		(Text Free)	
957A	799719	CAP, Fuel Tank		(Carbon In Cap)	
957B	698109	CAP, Fuel Tank			
958	698180	VALVE, Fuel Shutoff			
972	799863	TANK, Fuel			
975D	798931	BOWL, Float			
1357	794700	SLEEVE, Fuel Line			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
1	596087	CYLINDER ASSEMBLY		Used After Code Date 16090100	
1	794188	CYLINDER ASSEMBLY		Used Before Code Date 16090200	
2	796961	KIT, Bushing/Seal		(Magneto Side)	
3	299819S	SEAL, Oil		(Magneto Side)	
7B	791716	GASKET, Cylinder Head			
12	699485	GASKET, Crankcase			
15	691686	PLUG-OIL DRAIN			
16	797077	CRANKSHAFT			
20	692550	SEAL-OIL		(PTO Side)	
20A	691952	SEAL, Oil		(PTO Side) (Auxiliary Drive)	
24	796335	KEY, Flywheel			
25	791791	PISTON ASSEMBLY		(.020 Oversize)	
25	791786	PISTON ASSEMBLY		(Standard)	
26	791792	SET, Ring		(.020" Oversize)	
26	791787	SET, Ring		(Standard)	
27	690975	LOCK, Piston Pin			
28	690229	PIN, Piston		(Standard)	
29B	791783	ROD, Connecting			
32B	791784	SCREW		(Connecting Rod)	
46	693404	CAMSHAFT			
46A	695285	CAMSHAFT			
51	692555	GASKET, Intake		(2 Required)	
82	690369	SCREW		(Gear Reduction Case)	
306A	594227	SHIELD, Cylinder			
307	794822	SCREW		(Cylinder Shield)	
307A	699234	SCREW		(Cylinder Shield)	
307B	790557	SCREW		(Cylinder Shield)	
357	692191	KEY, Drive Pulley			
358B	791797	GASKET SET, Engine			
377	690979	KEY, Woodruff			
552	692346	BUSHING, Governor Crank			
584	791759	COVER, Breather Passage			
585	791760	GASKET, Breather Passage			
598	220624	SHIM, End Play		(Crankshaft or Camshaft Bearing)	
615	692576	RETAINER, Governor Shaft			
616	692547	CRANK, Governor			
684	793369	SCREW		(Breather Passage Cover)	
718	592860	PIN, Locating			

Ref #	Part #	Description	Qty	Context Note	Foot Note
741	695087	GEAR, Timing		(Metal)	
741	593499	GEAR, Timing		(Plastic)	
868	795440	SEAL-VALVE			
883A	691893	GASKET-EXHAUST			
993	694088	GASKET, Cylinder Head Plate			
998	696683	PIPE, Oil		(4)	
998	792928	PIPE, Oil		(2 1/2)	
998	794701	PIPE, Oil		(5)	
1019	792211	KIT, Label			
1022	691890	GASKET-ROCKER COVER			
1036		Label-Emissions		(Available From A Briggs & Stratton Authorized Dealer)	
1319	794467	LABEL, Warning			
1319A	797669	LABEL, Warning			
1330	272147	MANUAL, Repair			
1427	695757	PLUG, Oil Drain			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
11B	695745	TUBE, Breather			
23	798882	FLYWHEEL			
37	699661	GUARD, Flywheel			
65	699228	SCREW		(Rewind Starter)	
78	699205	SCREW		(Flywheel Guard)	
281	793122	PANEL, Control			
300E	594226	MUFFLER			
304	596229	HOUSING, Blower			
305	699481	SCREW		(Blower Housing)	
318	798649	SCREW		(Mounting Bracket) (Metric)	
318	690370	SCREW		(Mounting Bracket) (SAE)	
332A	591988	NUT		(Flywheel)	
363	19203	PULLER, Flywheel			
455	797431	CUP, Flywheel		Used After Code Date 11071900	
455	591302	CUP, Flywheel		Used Before Code Date 10072000	
472C	791948	KNOB, Choke Shaft			
493A	695744	BRACKET, Mounting			
528	793006	HOSE, Primer			
564	699854	SCREW		(Control Cover)	
604A	793134	COVER, Control			
604B	790473	COVER, Control			
610	794614	ARRESTER-INTAKE			
613D	798517	SCREW		(Muffler)	
663	699206	SCREW		(Control Panel)	
676D	794213	DEFLECTOR, Muffler			
677A	699776	SCREW		(Muffler Deflector)	
727	698039	COVER-STARTER DRIVE			
731A	794589	HOOD, Snow			
731B	798456	HOOD, Snow			
732	699200	SCREW		(Starter Drive Cover)	
832D	793193	MUFFLER			
832E	797003	MUFFLER			
836E	699854	SCREW		(Muffler Guard)	
883A	691893	GASKET-EXHAUST			
976	793382	PRIMER, Carburetor			
1005A	794273	FAN, Flywheel			
1011	794544	TUBE, Vent			
1070	699201	SCREW		(Flywheel Fan)	
1196	798785	SCREW		(Snow Hood)	
1196A	699854	SCREW		(Snow Hood)	
1251A	594231	SHIELD, Snow			
1251B	594228	SHIELD, Snow			
1252	699234	SCREW		(Snow Shield)	
1252A	699491	SCREW		(Snow Shield)	