





Ref #	Part #	Description	Qty	Context Note	Foot Note
23	298260	FLYWHEEL			
23	392028	FLYWHEEL		(Aluminum Ring Gear) For Use on Engines with Alternator	
37	222475	GUARD, Flywheel			
55	393576	HOUSING, Rewind Starter			
56	295871	PULLEY, Starter		(63 Rope) Includes 63 Rope; if Longer Rope is required, Order Rope No. 66894 and cut to required length.	
57	490179	SPRING- REWIND STR			
58	66884	ROPE, Starter		(Cut To Required Length) if longer Rope is needed, Order No. 66894 and cut to required length.	
59	230228	PIN, Starter Grip			
60	66728	GRIP, Starter Rope			
63	260414	SPRING, Ratchet			
64	230543	ADAPTER, Ratchet Spring			
65B	94124	SCREW			
65A	94018	SCREW			
65	93067	SCREW		(3/8)	
66	394558	CLUTCH, Starter		(engines w/Ring Gear on Flywheel equipped for Electric Start)	
66	399671	CLUTCH- STARTER		(Uses Rubber Coated Retainer Washer- Ref. 71)	
67	394897	HOUSING, Clutch			
68	63770	BALL, Clutch			
70	298799	RATCHET, Clutch		(engine W/Ring Gear on FW equipped for Elec Start)	
71	221653	WASHER			
71	394506	COVER, Ratchet		(Rubber Coated)	
73	221796	SCREEN, Rotating			
74	93042	SCREW			
75	220865	WASHER		(Heavy Flywheel)	
76	68238	SEAL, Ratchet			
78	93805	SCREW			
200	221760	GUIDE, Air			
304	391379	HOUSING, Blower			

Ref #	Part #	Description	Qty	Context Note	Foot Note
319	395326	ARMATURE, Magneto		(Electronic Ignition-Without Module)	
332	92284	NUT		(Flywheel)	
333A	395492	ARMATURE, Magneto		(Magnetron Ignition)	
333	398811	ARMATURE, Magneto		(Magnetron Ignition)	
334	93381	SCREW			
356A	298693	WIRE, Stop		(Cut To Required Length)	
356	398808	WIRE, Stop		(Cut To Required Length)	
363	19165	PULLER, Flywheel			
373	92987	STARTER, Rewind			
455	222561	CUP, Flywheel			
468	222302	SCREEN, Rotating		(Stationary) Uses: 93572 Screw (8) 231020 Spacer (4)	
468	222562	SCREEN, Rotating			
517	295423	PULLEY, Rope Starter			
518	69932	GRIP, Starter Rope			
608	390391	STARTER, Rewind			
655	222598	ANCHOR, Rewind Spring		(Stamped Rewind Housing)	
781	280068	CAP, Starter Pulley			Both Guards Use: 93712 Screw (2)
851	221798	TERMINAL, Spark Plug			Both Guards Use: 93712 Screw (2)
897	394970	KIT, Magnetron Ignition			Both Guards Use: 93712 Screw (2)
949A	396581	GUARD, Rewind			Both Guards Use: 93712 Screw (2)
949	397530	GUARD, Debris Screen		(Rewind Starter)	Both Guards Use: 93712 Screw (2)
949	398857	GUARD, Debris Screen		(Electric Starter)	Both Guards Use: 93712 Screw (2)

Ref #	Part #	Description	Qty	Context Note	Foot Note
954	223379	BRACKET, Mounting			Both Guards Use: 93712 Screw (2)
986	271735	FILTER, Debris Foam			Both Guards Use: 93712 Screw (2)
1016	490817	SPACER- REWIND		(Rewind)	

DC ONLY	DUAL CIRCUIT	TRI - CIRCUIT	10 AMP
23A or NOTE under 23	23A or NOTE under 23	23A or NOTE under 23	23A or NOTE under 23
887 	474 	474A 	474B 
878A 	878 	814 	878A 
			501 


NOTE: All stators use No. 482 Mtg. Screw



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
23A	392034	FLYWHEEL		(Aluminum Ring Gear) For use only on electric starter engines WITHOUT ALTERNATOR (Includes aluminum ring gear.)	
23A	391983	FLYWHEEL		(Engines With Alternator) For use on engines WITH ALTERNATOR (Includes aluminum ring gear.)	
23	298260	FLYWHEEL			
23	392028	FLYWHEEL		(Aluminum Ring Gear) For Use on Engines with Alternator	
309	393851	MOTOR, Starter		(3 1/2 Housing) (Briggs & Stratton 110V)	
309	394805	MOTOR, Starter		(3 1/16 Housing)	
346	93705	SCREW		(8-32 X 3/8)	
423	93984	SCREW			
474A	392595	ALTERNATOR		(Tri Circuit) (9 Amp Regulated)	
474B	393295	ALTERNATOR		(10, 13, or 16 Amp-Depending on Size of Flywheel Magnets) (Regulated)	
474	393474	ALTERNATOR		(Dual Circuit)	
482	93621	SCREW		(Tapping)	
501	394890	REGULATOR		(10, 13, or 16 Amp, Depending on Size of Flywheel Magnets)	
526	93343	SCREW		(Control Panel)	
605	222934	BRACKET, Mounting			
726	392134	GEAR, Ring			
727	221940	GUARD, Flywheel		Used Before Code Date 86082600	Both Guards Use: 93712 Screw (2)
727	223597	GUARD, Flywheel		Used After Code Date 86082500	Both Guards Use: 93712 Screw (2)
727	395405	COVER, Starter Drive			
728	93535	SCREW		(5/16-18 X 3/4)	Both Guards Use: 93712 Screw (2)
735	390966	CORD, Starter		(Includes Adaptor Plug)	Both Guards Use: 93712 Screw (2)
763	391604	KIT, Electric Starter		(12 Volt Gear Drive)	Both Guards Use: 93712 Screw (2)

Ref #	Part #	Description	Qty	Context Note	Foot Note
800	222095	RETAINER			Both Guards Use: 93712 Screw (2)
814	392606	HARNESS, Alternator		(Tri Circuit)	Both Guards Use: 93712 Screw (2)
841	393514	CLAMP			Both Guards Use: 93712 Screw (2)
877A	393814	WIRE/ CONNECTOR, Alternator		(10 Amp Regulated)	Both Guards Use: 93712 Screw (2)
877B	393537	WIRE/ CONNECTOR, Alternator		(Tri Circuit) (9 Amp)	Both Guards Use: 93712 Screw (2)
877	393456	WIRE/ CONNECTOR, Alternator			Both Guards Use: 93712 Screw (2)
878A	393422	WIRE ASSEMBLY		(Dc Only)	Both Guards Use: 93712 Screw (2)
878	393362	HARNESS, Alternator		(Dual Circuit)	Both Guards Use: 93712 Screw (2)
887	391529	ALTERNATOR		(DC Only)	Both Guards Use: 93712 Screw (2)




Ref #	Part #	Description	Qty	Context Note	Foot Note
1	396269	CYLINDER ASSEMBLY			
2	261960	KIT, Bushing/Seal			
3	294606	SEAL, Oil			
5	212286	HEAD, Cylinder			
8	391406	BREATHER ASSEMBLY			
9	27803	GASKET, Rocker Cover		Included in Gasket Set-Part No. 299577	
10	93394	SCREW			
11	280005	TUBE, Breather			
12	27750	GASKET, Crankcase		(1/64) Included in Gasket Set-Part No. 299577	
12	27876	GASKET, Crankcase		(.005) Included in Gasket Set-Part No. 299577	
12	27877	GASKET, Crankcase		(.009) Included in Gasket Set-Part No. 299577	
13	93211	SCREW		(5/16-18 X 2-21/32)	
13	93776	STUD		(Cylinder Head)	
14	93723	SCREW		(3)	
14	93781	STUD		(3 15/16)	
15	91084	PLUG, Oil Drain		(3/8)	
16	396876	CRANKSHAFT		Order Part 230978 for Timing Gear Pin Replacement	
18	392548	SUMP, Engine			
19	295963	KIT, Bushing/Seal			
20	391086	SEAL, Oil		(Magnetoside)	
21	66768	PLUG, Oil			
22	93585	SCREW		(Crankcase Cover)	
24	222698	KEY, Flywheel			
25	391673	PISTON ASSEMBLY		(Standard)	
25	391674	PISTON ASSEMBLY		(.010 Oversize)	
25	391675	PISTON ASSEMBLY		(.020 Oversize)	
25	391676	PISTON ASSEMBLY		(.030 Oversize)	
26	299743	SET, Ring		(.030 Oversize Chrome)	
26	391669	SET, Ring		(Standard)	
26	391670	SET, Ring		(.010 Oversize)	
26	391671	SET, Ring		(.020 Oversize)	
26	391672	SET, Ring		(.030 Oversize)	
27	68546	LOCK, Piston Pin			
28	295840	PIN, Piston		(Standard)	
28	295841	PIN, Piston		(.005 Oversize)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
29	390402	ROD, Connecting		For Connecting Rod with .020 Undersize Crankpin Bore-Order No. 390773	
31	222114	LOCK, Rod Screw			
32	92659	SCREW		(Connecting Rod)	
33	390419	VALVE, Exhaust		(Includes Retainer(s))	
34	261055	VALVE, Intake			
35	65906	SPRING, Valve		(Intake)	
36	26828	SPRING, Valve		(Exhaust)	
40	221596	RETAINER, Valve		(Valves With Groove In Stem)	
41	292260	RETAINER, Valve		(Exhaust Valve) (Exhaust)	
42	93630	KEEPER, Valve		(2)	
45	260933	TAPPET, Valve			
46	211689	CAMSHAFT			
81	222263	LOCK, Muffler Screw		(3/8 Diameter Bolt Holes)	
98A	90200	SCREW		(8-32 X 1/2)	
99	26157	SPRING, Compression			
201	260971	LINK, Choke		Used Before Code Date 82121010	
201	261611	LINK, Choke		Used After Code Date 82121110	
209	261306	SPRING, Governor			
219	392718	SLINGER, Governor/ Oil			
222	390662	BRACKET, Control		Used Before Code Date 82121010	
222	390746	BRACKET, Control		(Manual Choke) Used After Code Date 82121110	
222	390784	BRACKET, Control		(Choke-A-Matic) Used After Code Date 85041400	
222	396199	BRACKET, Control		Used After Code Date 82121110 and Before Code Date 85041500	
225	231058	CRANK, Governor		(1/4 Diameter)	
227	391733	LEVER, Governor Control		(1/4 Diameter)	
230	222450	WASHER			
232	260584	SPRING/LINK, Mechanical Governor		Used Before Code Date 82121010	
232	261911	SPRING/LINK, Governor		Used After Code Date 82121110	
265	221535	CLAMP, Casing		(Stamped Steel)	
284	93804	SCREW		(Clamp Mounting)	
298	261409	LOCKNUT		(Muffler and Elbow)	
300C	392101	MUFFLER		(Super Lo Tone)	
300B	391313	MUFFLER			

Ref #	Part #	Description	Qty	Context Note	Foot Note
300B	391232	MUFFLER		Uses: 93587 Screw-Muffler Bracket to Head 93606 Screw- Guard to Muffler	
300A	398507	MUFFLER			
300	393010	MUFFLER		(Round Lo Tone)	
303	91205	ELBOW, Exhaust		(90 Degree)	
306	222830	SHIELD, Cylinder			
307	93163	SCREW			
308	222636	COVER, Cylinder Head			
337	293918	PLUG, Spark			
337	298809	PLUG, Spark			
346	93705	SCREW		(8-32 X 3/8)	
351	91920	SCREW		(8-32 X 5/8)	
351	93735	SCREW			
352	66068	WASHER		(Fiber)	
353	92791	WASHER			
354	90576	NUT		(Ground Terminal)	
355	66554	WASHER		(Insulating)	
357	91540	KEY, Drive Pulley		(1/4)	
358	299577	GASKET SET, Engine			
383	89838	WRENCH, Spark Plug			
422	222502	CLAMP, Tube			
520	93722	TERMINAL, Ground			
523	391840	DIPSTICK/CAP ASSEMBLY		(Screw Cap)	
524	68838	SEAL, O-Ring		(Dipstick Tube)	
525	280133	TUBE, Dipstick		(Plastic Screw Cap Dipstick)	
552	231055	BUSHING, Governor Crank		(1/4 I.D.)	
562	92613	BOLT		(Governor Lever)	
592	231082	NUT		(Governor Control)	
613	93704	SCREW		(Muffler) Used Before Code Date 82091300	
613	94042	SCREW		(Muffler) Used After Code Date 82091400	
614	93306	PIN, Cotter			
615	93307	RETAINER, Governor Shaft			
621	297472	SWITCH, Stop		Used After Code Date 85041500	
621	396847	SWITCH, Stop		Used After Code Date 85041400	
635	66538	BOOT, Spark Plug			

Ref #	Part #	Description	Qty	Context Note	Foot Note
657	93496	SCREW		(10-32 X 5/8)	
663	93572	SCREW		(10-32 X 3/8)	
665	296768	MINDER, Oil			
676A	395700	DEFLECTOR, Muffler		(Direct Outlet)	
676B	393758	DEFLECTOR, Muffler		(Louvered Outlet)	
676	393757	DEFLECTOR, Muffler		(Side Outlet)	
687	390690	SLIDE, Control			
688	221766	SPRING, Friction			
689	260847	SPRING, Friction			
690	92484	SCREW			
725	223540	SHIELD, Heat			
741	261195	GEAR, Timing		(Pin)	Both Guards Use: 93712 Screw (2)
757	212359	LINK, Counterweight			Both Guards Use: 93712 Screw (2)
758	390172	PIN, Counterweight			Both Guards Use: 93712 Screw (2)
759	298909	PIN, Piston			Both Guards Use: 93712 Screw (2)
761	93874	SCREW			Both Guards Use: 93712 Screw (2)
836	93559	SCREW		(Tank) (Fuel Tank)	Both Guards Use: 93712 Screw (2)
842	270920	SEAL, O-Ring		(Dipstick Tube) (Oil Fill)	Both Guards Use: 93712 Screw (2)
847	392066	DIPSTICK/TUBE ASSEMBLY			Both Guards Use: 93712 Screw (2)
869	211661	SEAT, Valve		(Exhaust)	Both Guards Use: 93712 Screw (2)
870	211661	SEAT, Valve		(Exhaust)	Both Guards Use: 93712 Screw (2)
871	231218	BUSHING, Valve Guide		(Intake)	Both Guards Use: 93712 Screw (2)
883	270918	GASKET, Exhaust			Both Guards Use: 93712 Screw (2)
985	398525	INSULATOR			Both Guards Use: 93712 Screw (2)
994	399541	ARRESTOR, Spark			
1019	491182	KIT, Label			
1020	261190	ECCENTRIC		Used After Code Date 85020100	
1021	94160	PIN, Retainer		Used After Code Date 85020100	




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
52	270824	GASKET, Intake			
94	292681	VALVE, Idle Mixture		Included in Carburetor Overhaul Kit-Part No. 394698	
95	93499	SCREW		(Throttle Valve)	
98	91920	SCREW		(8-32 X 5/8)	
99	26157	SPRING, Compression			
101	93043	PIN, Shaft			
104	230896	PIN, Float Hinge		Included in Carburetor Overhaul Kit-Part No. 394698	
108	222010	VALVE, Choke			
110	220899	WASHER		(Choke Lever)	
111	26229	SPRING, Choke Return			
112	23270	SCREW		(Choke Lever)	
118	391233	VALVE, Float Needle		Used After Code Date 83052000	
118	396568	VALVE, Float Needle		Used Before Code Date 83051900	Included in Carburetor Overhaul Kit-Part No. 394698
121	394698	KIT, Carburetor Overhaul			Included in Carburetor Overhaul Kit-Part No. 394698
123	93357	SCREW			Included in Carburetor Overhaul Kit-Part No. 394698
125	390811	CARBURETOR		(Choke-A-Matic)	Included in Carburetor Overhaul Kit-Part No. 394698
126	299851	BODY, Lower Carburetor			Included in Carburetor Overhaul Kit-Part No. 394698
127	221997	PLUG, Welch		Included in Carburetor Overhaul Kit-Part No. 394698	Included in Carburetor Overhaul Kit-Part No. 394698
128	211682	VENTURI, Carburetor			Included in Carburetor Overhaul Kit-Part No. 394698

Ref #	Part #	Description	Qty	Context Note	Foot Note
130	221986	VALVE, Throttle			Included in Carburetor Overhaul Kit-Part No. 394698
131	391512	SHAFT, Throttle		Used Before Code Date 86071700	
131	490017	SHAFT, Throttle			
132	211712	STOP, Throttle			
133	299707	FLOAT, Carburetor			
134	394681	KIT, Needle/Seat		(Gravity Feed) Included in Carburetor Overhaul Kit-Part No. 394698. Order No. 394683 for Fuel Pump Applications.	
136	221995	BOWL, Float			
137	270511	GASKET, Float Bowl		Included in Carburetor Overhaul Kit-Part No. 394698	
138	222014	WASHER		(Float Bowl) Included in Carburetor Overhaul Kit-Part No. 394698	
141A	299647	SHAFT, Choke			
141	390684	SHAFT, Choke		(Choke-A-Matic)	
142	299740	NOZZLE, Carburetor		Included in Carburetor Overhaul Kit-Part No. 394698	
147	230932	SCREW		(Nozzle) Used Before Code Date 83052000	
147	231323	SCREW		(Nozzle) Used After Code Date 83051900	Included in Carburetor Overhaul Kit-Part No. 394698
169	90832	SCREW		(Blower Housing)	Included in Carburetor Overhaul Kit-Part No. 394698
180	390225	TANK, Fuel		(3 Quart) (Plastic)	Included in Carburetor Overhaul Kit-Part No. 394698
181A	392300	CAP, Fuel Tank		(Metal) (1 9/16 I.D.) Used After Code Date 85120100	
181	397975	CAP, Fuel Tank		(Plastic) (2 1/4 I.D.) Used After Code Date 85113100	
182A	222112	BRACKET, Fuel Tank		(L.H.)	
182	222813	BRACKET, Fuel Tank		(R.H.)	
183A	390405	STRAP, Fuel Tank		(L.H.)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
183	390406	STRAP, Fuel Tank		(R.H.)	
184	93803	SCREW			
185	90970	NUT		(1/4-20)	
186	67218	CONNECTOR, Hose			
187	296004	LINE, Fuel		(Cut To Required Length)	
187	393815	HOSE, Vacuum		(Cylinder To Impulse Pump)(Cut To Required Length)	
188	93535	SCREW		(5/16-18 X 3/4)	
198	293934	VALVE, Fuel Shut Off			
199	390303	OUTLET, Tank			
216	261117	LINK, Choke		Used Before Code Date 82121010	
216	261612	LINK, Choke		Used After Code Date 82121110	
224	94018	SCREW			
240	298090	FILTER, Fuel			
240	394358	FILTER, Fuel		(Fuel Pump)	
244	230318	CONNECTOR, Hose			
268	65616	CASING, Control Wire		(Cut To Required Length)	
269	26633	WIRE, Control		(Cut To Required Length) If longer wire is required, specify length in inches; if shorter wire is needed, Order No. 26633 and cut to required length	
270	63426	NUT		(Control Wire Casing)	
271	290568	LEVER, Control			
367	93380	SCREW			
387	390818	PUMP, Fuel		Order No. 394462 for Pump Repair Kit	
445	393406	FILTER, A/C Cartridge			
527	221428	CLAMP, Tube			
528	394045	HOSE, Vacuum			
534A	93323	SCREW			
534B	93913	SCREW			
534C	93881	SCREW		(Air Cleaner)	
534	93622	SCREW			
535	270528	FILTER, A/C Cartridge			
536A	393481	CLEANER, Air			
536	391399	CLEANER, Air		Uses: 280111 Support-Air Cleaner Element (Plastic)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
537	270539	GASKET, Air Cleaner		(Air Cleaner)	
549	270978	WASHER		(Below Internal Screw Head)	
601	93053	CLAMP, Hose		(Green)	
618	261116	SPRING, Choke Return			
634A	271013	WASHER, Sealing		(Foam) Used Before Code Date 86071700	
634	270382	WASHER		(Foam)	
643	222149	CUP, Air Cleaner			
662	222027	BRACKET, Support			
663	93572	SCREW		(10-32 X 3/8)	
670	22963	WASHER			
683	93572	SCREW		(10-32 X 3/8)	
725A	222175	SHIELD, Heat			
861	394462	KIT, Fuel Pump		(Use With Pump 390818 Only)	Both Guards Use: 93712 Screw (2)
872	222897	COVER, Air Cleaner			Both Guards Use: 93712 Screw (2)
873	271171	GASKET, Air Cleaner			Both Guards Use: 93712 Screw (2)
874	222898	RETAINER, Air Filter			Both Guards Use: 93712 Screw (2)
875	393828	BASE, Air Cleaner			Both Guards Use: 93712 Screw (2)
917	223271	VALVE, Handle Shutoff			Both Guards Use: 93712 Screw (2)
952	222495	SPACER, Air Cleaner			Both Guards Use: 93712 Screw (2)
953	222022	SCREEN, Air Cleaner			Both Guards Use: 93712 Screw (2)
987	398970	SEAL, Throttle Shaft		(Lmt 46, 49, 50, 51, 53, 86) Used After Code Date 86071600	



Reference Number		309	310	311	510	510A	544	801	802	803
Manufacturer		Motor and Control Ass'y.	Thru Bolt Assembly	Brush Assembly	Drive Assembly	Drive Assembly	Armature Assembly	Drive End Cap Assembly	End Cap Ass'y. Commutator	Housing Assembly
Briggs & Stratton	Housing Length									
12V	3-21/32"	394805	94003	395538	396865**	-	390837	394857	395537*	393825
120V	3-1/2"	393851	94004	393612	-	391461***	393607	394398	393833*	393433

*Includes Brush Set

**Includes #391135 Clutch Assembly (Ref. No. 513)
#280104 Gear (Ref. No. 783)
#393254 Retainer and Pin (Ref. No. 773)
93754 Roll Pin (Ref. No. 896)

***Includes #391135 Clutch Assembly (Ref. No. 513)
#280104 Gear (Ref. No. 783)
#393254 Retainer and Pin (Ref. No. 876)
93754 Roll Pin (Ref. No. 896)

Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
309	393851	MOTOR, Starter		(3 1/2 Housing) (Briggs & Stratton 110V)	
309	394805	MOTOR, Starter		(3 1/16 Housing)	
310	94003	SCREW		(3 5/8 Housing)	
310	94004	SCREW		(4 3/8 Housing)	
311	393612	SET, Brush		(3 1/2 Housing) (110V)	
311	395538	SET, Brush		(3-5/8 or 4 3/8 Housing)	
510A	391461	DRIVE, Starter		(3 1/2 Housing) Includes #391135 Clutch Assembly (Ref. No. 513) #280104 Gear (Ref. No. 783) #393254 Retainer and Pin (Ref. No. 876) #93754 Roll Pin (Ref. No. 896)	
510	396865	DRIVE, Starter		(3 21/32 Housing) Includes #391135 Clutch Assembly (Ref. No. 513) #280104 Gear (Ref. No. 783) #393254 Retainer and Pin (Ref. No. 773) #93754 Roll Pin (Ref. No. 896)	
544	390837	ARMATURE, Starter		(3 5/8 Housing)	
544	393607	ARMATURE, Starter		(3 1/2 Housing) (110V)	
801	394398	CAP, Drive		(3 1/2 Housing)	Both Guards Use: 93712 Screw (2)
801	394857	CAP, Drive		(3-21/32 or 4 9/16 Housing)	Both Guards Use: 93712 Screw (2)
802	393833	CAP, End		(3 1/2 Housing) (Briggs & Stratton 110V) Includes Brush Set	Both Guards Use: 93712 Screw (2)
802	395537	CAP, End		(3 5/8 Housing) Includes Brush Set	Both Guards Use: 93712 Screw (2)
803	393433	HOUSING, Starter		(3 1/2 Housing) (Briggs & Stratton 110V)	Both Guards Use: 93712 Screw (2)
803	393825	HOUSING, Starter		(3 5/8 Housing)	Both Guards Use: 93712 Screw (2)