





Ref #	Part #	Description	Qty	Context Note	Foot Note
15A	691682	PLUG-OIL DRAIN			
83	690387	SHAFT, Auxiliary Drive			
84	691121	PLUG-BREATHER			
85	691076	SCREW		(Gear Cover to Gear Reduction Case)	
87	391086S	SEAL, Oil			
272	691168	LOCK, Screw Head			
277	691075	WASHER		(Gear Case To Gear Reduction)	
309	695479	MOTOR, Starter			
310	690323	SCREW		(Starter Motor)	
415B	690283	PLUG, Oil		(1/8 Standard)	
503	691532	STRAP, Starter			
510	693699	DRIVE, Starter			
513	692024	CLUTCH, Drive			
544	692034	ARMATURE, Starter		(3 5/8 Housing)	
579		NUT		(Starter Cable)	
783	693713	GEAR, Pinion			
801	694482	CAP-DRIVE			
802	691286	CAP, End			
803		Housing-Starter		(Not Serviced Separately, Order Starter Motor 695479)	
1051	691265	RING, Retaining			
1090	691293	RETAINER, Brush			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
3	391086S	SEAL, Oil		(Magneto Side)	
5	793009	HEAD, Cylinder			
7	694872	GASKET, Cylinder Head			
12	694953	GASKET, Crankcase			
13	690360	SCREW		(Cylinder Head)	
20	391086S	SEAL, Oil		(PTO Side)	
33	499596	VALVE, Exhaust			
34	792200	VALVE, Intake			
35	694865	SPRING, Valve		(Intake)	
36	694865	SPRING, Valve		(Exhaust)	
42	499586	KEEPER, Valve			
45	690977	TAPPET, Valve			
51	694874	GASKET, Intake			
51A	694875	GASKET, Intake			
163	692277	GASKET, Air Cleaner		(Air Cleaner)	
176	691917	SEAL, O-Ring		(Air Cleaner Base)	
192	690083	ADJUSTER, Rocker Arm			
337	491055S	PLUG, Spark			
337	84007216	PLUG, SPARK		(China Only)	
358	695438	GASKET SET, Engine			
383	19374S	WRENCH, Spark Plug			
635	691909	BOOT, Spark Plug			
798	697890	SCREW		(Rocker Arm)	
868	690968	SEAL, Valve			
883	695398	GASKET, Exhaust		Used Before Code Date 02012000	
883A	697255	GASKET, Exhaust		Used After Code Date 02011900	
914	693732	SCREW		(Rocker Cover)	
1022	690971	GASKET, Rocker Cover			
1023	697691	COVER, Rocker			
1026	695177	ROD, Push			
1029	690972	ARM, Rocker			
1095	695440	GASKET SET, Valve			
1100	791959	PIVOT, Rocker Arm			
1171	696754	STUD		(Rocker Cover)	




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
187	791766	LINE, Fuel		(15" Long)(Cut to Required Length)	
187A	695429	LINE, Fuel		Used Before Code Date 05070100	
187A	791869	LINE, Fuel		Used After Code Date 05063000	
187C	791871	LINE, Fuel		Used After Code Date 05063000	
187D	791879	LINE, Fuel		Used After Code Date 05063000	
187B	695482	LINE, Fuel		Used Before Code Date 05070100	
187C	695483	LINE, Fuel		Used Before Code Date 05070100	
187D	698080	LINE, Fuel		Used Before Code Date 05070100	
187B	791834	LINE, Fuel		Used After Code Date 05063000	
188	690877	SCREW		(Control Bracket)	
190	692127	SCREW		(Fuel Tank)	
209	694867	SPRING, Governor			
211	695307	SPRING, Governed Idle			
222	695380	BRACKET, Control			
222B	791753	BRACKET, Control			
227	694864	LEVER, Governor Control			
240	394358S	FILTER, Fuel			
240A	694485	FILTER, Fuel			
265	691024	CLAMP, Casing			
267	692577	SCREW		(Casing Clamp)	
268	691025	CASING, Control Wire		(Cut To Required Length)	
269	691026	WIRE, Control		(Cut To Required Length)	
270	691027	NUT		(Control Wire Casing)	
271	691028	LEVER, Control			
271A	695381	LEVER, Control			
278	792008	WASHER		(Governor Lever)	
281	697268	PANEL, Control		Used After Code Date 01102800	
281	695294	PANEL, Control		Used Before Code Date 01102900	
410	695382	LINK, Control			
493B	699973	BRACKET, Mounting			
504	695383	SET, Friction Washer			
505	691251	NUT		(Governor Control Lever)	
562	793216	BOLT		(Governor Lever)	
564	692577	SCREW		(Control Cover)	
564A	692198	SCREW		(Control Cover)	
601	791850	CLAMP, Hose			


Ref #	Part #	Description	Qty	Context Note	Foot Note
604	697326	COVER-CONTROL			
604A	791752	COVER, Control			
615	694676	RETAINER, Governor Shaft			
616	694675	CRANK, Governor			
621	692310	SWITCH, Stop			
632	695917	SPRING/LINK, Mechanical Governor		(Use With Nikki Carburetor)	
632	694868	SPRING/LINK, Mechanical Governor		(Used With Walbro Carburetors)	
663	692577	SCREW		(Control Panel)	
668	694257	SPACER		(Control Bracket)	
773	694258	RETAINER			
843	695588	SLEEVE, Lever			
957	792647	CAP, Fuel Tank		(Plastic)	
958	698180	VALVE, Fuel Shutoff		(Plastic)	
972A	694260	TANK, Fuel		(Plastic)	
1138	694255	NUT		(Control Bracket)	
1230	791754	STUD		(Control Bracket)	
1404	696757	LOCKNUT		(Control Cover)	

GHOSTED PARTS ARE NOT SERVICEABLE
AND ARE SHOWN FOR REFERENCE ONLY.






WALBRO CARBURETOR

977 CARBURETOR GASKET SET





121 CARBURETOR OVERHAUL KIT



NIKKI CARBURETOR


121A CARBURETOR OVERHAUL KIT



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
51	694874	GASKET, Intake			
51A	694875	GASKET, Intake			
93	690602	BUSHING, Throttle Shaft			
95	691636	SCREW		(Throttle Valve)	
95A	690718	SCREW		(Throttle Valve)	
97	695325	SHAFT, Throttle			
97A	696387	SHAFT, Throttle			
98	495800	KIT, Idle Speed		(Idle Speed) (Lmt 54, 55, 91)	
98A	695408	KIT, Idle Speed			
104	690525	PIN, Float Hinge			
104A	694918	PIN, Float Hinge			
105	691782	VALVE, Float Needle			
105A	696136	VALVE, Float Needle			
106	690577	SEAT, Inlet			
108A	696143	VALVE, Choke			
108B	696209	VALVE, Choke			
109C	790148	SHAFT, Choke			
117	696134	JET, Main		(Standard)	
118	696135	JET, Main		(High Altitude)	
121	695441	KIT, Carburetor Overhaul		(Use With Walbro Carburetor)	
121A	696146	KIT, Carburetor Overhaul		(Nikki Carburetor)	
122	694876	SPACER, Carburetor			
125A	695920	CARBURETOR			
127	694524	PLUG, Welch			
127A	690727	PLUG, Welch			
130	690468	VALVE, Throttle			
130A	696139	VALVE, Throttle			
133	494381	FLOAT, Carburetor			
133A	694914	FLOAT, Carburetor			
135	696142	TUBE, Fuel Transfer			
137	281165S	GASKET, Float Bowl			
137A	695426	GASKET, Float Bowl			
141B	696144	KIT, Choke Shaft			
142	695528	NOZZLE, Carburetor		(Standard)	
143	695529	NOZZLE, Carburetor		(High Altitude)	
163	692277	GASKET, Air Cleaner		(Air Cleaner)	
176	691917	SEAL, O-Ring		(Air Cleaner Base)	
186	692317	CONNECTOR-HOSE			
231	691636	SCREW		(Choke Valve)	
231A	690718	SCREW		(Choke Valve)	
276	692255	WASHER, Sealing			


Ref #	Part #	Description	Qty	Context Note	Foot Note
369	695422	SPRING, Float Bowl			
632	694868	SPRING/LINK, Mechanical Governor		(Used With Walbro Carburetors)	
632	695917	SPRING/LINK, Mechanical Governor		(Use With Nikki Carburetor)	
633	690597	SEAL, Choke/Throttle Shaft			
633A	691326	SEAL, Choke/Throttle Shaft			
633B	690998	SEAL, Choke/Throttle Shaft			
692	691301	SPRING, Detent			
950	691657	SCREW		(Float Bowl)	
951	699961	LEVER, Choke			
955	695659	PLUG, Carburetor			
975	495933	BOWL, Float		(Float Bowl)	
975A	696138	BOWL, Float			
977	695439	SET, Carburetor Gasket		(Used With Walbro Carburetors)	
1127A	695407	SCREW		(Float Bowl) (Float Bowl to Carburetor Body)	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
1	793117	CYLINDER ASSEMBLY			
2	698340	KIT, Bushing/Seal		(Magneto Side)	
3	391086S	SEAL, Oil		(Magneto Side)	
12	694953	GASKET, Crankcase			
15	691686	PLUG-OIL DRAIN			
16	794716	CRANKSHAFT			
17	695434	BEARING, Ball			
18	791965	COVER, Crankcase			
19	698340	KIT, Bushing/Seal		(PTO Side)	
20	391086S	SEAL, Oil		(PTO Side)	
21	281658S	CAP, Oil Fill			
22	695174	SCREW		(Crankcase Cover/Sump)	
24	222698S	KEY, Flywheel			
25	792144	PISTON ASSEMBLY		(.020 Oversize)	
25	792117	PISTON ASSEMBLY		(Standard)	
26	792026	SET, Ring		(Standard) Used After Code Date 05101100	
26	792073	SET, Ring		(.020 Oversize) Used After Code Date 05101100	
26	694004	SET, Ring		(Standard) Used Before Code Date 05101200	
26	694008	SET, Ring		(.020 Oversize) Used Before Code Date 05101200	
27	690975	LOCK, Piston Pin			
28	696581	PIN, Piston		(Standard)	
29	694691	ROD, Connecting			
30	694692	DIPPER, Connecting Rod			
32	690976	SCREW		(Connecting Rod)	
46	790958	CAMSHAFT			
146	690979	KEY, Woodruff			
170	695296	STUD		(Crankcase Cover/Sump)	
219	693578	GEAR, Governor			
220	691724	WASHER		(Governor Gear)	
287	691693	SCREW		(Dipstick Tube)	
306	694677	SHIELD, Cylinder		Used Before Code Date 01102900	
306	697240	SHIELD, Cylinder		Used After Code Date 01102800	
307	691660	SCREW		(Cylinder Shield)	
415	691363	PLUG			
523	695344	DIPSTICK			
524	691876	SEAL, O-Ring			
525	695343	TUBE, Dipstick			
529	791822	GROMMET			


Ref #	Part #	Description	Qty	Context Note	Foot Note
552	694674	BUSHING, Governor Crank			
718	690959	PIN, Locating			
718A	695178	PIN, Locating		(Head)	
741	691288	GEAR, Timing			
742	692564	RETAINER, E Ring			
746	694679	GEAR, Idler			
842	691031	SEAL, O-Ring		(Dipstick Tube)	
847	695342	DIPSTICK/TUBE ASSEMBLY			
1058	277040	MANUAL, Operator's			
1194	691876	SEAL, O-Ring		(Plug)	
1319	794467	LABEL, Warning			



Ref #	Part #	Description	Qty	Context Note	Foot Note
23	794814	FLYWHEEL			
37	790730	GUARD, Flywheel			
55	695288	HOUSING-REWIND STR			
55A	691421	HOUSING, Rewind Starter			
58	693389	ROPE, Starter		(Cut To Required Length)	
59	805957	INSERT, Grip			
60	490652	GRIP-STARTER ROPE			
65	690837	SCREW		(Rewind Starter)	
78	690372	SCREW		(Flywheel Guard)	
298	698838	LOCKNUT		(Muffler and Elbow)	
304	791478	HOUSING, Blower			
305	691108	SCREW		(Blower Housing)	
332	694685	NUT		(Flywheel)	
363	19203	PULLER, Flywheel			
455	694683	CUP, Flywheel			
456	692299	PLATE-PAWL FRICTION			
459	281505S	PAWL-RATCHET			
592	690800	NUT		(Rewind Starter)	
597	691696	SCREW		(Pawl Friction Plate)	
608	695287	STARTER-REWIND			
608A	497680	STARTER, Rewind			
622	698839	WASHER		(Heat Shield)	
689	691855	SPRING-FRICTION			
695	698807	SCREW		(Ring Gear)	
725A	792995	SHIELD, Heat			
727A	697465	COVER, Starter Drive			
728	696763	SCREW		(Heat Shield)	
732	691097	SCREW		(Starter Drive Cover)	
934	710550	SCREW		(Fan Retainer)	
1005	694684	FAN, Flywheel			
1036		Label-Emissions		(Available From A Briggs & Stratton Authorized Dealer)	
1070	691058	SCREW		(Flywheel Fan)	
1210	498144	PULLEY/SPRING ASSY		(Pulley)	
1211	498144	PULLEY/SPRING ASSY		(Spring)	
1212	792614	STUD		(Blower Housing)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
1298	696757	LOCKNUT		(Shield-Heat)	


DC ONLY	10 - 16 AMP
474A 	474D
578 	578
<p>NOTE: All stators use a No. 1119 mounting screw.</p> <p>NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.</p>	
	526 501



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
333	492341	ARMATURE, Magneto			
334	691061	SCREW		(Magneto Armature)	
347A	697854	SWITCH, Rocker			
347B	790949	SWITCH, Rocker			
356	692603	WIRE, Stop			
356A	692390	WIRE, Stop			
356J	699994	WIRE, Stop			
356L	792609	WIRE, Stop			
356C	695295	WIRE, Stop			
356D	695366	WIRE, Stop			
356E	696328	WIRE, Stop			
356H	696482	WIRE, Stop			
356K	697397	WIRE, Stop		(1 Wire, 13-5/8)(Snap Connect Insulated Female Blade Terminal,And Snap Connect Insulated Pin Socket)	
356B	699340	WIRE, Stop			
361	691681	SCREW		(Starting Switch)	
361A	690297	SCREW		(Starting Switch)	
364A	699947	TERMINAL, Oil Plug			
474A	695730	ALTERNATOR		(3 Amps DC)	
474D	695466	ALTERNATOR		(10 Amp Regulated)	
493	694861	BRACKET, Mounting		(Oil Sensor)	
493A	691177	BRACKET, Mounting			
500	691086	WASHER		(Key Switch)	
500A	792613	WASHER		(Key Switch)	
501	691185	REGULATOR		(16 Amp Regulated)	
503	691532	STRAP, Starter			
526	690297	SCREW		(Regulator)	
577	690630	CABLE, Starter			
577A	690795	CABLE, Starter			
578A	790948	WIRE ASSEMBLY			
579		NUT		(Starter Cable)	
627	696064	BRACKET, Stopswitch			
627A	792608	BRACKET, Stopswitch			
636	696198	NUT		(Starting Switch)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
641	690282	WASHER		(Starting Switch)	
664	691087	NUT		(Key Switch)	
697	690372	SCREW		(Drive Cap)	
774	695447	SCREW		(Stop Wire)	
799	690297	SCREW		(Oil Sensor)	
799	695446	SCREW		(Oil Sensor) (Shoulder Screw)	
813	690635	CLAMP			
851	692424	TERMINAL, Spark Plug			
892	392833	SWITCH, Key			
892A	791944	SWITCH, Key			
920	691656	SOLENOID, Starter			
990	691959	SET, Key			
1052A	791159	SENSOR, Oil			
1119	691183	SCREW		(Alternator)	



Ref #	Part #	Description	Qty	Context Note	Foot Note
11A	695305	TUBE, Breather			
53	694869	STUD		(Carburetor)	
53A	695433	STUD		(Carburetor)	
81	695400	LOCK, Muffler Screw			
161	695384	BASE, Air Cleaner		(Metal)	
163	692277	GASKET, Air Cleaner		(Air Cleaner)	
176	691917	SEAL, O-Ring		(Air Cleaner Base)	
185	690958	NUT		(Air Cleaner Base)	
300	697252	MUFFLER			
300C	793701	MUFFLER			
346	690661	SCREW		(Spark Arrestor)	
355	691075	WASHER		(Muffler Bracket)	
412	690958	NUT		(Air Cleaner Cover)	
425	694515	SCREW		(Air Cleaner Cover)	
425A	790043	SCREW		(Air Cleaner Cover)	
436C	792374	MANIFOLD, Exhaust			
437	696705	SCREW		(Exhaust Manifold)	
445A	695302	FILTER, A/C Cartridge			
467	691668	KNOB, Air Cleaner Cover			
613	695312	SCREW		(Muffler)	
613A	695399	SCREW		(Muffler)	
676	393761	DEFLECTOR, Muffler		(Side Outlet)	
677	690661	SCREW		(Muffler Deflector)	
740	710090	LOCKNUT		(Muffler Bracket)	
740A	793859	NUT		(Muffler Bracket)	
819	690352	SCREW		(Muffler Bracket)	
832	795035	GUARD, Muffler			
832C	792380	MUFFLER			
836	690367	SCREW		(Muffler Guard) Used Before Code Date 01061100	
836	695312	SCREW		(Muffler Guard) Used After Code Date 01061000	
836C	710023	SCREW		(Muffler Guard)	
863C	793700	BRACKET, Muffler			
875	695304	BASE, Air Cleaner		(Plastic)	
883	695398	GASKET, Exhaust		Used Before Code Date 02012000	
883A	697255	GASKET, Exhaust		Used After Code Date 02011900	
883C	710250	GASKET, Exhaust			
967A	695303	FILTER, Pre Cleaner			
968B	695301	COVER, Air Cleaner			

Ref #	Part #	Description	Qty	Context Note	Foot Note
971	695181	SCREW		(Air Cleaner Base) (Remote Choke)	
1177	710090	LOCKNUT		(Muffler)	