





Copyright © Briggs & Stratton, LLC. All rights reserved.




Ref #	Part #	Description	Qty	Context Note	Foot Note
23B	591760	FLYWHEEL			
24	591757	KEY, Flywheel			
37	697352	GUARD, Flywheel			
37A	697626	GUARD, Flywheel			
56	695129	PULLEY, Starter			
57	695131	SPRING, Rewind Starter			
58	695132	ROPE, Starter			
60	490652	GRIP-STARTER ROPE			
65	690940	SCREW		(Rewind Starter)	
78	691693	SCREW		(Flywheel Guard)	
78A	690364	SCREW		(Flywheel Guard)	
309	593934	MOTOR, Starter			
310	690323	SCREW		(Starter Motor)	
324	593933	SCREEN/CUP ASSEMBLY			
363	19203	PULLER, Flywheel			
415A	794129	COVER, Flywheel		(Cover/Retainer)	
455A	796615	CUP, Flywheel		(Non Washable)	
456	695128	PLATE, Pawl Friction			
459	281505S	PAWL-RATCHET			
462	691261	WASHER		(Starter Cable)	
503	691532	STRAP-STARTER			
510	693699	DRIVE, Starter			
513	692024	CLUTCH-DRIVE			
563A	799359	SCREW		(Debris Screen Guard)	
579	691029	NUT		(Starter Cable)	
597	691696	SCREW		(Pawl Friction Plate)	
608A	591606	STARTER, Rewind			
689	691855	SPRING-FRICTION			
697	791680	SCREW		(Starter Motor) (Drive Cap)	
729A	691224	CLIP, Wire		(Starter Motor)	
783	593935	GEAR, Pinion			
797	693167	NUT		(Brush Retainer)	
801	691283	CAP-DRIVE			
802	691286	CAP-END			
949A	799358	GUARD, Debris Screen			
1005	796082	FAN, Flywheel			
1044	698139	SCREW		(Flywheel)	
1051	691265	RING, Retaining			
1090	691293	RETAINER-BRUSH			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
1	697377	CYLINDER ASSEMBLY			
2	797673	KIT-BUSHING/SEAL		(Magneto Side)	
3	391086S	SEAL, Oil		(Magneto Side)	
4A	592849	SUMP, Engine			
11	794683	TUBE, Breather			
12	697110	GASKET, Crankcase		(.015" Thick)(Standard)	
15	690946	PLUG-OIL DRAIN		(3/8" Standard)	
20	795387	SEAL-OIL		(PTO Side)	
22	692125	SCREW		(Crankcase Cover/Sump)	
37A	697626	GUARD, Flywheel			
43	691968	SLINGER, Governor/Oil			
78A	690364	SCREW		(Flywheel Guard)	
186A	796532	CONNECTOR, Hose			
239	491657S	SWITCH, Oil Pressure			
306	592778	SHIELD, Cylinder			
307	691693	SCREW		(Cylinder Shield)	
415	794903	PLUG		(TEMP/MAP Sensor) (Intake Manifold)	
512	594200	HOSE, Oil Drain			
523	699908	DIPSTICK			
524	691032	SEAL, O-Ring			
525	697085	TUBE, Dipstick		(With Side Tube Connector)	
525A	697184	TUBE, Dipstick		(Standard Dipstick Tube)	
552	697144	BUSHING, Governor Crank			
584	794682	COVER, Breather Passage		(Use with Liquid Sealant Reference 850)	
598	799739	SHIM, End Play		(Crankshaft or Camshaft Bearing)	
684	697157	SCREW		(Breather Passage Cover)	
691	692407	SEAL-GOVERNOR SHAFT			
718	690959	PIN, Locating			
750	790832	SCREW		(Oil Pump Cover)	
842	691031	SEAL, O-Ring		(Dipstick Tube)	
847	790443	DIPSTICK/TUBE ASSEMBLY		(With Side Tube Connector)	
847A	790442	DIPSTICK/TUBE ASSEMBLY		(Standard Dipstick Tube)	
850	100106	SEALANT, Liquid		(Rocker Cover Gasket and Breather Gasket)	
943	690589	SEAL, O-Ring		(Oil Pump Cover)	
965	499613	COVER, Oil Pump			
1017	796981	SCREEN, Oil Pump			


Ref #	Part #	Description	Qty	Context Note	Foot Note
1024A	794644	PUMP-OIL			
1027	798576	FILTER, Oil		(Premium)(Orange)	
1027	492932S	FILTER, Oil		(Standard)(Black)	
1036		Label-Emissions		(Available From A Briggs & Stratton Authorized Dealer)	
1263	697124	REED, Breather			
1264	697104	SCREW		(Breather Reed)	
1319	794467	LABEL, Warning			
1319A	797669	LABEL, Warning		(International)	



Copyright © Briggs & Stratton, LLC. All rights reserved.





Ref #	Part #	Description	Qty	Context Note	Foot Note
3	391086S	SEAL, Oil		(Magneto Side)	
5	796183	HEAD, Cylinder			
7	273280S	GASKET, Cylinder Head			
12	697110	GASKET, Crankcase		(.015" Thick)(Standard)	
13	690360	SCREW		(Cylinder Head)	
20	795387	SEAL-OIL		(PTO Side)	
33	792868	VALVE, Exhaust		(Chrome)	
34	791935	VALVE, Intake			
35	691279	SPRING, Valve		(Intake)	
36	691279	SPRING, Valve		(Exhaust)	
42	499586	KEEPER, Valve			
45	690564	TAPPET, Valve			
50	592845	MANIFOLD, Intake			
51	692137	GASKET-INTAKE			
51A	796081	GASKET, Intake			
53	591260	STUD		(Carburetor)	
54	691148	SCREW		(Intake Manifold)	
186	794873	CONNECTOR, Hose		(TEMP/MAP Sensor) (Intake Manifold)	
192	691986	ADJUSTER, ROCKER ARM			
238	691843	CAP, Valve			
337	792015	PLUG, Spark		(Resistor EMS)	
337	491055S	PLUG-SPARK		(Resistor)	
337	691043	PLUG, Spark		(EMS)	
358	796181	GASKET SET, Engine			
383	19576S	WRENCH, Spark Plug			
415	794903	PLUG		(TEMP/MAP Sensor) (Intake Manifold)	
524	691032	SEAL, O-Ring			
617	692138	SEAL, O-Ring		(Intake Manifold) (TEMP/MAP Sensor) (Intake Manifold)	
635	691909	BOOT, Spark Plug			
654	690958	NUT		(Carburetor)	
691	692407	SEAL-GOVERNOR SHAFT			
830	691095	STUD-ROCKER ARM			
842	691031	SEAL, O-Ring		(Dipstick Tube)	
850	100106	SEALANT, Liquid		(Rocker Cover Gasket and Breather Gasket)	
868	690968	SEAL, Valve			
883	692236	GASKET-EXHAUST			
914	691108	SCREW		(Rocker Cover)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
1022	272475S	GASKET, Rocker Cover			
1023	797421	COVER-ROCKER			
1026	794573	ROD, Push		(Exhaust)	
1026	697394	ROD, Push		(Intake)	
1029	691751	ARM, Rocker			
1034	690822	GUIDE, Push Rod			
1095	796189	GASKET SET, Valve			
1266	691917	SEAL, O-Ring		(Intake Elbow)	



121B CARBURETOR OVERALL KIT - RUIXING					
51	104B	137B	217B	98B	105B
276B	633C	633D	633E		



Ref #	Part #	Description	Qty	Context Note	Foot Note
51	692137	GASKET-INTAKE			
95B	593897	SCREW		(Throttle Valve) (Ruixing)	
98B	846817	KIT, Idle Speed		(Ruixing)	
104B	594860	PIN, Float Hinge		(Ruixing)	
105B	594868	VALVE, Float Needle		(Ruixing)	
108B	594863	VALVE, Choke		(Ruixing)	
117B	594871	JET, Main		(Standard) (Ruixing)	
118B	595069	JET, Main		(High Altitude) (Ruixing)	
121B	594886	KIT, Carburetor Overhaul		(Ruixing)	
130B	594858	VALVE, Throttle		(Ruixing)	
131B	594856	KIT, Throttle Shaft		(Ruixing)	
133B	594859	FLOAT, Carburetor		(Ruixing)	
137B	594861	GASKET, Float Bowl		(Ruixing)	
141B	594862	KIT, Choke Shaft		(Ruixing)	
147B	594872	JET, Pilot		(Ruixing)	
217B	594864	SPRING, Choke Return		(Ruixing)	
276B	846640	WASHER, Sealing		(Ruixing)	
633C	594866	SEAL, Choke/Throttle Shaft		(Ruixing)	
633D	594865	SEAL, Choke/Throttle Shaft		(Ruixing)	
633E	797629	SEAL, Choke/Throttle Shaft		(Ruixing)	
947B	846639	SOLENOID, Fuel		(Ruixing)	
975B	594867	BOWL, Float		(Ruixing)	



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
51	692137	GASKET-INTAKE			
51A	796081	GASKET, Intake			
94A	793610	KIT, Idle Mixture		(Nikki)	
95A	690718	SCREW		(Throttle Valve) (Nikki)	
98A	695408	KIT, Idle Speed		(Nikki)	
104A	694918	PIN-FLOAT HINGE		(Nikki)	
105A	696136	VALVE, Float Needle		(Nikki)	
108A	698773	VALVE, Choke		(Nikki)	
112	593040	SCREW		(Choke Lever) (Ready Start System)	
117	591936	JET, Main		(Standard) (Standard)	
118	696134	JET-MAIN		(High Altitude) (5000 Feet)	
121A	796184	KIT, Carburetor Overhaul		(Nikki)	
125A	593432	CARBURETOR		(Nikki Without Solenoid)	
127A	690727	PLUG, Welch		(Nikki)	
130A	698774	VALVE, Throttle		(Nikki)	
131A	698776	KIT, Throttle Shaft		(Nikki)	
133A	694914	FLOAT, Carburetor		(Nikki)	
135A	796400	TUBE, Fuel Transfer			
137A	698781	GASKET, Float Bowl		(Nikki)	
141A	698778	KIT, Choke Shaft		(Nikki)	
187	791766	LINE, Fuel		(15" Long)(Cut to Required Length)	
216B	593043	LINK, Choke		(Ready Start System)	
217	695409	SPRING, Choke Return			
226	793386	KIT, Choke Shaft		(Manual Choke)	
276A	695410	WASHER-SEALING			
318	594384	SCREW		(Mounting Bracket)	
422A	593056	SWITCH, Snap		(Ready Start System)	
617	692138	SEAL, O-Ring		(Intake Manifold) (TEMP/MAP Sensor) (Intake Manifold)	
633	699813	SEAL, Choke/Throttle Shaft		(Nikki)	
633B	690998	SEAL, Choke/Throttle Shaft		(Nikki)	
634A	698779	SPRING/SEAL ASSEMBLY		(Nikki)	
947C	596038	SOLENOID, Fuel			
951	593039	LEVER, Choke		(Ready Start System)	
975	698783	BOWL, Float		(Nikki Without Solenoid)	
975A	699502	BOWL, Float		(Nikki With Solenoid)	
1091	691333	CAP, Limiter			
1127	695407	SCREW		(Float Bowl) (Float Bowl to Carburetor Body)	
1146	793380	SCREW		(Choke Shaft) (Manual Choke)	
1266	691917	SEAL, O-Ring		(Intake Elbow)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
1478	593037	SOLENOID, Choke		(Ready Start System)	
1479	593041	SCREW		(Choke Solenoid) (Ready Start System)	
1479A	593042	SCREW		(Choke Solenoid) (Ready Start System)	



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
16	593417	CRANKSHAFT			
24	591757	KEY, Flywheel			
25	595053	PISTON ASSEMBLY		(Standard)	
25	595054	PISTON ASSEMBLY		(.020" Oversize)	
26	792643	SET, Ring		(.020 Oversize)	
26	797011	SET, Ring		(Standard)	
27	698469	LOCK-PISTON PIN			
28	797013	PIN, Piston			
29	791633	ROD, Connecting		(Standard)	
32	791118	SCREW		(Connecting Rod)	
43	691968	SLINGER, Governor/Oil			
45	690564	TAPPET, Valve			
46	793880	CAMSHAFT			
357	691483	KEY, Drive Pulley			
377	691639	KEY, Woodruff			
741	697128	GEAR, Timing			
757	793242	LINK, Counterweight			
758	593418	COUNTERWEIGHT			
759	697392	PIN, Counterweight			
1270	793243	PLUG, AVS Counterweight			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
188	691693	SCREW		(Control Bracket)	
202	691841	LINK, Mechanical Governor			
203	691381	CRANK, Bell			
209	792813	SPRING-GOVERNOR		(Brown)	
216	691840	LINK, Choke			
216A	691281	LINK, Choke			
222	694042	BRACKET, Control			
227	691374	LEVER, Governor Control			
232	691842	SPRING, Governor Link			
265	691024	CLAMP, Casing			
267	794904	SCREW		(Casing Clamp) (#10-32x.62)	
267	699891	SCREW		(Casing Clamp) (#8-32x.50)	
268	691025	CASING, Control Wire		(Cut To Required Length)	
269	691026	WIRE, Control		(Cut To Required Length)	
270	691027	NUT		(Control Wire Casing)	
271	691028	LEVER, Control			
333	799650	ARMATURE, Magneto		Used Before Code Date 16080900	
333A	594626	ARMATURE, Magneto		Used After Code Date 16080800	
334	691061	SCREW		(Magneto Armature)	
356	398808	WIRE-STOP		(Cut To Required Length)	
356A	697397	WIRE, Stop			
356B	697089	WIRE, Stop			
359	691077	WASHER		(Ground Terminal)	
373	845823	NUT		(Ground Terminal)	
404	691691	WASHER		(Governor Crank)	
474D	592830	ALTERNATOR		(10-16 Amp Regulated)	
501D	845907	REGULATOR			
505	691251	NUT		(Governor Control Lever)	
507	691972	INSULATOR			
520	691084	TERMINAL, Ground			
521	690581	SHIELD, Cable			
526	697088	SCREW		(Regulator)	
526B	697348	SCREW		(Regulator)	
559A	693675	SCREW		(Remote Choke Stop) (Length .419 Inches)	
562	691119	BOLT		(Governor Control Lever)	
578	692306	WIRE ASSEMBLY			
614	691620	PIN, Cotter			
616	692012	CRANK-GOVERNOR			
621	692310	SWITCH, Stop			
789	698329	HARNESS, Wiring			
789A	594433	HARNESS, Wiring			
851	692424	TERMINAL, Spark Plug			

Ref #	Part #	Description	Qty	Context Note	Foot Note
877	393456	WIRE/CONNECTOR, Alternator		(Dual Circuit)	
877D	790544	WIRE/CONNECTOR, Alternator			
878	398661	HARNESS, Wiring		(Dual Circuit)	
878A	691955	HARNESS, Alternator		(Tri Circuit)	
1059	698516	KIT, Screw/Washer			
1119	691183	SCREW		(Alternator)	
1448	690260	WASHER		(Magneto Armature)	



Ref #	Part #	Description	Qty	Context Note	Foot Note
14	790560	STUD		(Cylinder Head)	
81	691178	LOCK-MUFFLER SCREW			
187	791766	LINE, Fuel		(15" Long)(Cut to Required Length)	
187A	796491	LINE, Fuel		(Formed)(Cut To Required Length)	
187D	791744	LINE-FUEL		(Formed)(Cut To Required Length)	
187B	791805	LINE, Fuel		(Formed)(Cut To Required Length)	
190	796174	SCREW		(Fuel Tank)	
240	394358S	FILTER-FUEL		(White, 75 Microns)	
240A	84001895	FILTER, FUEL			
300A	796000	MUFFLER			
300B	795997	MUFFLER			
304G	591641	HOUSING, Blower		(Black-Compatible With Canister Style Filter)	
305	697102	SCREW		(Blower Housing)	
305B	795891	SCREW		(Blower Housing) (Blower Housing To Intake Elbow)	
305C	799370	SCREW		(Blower Housing) (Used On Grommet Style Blower Housings)	
346	794845	SCREW		(Spark Arrestor)	
387	808656	PUMP, Fuel			
431B	797901	ELBOW, Intake		(EVAP)	
445B	591583	FILTER, A/C Cartridge		(Canister)	
601	791850	CLAMP-HOSE		(Green)	
613	691416	SCREW		(Muffler)	
613A	691678	SCREW		(Muffler)	
613B	690297	SCREW		(Muffler)	
670	796175	SPACER, Fuel Tank			
676	795036	DEFLECTOR, Muffler			
676A	396903	DEFLECTOR, Muffler			
676B	795038	DEFLECTOR, Muffler			
677	690367	SCREW		(Muffler Deflector) (#8-18 x 0.563 lg)	
677	690661	SCREW		(Muffler Deflector) (#8-18 x 0.375 lg)	
705	790561	NUT		(Fuel Tank)	
773	796448	RETAINER			
823	698941	SCREW		(Muffler Adapter)	
832	790244	GUARD, Muffler			
832A	595029	GUARD, Muffler			
832B	706336	GUARD, Muffler			
836	690367	SCREW		(Muffler Guard)	
864	796002	ADAPTER, Muffler		(2 1/4" Long)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
883	692236	GASKET- EXHAUST			
957	795027	CAP, Fuel Tank		(Standard)	
957A	799719	CAP, Fuel Tank		(Carbon In Cap)	
958	698183	VALVE-FUEL SHUT OFF			
964	799159	CAP, Connector		(EVAP)	
968B	591646	COVER, Air Cleaner		(Black-Compatible With Canister Style Filter)	
972	799111	TANK, Fuel		(Fluorinated)	
994	794945	ARRESTOR, Spark			
1040	698368	PLATE, Trim		(Black)	
1139	796449	WASHER		(Fuel Pump Bracket)	
1266	691917	SEAL, O-Ring		(Intake Elbow)	