





Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
23	693557	FLYWHEEL		(Steel Ring Gear)	
55	695130	HOUSING, Rewind Starter			
55A	393576	HOUSING, Rewind Starter			
56	695129	PULLEY, Starter			
56A	295871	PULLEY, Starter		(63 Rope)	
57	695131	SPRING, Rewind Starter			
57A	490179	SPRING-REWIND STR			
58	695132	ROPE, Starter		(59" Long)	
58A	692188	ROPE, Starter		(63)	
60	494212	GRIP, Starter Rope			
63	690547	SPRING, Ratchet			
64	691920	ADAPTER, Ratchet Spring			
65	695453	SCREW		(Rewind Starter) (3/8)	
65A	690837	SCREW		(Rewind Starter)	
66	399671	CLUTCH-STARTER		Used Before Code Date 99102500	
67	394897	HOUSING, Clutch			
68	691604	BALL, Clutch			
70	691945	RATCHET-CLUTCH			
71	691359	COVER, Ratchet			
73	691191	SCREEN-ROTATING			
73A	690492	SCREEN, Rotating			
74	691627	SCREW		(Rotating Screen) (7/16)	
74A	691655	SCREW		(Rotating Screen) (13/32)	
165	693148	NUT		(Ring Gear)	
196	695493	FAN/SCREEN ASSEMBLY			
363	19203	PULLER, Flywheel			
455	691173	CUP, Flywheel			
455A	695113	CUP, Flywheel			
456	695128	PLATE, Pawl Friction			
459	281505S	PAWL-RATCHET			
592	690800	NUT		(Rewind Starter)	
597	691696	SCREW		(Pawl Friction Plate)	
608	695058	STARTER, Rewind		Used After Code Date 99102400	
608A	390391	STARTER, Rewind		Used Before Code Date 99102500	
655	691734	ANCHOR-REWIND SPRING			
668	690510	SPACER		(FAN/SCREEN ASSEMBLY)	
668A	691323	SPACER		(Flywheel Cup)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
678	490817	SPACER-REWIND		(Rewind)	
689	691855	SPRING-FRICTION			
695	693109	SCREW		(Ring Gear)	
726		Gear-Ring		(Steel)(See Reference 23 for Service)	
726A	696537	GEAR, Ring		(Aluminum)(Services Plastic Ring Gear Only)	
783	693713	GEAR, Pinion		(Steel Ring Gear Only)	
783A	695708	GEAR-PINION		(Aluminum And Plastic Ring Gears)	
934	690372	SCREW		(Fan Retainer)	
1005	691905	FAN, Flywheel			
1005A	697853	FAN, Flywheel			
1005B	695056	FAN, Flywheel			
1006	690452	RETAINER, Fan			
1051	691265	RING, Retaining			




Ref #	Part #	Description	Qty	Context Note	Foot Note
11	691328	TUBE, Breather			
81	691178	LOCK, Muffler Screw			
167	692297	SEAL-A/C NUT			
176	691917	SEAL, O-Ring		(Air Cleaner Base)	
185	690958	NUT		(Air Cleaner Base)	
300	495805S	MUFFLER			
300A	496022S	MUFFLER			
300B	495882	MUFFLER			
300C	498984S	MUFFLER			
344	693675	SCREW		(Cable Clamp)	
346	690661	SCREW		(Spark Arrestor)	
445	496894S	FILTER-A/C CARTRIDGE			
467	691668	KNOB, Air Cleaner Cover			
607	691693	SCREW		(Air Cleaner Brace) (3/8" Long)	
607A	690703	SCREW		(Air Cleaner Brace) (7/16)	
613	691416	SCREW		(Muffler)	
613A	691678	SCREW		(Muffler) (Muffler Bracket)	
613B	690297	SCREW		(Muffler) (Muffler Bracket)	
646	690460	BRACE, Air Cleanr			
676	393761	DEFLECTOR, Muffler		(Side Outlet)	
677	690661	SCREW		(Muffler Deflector)	
711	690703	SCREW		(Carburetor Shield)	
823	698941	SCREW		(Muffler Adapter)	
864	697346	ADAPTER, Muffler			
875	696129	BASE, Air Cleaner		(Plastic)	
883	692236	GASKET, Exhaust			
967	272403S	FILTER-PRE CLEANER			
968	691916	COVER, Air Cleaner			
971	690810	SCREW		(Air Cleaner Base to Carburetor) Used Before Code Date 97100600	
971	692129	SCREW		(Air Cleaner Base to Carburetor) Used After Code Date 97100500	
994	392390	ARRESTOR, Spark			
996	690678	SHIELD, Carburetor			



Ref #	Part #	Description	Qty	Context Note	Foot Note
5	698148	HEAD, Cylinder			
7	273280S	GASKET, Cylinder Head			
13	690360	SCREW		(Cylinder Head)	
33	695760	VALVE, Exhaust			
34	695761	VALVE, Intake			
35	691279	SPRING, Valve		(Intake)	
36	691279	SPRING, Valve		(Exhaust)	
42	499586	KEEPER, Valve			
45	690564	TAPPET, Valve			
50	690193	MANIFOLD, Intake			
51	692137	GASKET-INTAKE			
51A	272569S	GASKET, Intake			
53	690227	STUD		(Carburetor)	
54	691148	SCREW		(Intake Manifold) (1" Long) Used After Code Date 97100500	
54A	690953	SCREW		(Intake Manifold) (3/4) Used Before Code Date 97100600	
192	691986	ADJUSTER, ROCKER ARM			
238	691843	CAP, Valve			
287	691002	SCREW		(Dipstick Tube)	
337	491055S	PLUG, Spark		(Resistor)	
337	84007216	PLUG, SPARK	1	(China Only)	
383	89838S	WRENCH-SPARK PLUG			
441	224390	BRACKET, Oil Fill			
449	690664	SCREW		(Oil Fill Bracket)	
523	692014	DIPSTICK			
524	281370S	SEAL-DIPSTICK TUBE		(Dipstick Tube)	
525	691398	TUBE, Dipstick			
525A	495768	TUBE, Dipstick			
617	692138	SEAL, O-Ring		(Intake Manifold) Used After Code Date 97100500	
635	691909	BOOT, Spark Plug			
654	690958	NUT		(Carburetor)	
737	690372	SCREW		(Oil Filter Adapter)	
750	691033	SCREW		(Oil Pump Cover) Used After Code Date 98063000	
750A	692198	SCREW		(Oil Pump Cover) Used Before Code Date 98070100	
830	691095	STUD-ROCKER ARM			
842	691870	SEAL, O-Ring		(Dipstick Tube)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
847	496415	DIPSTICK/TUBE ASSEMBLY			
847A	490474	DIPSTICK/TUBE ASSEMBLY			
868	690968	SEAL, Valve			
883	692236	GASKET, Exhaust			
914	691108	SCREW		(Rocker Cover)	
943	690589	SEAL, O-Ring		(Oil Pump Cover) Used After Code Date 98063000	
943A	690604	SEAL, O-Ring		(Oil Pump Cover) Used Before Code Date 98070100	
965	499613	COVER, Oil Pump		Used After Code Date 98063000	
965A	496745	COVER, Oil Pump		Used Before Code Date 98070100	
988	691317	GASKET, Oil Adapter			
1022	272475S	GASKET, Rocker Cover			
1023	691192	COVER, Rocker			
1024	499054	PUMP, Oil		Used After Code Date 98063000	
1024A	493884	PUMP-OIL		Used Before Code Date 98070100	
1026	692003	ROD, Push		(Intake)	
1026	692011	ROD, Push		(Exhaust)	
1027	492932S	FILTER, Oil			
1028	496744	ADAPTER, Oil Filter			
1029	691751	ARM, Rocker			
1034	690822	GUIDE, Push Rod			
1095	691581	GASKET SET, Valve		Used After Code Date 97100500	
1095A	495992	GASKET SET, Valve		Used Before Code Date 97100600	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
309	499521	MOTOR, Starter		(4 3/8 Housing Length For Aluminum Ring Gear Only)	
309	693054	MOTOR, Starter		(3 5/8) (Aluminum Ring Gear)	
309	693551	MOTOR, Starter		(3 5/8 Housing Length For Steel Ring Gear Only)	
309	693552	MOTOR, Starter		(4 3/8 Housing Length For Steel Ring Gear Only)	
309	497401	MOTOR, Starter		(4 3/8 Housing Length For Plastic Ring Gear Only)	
309	497595	MOTOR-STARTER		(3 5/8) (Plastic Ring Gear)	
309A		Motor-Starter		(For Replacement Starter Motor, Order Reference 309)	
310	691263	BOLT		(Starter Motor) (4 3/8 Housing)	
310	692329	BOLT		(Starter Motor) (4 9/16 Housing)	
310	690323	SCREW		(Starter Motor) (3 5/8" Housing Length)	
311	497608	SET, Brush			
311A	395538	SET, Brush		(3 5/8 Housing)	
311B	490311	SET, Brush		(4 9/16 Housing)	
333	492341	ARMATURE, Magneto			
334	691061	SCREW		(Magneto Armature)	
356	690807	WIRE, Stop			
462	691261	WASHER		(Starter Cable)	
474	696578	ALTERNATOR		(DC Only)	
474A	696459	ALTERNATOR		(Dual Circuit)	
474B	696457	ALTERNATOR		(Tri Circuit)	
493	694475	BRACKET, Mounting		(Regulator)	
493A	691177	BRACKET, Mounting		(Regulator)	
500	691086	WASHER		(Key Switch)	
501	691188	REGULATOR		(9 Amp Regulated)	
503	691532	STRAP-STARTER			
510	693699	DRIVE, Starter		(Used With Steel Ring Gear)	
510A	696541	DRIVE, Starter		(Used With Aluminum And Plastic Ring Gears)	
510B	696540	DRIVE, Starter			
513	692024	CLUTCH-DRIVE			
521	690581	SHIELD, Cable			
526	694476	SCREW		(Regulator)	
544	692034	ARMATURE, Starter		(3 5/8 Housing)	
544A	390837	ARMATURE, Starter		(3 5/8 Housing)	
544A	490309	ARMATURE, Starter		(4 3/8 Housing)	
579	691029	NUT		(Starter Cable)	


Ref #	Part #	Description	Qty	Context Note	Foot Note
664	691087	NUT		(Key Switch)	
697	690372	SCREW		(Drive Cap) (11/16)	
697A	691058	SCREW		(Drive Cap) (3/4)	
729A	691224	CLIP, Wire		(Starter Motor)	
729B	224723	CLIP, Wire		(Starter Motor)	
783	693713	GEAR, Pinion		(Steel Ring Gear Only)	
783A	695708	GEAR-PINION		(Aluminum And Plastic Ring Gears)	
789A	698329	HARNESS, Wiring		(Alternator)	
789B	693000	HARNESS, Wiring			
797	693167	NUT		(Brush Retainer)	
801	691283	CAP-DRIVE			
802	691286	CAP-END			
802A	395537	CAP, End		(3 5/8 Housing)	
803	693757	HOUSING, Starter		(3 5/8 Housing)	
803A	494205	HOUSING, Starter		(4 3/8 Housing)	
803A	398159	HOUSING, Starter		(3 5/8 Housing)	
813	690635	CLAMP		(Regulator)	
851	692424	TERMINAL, Spark Plug			
876	696539	KIT, Pinion Spring			
877	393456	WIRE/CONNECTOR, Alternator		(Dual Circuit)	
877A	393814	WIRE/CONNECTOR, Alternator		(DC CIRCUIT)	
877B	393537	WIRE/CONNECTOR, Alternator		(Tri Circuit)	
878	691237	HARNESS, Alternator			
878A	691955	HARNESS, Alternator			
892	692318	SWITCH, Key			
896	691641	PIN, Drive Retainer			
990	691959	SET, Key			
1051	691265	RING, Retaining			
1054	280275	TIE, Cable			
1059	698516	KIT, Screw/Washer		(Alternator)	
1090	691293	RETAINER-BRUSH			
1119	691183	SCREW		(Alternator)	



Ref #	Part #	Description	Qty	Context Note	Foot Note
1	495867	CYLINDER ASSEMBLY		Used Before Code Date 93073000	
1	496412	CYLINDER ASSEMBLY		Used After Code Date 93072900	
2	399265	KIT, Bushing/Seal		(Magneto Side)	
3	391086S	SEAL, Oil		(Magneto Side)	
4	494238	SUMP, Engine			
7	273280S	GASKET, Cylinder Head			
8	696126	BREATHER ASSEMBLY			
9	27803S	GASKET, Breather			
10	691666	SCREW		(Breather Assembly)	
12	692226	GASKET, Crankcase		(.015)(Standard)	
12	692405	GASKET, Crankcase		(.009)	
12	692406	GASKET, Crankcase		(.005)	
15	690946	PLUG, Oil Drain			
15A	691680	PLUG, Oil Drain			
16	690136	CRANKSHAFT		Used After Code Date 98063000	
16A	693944	CRANKSHAFT		Used After Code Date 95073100 Used Before Code Date 98070100	
16B	693653	CRANKSHAFT		Used Before Code Date 95080100	
20	291675S	SEAL, Oil		(PTO Side)	
22	692125	SCREW		(Crankcase Cover/Sump)	
24	222698S	KEY, Flywheel			
25	499284	PISTON ASSEMBLY		(Standard) Used Before Code Date 01041900	
25	499292	PISTON ASSEMBLY		(.020 Oversize) Used Before Code Date 01041900	
25	696397	PISTON ASSEMBLY		(Standard) Used After Code Date 01041800	
25	696399	PISTON ASSEMBLY		(.020 Oversize) Used After Code Date 01041800	
25	696400	PISTON ASSEMBLY		(.030 Oversize) Used After Code Date 01041800	
26	696404	SET, Ring		(.010 Oversize) Used After Code Date 01041800	
26	696405	SET, Ring		(.020 Oversize) Used After Code Date 01041800	
26	696403	SET, Ring		(Standard) Used After Code Date 01041800	
26	495851	SET, Ring		(.020 Oversize) Used Before Code Date 01041900	

Ref #	Part #	Description	Qty	Context Note	Foot Note
26	696406	SET, Ring		(.030 Oversize) Used After Code Date 01041800	
26	495854	SET, Ring		(Standard) Used Before Code Date 01041900	
26	495855	SET, Ring		(.030 Oversize) Used Before Code Date 01041900	
27	691299	LOCK, Piston Pin		Used After Code Date 95101500	
27A	691792	LOCK, Piston Pin		Used Before Code Date 95101600	
28	498319	PIN, Piston		(Standard) Used After Code Date 95101500	
28	498320	PIN, Piston		(.005 Oversize) Used After Code Date 95101500	
28A	299691	PIN, Piston		(Standard) Used Before Code Date 95101600	
28A	391286	PIN, Piston		(.005 Oversize) Used Before Code Date 95101600	
29	692420	ROD, Connecting		(.020 Undersize) Used After Code Date 98063000	
29	692419	ROD, Connecting		(Standard) Used After Code Date 98063000	
29	495490	ROD, Connecting		(.020 Undersize) Used Before Code Date 98070100	
29	494504S	ROD, Connecting		(Standard) Used Before Code Date 98070100	
32	690356	SCREW		(Connecting Rod) (1 7/8)	
32A	690348	SCREW		(Connecting Rod) (1 5/8)	
43	691968	SLINGER, Governor/Oil			
45	690564	TAPPET, Valve			
46	698492	CAMSHAFT			
51	692137	GASKET-INTAKE			
84	690343	PLUG, Oil Drain			
146	691639	KEY, Woodruff			
176	691917	SEAL, O-Ring		(Air Cleaner Base)	
186	691609	CONNECTOR, Hose		(Breather Assembly)	
306	698454	SHIELD-CYLINDER			
307	691003	SCREW		(Cylinder Shield)	
358	495993	GASKET SET, Engine		Used Before Code Date 97100600	
358	691580	GASKET SET, Engine		Used After Code Date 97100500	
524	281370S	SEAL-DIPSTICK TUBE		(Dipstick Tube)	
552	491986	BUSHING, Governor Crank		(1/4 I.D.)	


Ref #	Part #	Description	Qty	Context Note	Foot Note
617	692138	SEAL, O-Ring		(Intake Manifold) Used After Code Date 97100500	
691	692407	SEAL-GOVERNOR SHAFT			
718	690959	PIN, Locating			
733	691658	SCREW		(Crankshaft Extension)	
741	691284	GEAR, Timing			
757	691714	LINK, Counterweight		(Used After Code Date 78100411)	
758	692423	COUNTERWEIGHT			
759	691239	PIN, Counterweight			
761	691096	SCREW		(Counterweight)	
810	691779	EXTENSION, Crankshaft			
842	691870	SEAL, O-Ring		(Dipstick Tube)	
868	690968	SEAL, Valve			
943	690589	SEAL, O-Ring		(Oil Pump Cover) Used After Code Date 98063000	
988	691317	GASKET, Oil Adapter			
1017	690770	SCREEN, Oil Pump			
1017A	691216	SCREEN, Oil Pump			
1022	272475S	GASKET, Rocker Cover			
1035	693784	SHAFT, Pump			
1055	690528	TUBE, Oil Pump		Used Before Code Date 98070100	
1058	275935	MANUAL, Operator's			
1330	272147	MANUAL, Repair			




Ref #	Part #	Description	Qty	Context Note	Foot Note
51	692137	GASKET-INTAKE			
51A	272569S	GASKET, Intake			
51B	692284	GASKET, Intake			
93	690602	BUSHING, Throttle Shaft			
94	498032	KIT, Idle Mixture		(LMT 130, 137, 138)	
94	498030	KIT, Idle Mixture		(Lmt 153154,155,156)	
94A	495932	VALVE, Idle Mixture		(LMT 73, 74, 75, 76, 121, 122, 123, 124, 153, 154, 155, 156)	
95	691636	SCREW		(Throttle Valve)	
95A	690718	SCREW		(Throttle Valve)	
98	495800	KIT, Idle Speed		(Idle Speed) (Lmt 54, 55, 91)	
98A	695408	KIT, Idle Speed			
104	690525	PIN, Float Hinge			
104A	694918	PIN, Float Hinge			
105	231855S	VALVE-FLOAT NEEDLE			
105A	694922	VALVE, Float Needle			
106	690577	SEAT, Inlet		(Gravity Feed)	
106	691780	SEAT, Inlet		(Pump Feed)	
108	690464	VALVE, Choke		(Manual Choke)	
108A	692344	VALVE, Choke		(Choke A Matic)	
108B	695419	VALVE, Choke			
117	692408	JET, Main		(Standard) (LMT 149, 150, 152, 153, 154, 155, 156, 697480, 697481, 697482, 697483)	
117	697228	JET, Main		(Standard) (LMT 33, 34, 73, 74, 76, 121, 122, 130, 137, 138)	
117A	695415	JET, Main		(Standard) (Standard)	
118	231850	JET, Main		(High Altitude) (LMT 33, 34, 73, 74, 76, 121, 122, 130, 137, 138)	
118	692411	JET, Main		(High Altitude) (LMT 149, 150, 152, 153, 154, 155, 156, 697480, 697481, 697482, 697483)	
118A	695416	JET, Main		(High Altitude) (Nikki Carburetor)	
121	499233	KIT, Carburetor Overhaul		Used After Code Date 96072500 Used Before Code Date 97100600	
121	690191	KIT, Carburetor Overhaul		Used After Code Date 97100500	
121	498116	KIT, Carburetor Overhaul		Used Before Code Date 96072600	
121A	695427	KIT, Carburetor Overhaul			

Ref #	Part #	Description	Qty	Context Note	Foot Note
125	698620	CARBURETOR		(Gravity Feed)	
125A		Carburetor		(Nikki Carburetor, Service With Walbro Carburetor) Used After Code Date 02091500	
125A		Carburetor		(Nikki Carburetor, Service With Walbro Carburetor) Used Before Code Date 02091600	
127	695005	PLUG, Welch			
127A	690727	PLUG, Welch			
127B	694530	PLUG, Welch		(LMT 153, 154, 155)	
130	691750	VALVE, Throttle			
130A	695418	VALVE, Throttle			
131	494379	KIT, Throttle Shaft			
131A	695421	KIT, Throttle Shaft			
133	494381	FLOAT, Carburetor			
133A	694914	FLOAT, Carburetor			
137	281165S	GASKET-FLOAT BOWL			
137A	695426	GASKET, Float Bowl			
141	495097	KIT, Choke Shaft		(Manual Choke)	
141A	495931	KIT, Choke Shaft		(Choke A Matic)	
141B	695420	KIT, Choke Shaft			
142	692412	NOZZLE, Carburetor		(Standard) (LMT 149, 150, 152, 153, 154, 155, 156, 697480, 697481, 697482, 697483)	
142	231990	NOZZLE, Carburetor		(Standard)	
147	231985	JET, Pilot		(LMT 73, 74, 121, 122, 125, 129, 130, 131, 132, 137, 138)	
147	497472	JET, Pilot		(LMT 33, 34)	
186A	692317	CONNECTOR-HOSE		(Carburetor)	
187A	698417	LINE, Fuel		(Formed)(10-1/4 Inches)(Cut to Required Length)	
187A	697907	LINE, Fuel		(Formed)(9-5/8 Inches)(Cut To Required Length)	
217	695409	SPRING, Choke Return			
231	691636	SCREW		(Choke Valve)	
276	692255	WASHER, Sealing		(Float Bowl)	
276A	695410	WASHER, Sealing		(Float Bowl)	
369	695422	SPRING, Float Bowl			
601	95162S	CLAMP, Hose			


Ref #	Part #	Description	Qty	Context Note	Foot Note
633	695414	SEAL, Choke/Throttle Shaft			
634	690801	SPRING/SEAL ASSEMBLY		(Manual Choke)	
634A	690802	SPRING/SEAL ASSEMBLY		(Choke A Matic)	
692	690572	SPRING, Detent			
729	691335	CLIP, Wire		(Wiring Harness/Solenoid)	
789	692037	HARNESS-WIRING		(Fuel Solenoid)	
947	692734	SOLENOID, Fuel			
947B	497672	SOLENOID, Fuel			
947C	695423	SOLENOID, Fuel			
975	495933	BOWL, Float		(Float Bowl)	
975A	695417	BOWL, Float			
977	690192	SET, Carburetor Gasket			
977A	695428	SET, Carburetor Gasket			
987	691326	SEAL, Choke/Throttle Shaft			
987A	692001	SEAL, Choke/Throttle Shaft		(LMT 33, 34)	
987B	698777	SEAL, Choke/Throttle Shaft			
1091	691333	CAP, Limiter			
1127	695407	SCREW		(Float Bowl)	



SMALL FAN



LARGE FAN



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
37	690456	GUARD, Flywheel			
78	697561	SCREW		(Flywheel Guard)	
187	691050	LINE, Fuel		(Cut To Required Length)	
187A	698417	LINE, Fuel		(Formed)(10-1/4 Inches)(Cut to Required Length)	
187A	697907	LINE, Fuel		(Formed)(9-5/8 Inches)(Cut To Required Length)	
187B	698600	LINE, Fuel		(Formed)(9 Inches)	
188	691693	SCREW		(Control Bracket)	
202	691841	LINK, Mechanical Governor			
209	692208	SPRING, Governor		(Green)	
216	691840	LINK, Choke			
222	694042	BRACKET, Control			
227	691374	LEVER, Governor Control			
232	691842	SPRING, Governor Link			
240	298090S	FILTER, Fuel		(Red)	
240	394358S	FILTER-FUEL		(White)	
265	691024	CLAMP, Casing			
267	690804	SCREW		(Casing Clamp) (5/8)	
267	695134	SCREW		(Casing Clamp) (TORX HEAD)	
268	691025	CASING, Control Wire		(Cut To Required Length)	
269	691026	WIRE, Control		(Cut To Required Length)	
270	691027	NUT		(Control Wire Casing)	
271	691028	LEVER, Control			
304	690844	HOUSING, Blower		(RED)(LARGE FAN)	
304	690845	HOUSING, Blower		(BLACK)(LARGE FAN)	
305	691108	SCREW		(Blower Housing) (19/32" Long)	
305	692127	SCREW		(Blower Housing) (13/16)	
359	691077	WASHER		(Ground Terminal)	
373	691612	NUT		(Ground Terminal)	
385	691108	SCREW		(Fuel Pump)	
387	808656	PUMP, Fuel			
404	691691	WASHER		(Governor Crank)	
505	691251	NUT		(Governor Control Lever)	
507	691972	INSULATOR			
520	691084	TERMINAL, Ground			
559	697561	SCREW		(Remote Choke Stop) (#8-32)	
559	690661	SCREW		(Remote Choke Stop) (#8-18)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
562	92613	BOLT		(Governor Lever)	
601	95162S	CLAMP, Hose			
601A	691038	CLAMP, Hose		(Black)	
614	691620	PIN, Cotter			
615	93307	RETAINER, Governor Shaft			
616	692012	CRANK- GOVERNOR			
628	692198	SCREW		(Fuel Pump Bracket)	
727	490324	COVER, Starter Drive		(Includes Mounting Hardware)	
732	691002	SCREW		(Starter Drive Cover)	
788	690458	BRACKET, Fuel Pump			
918	393815	HOSE, Vacuum		(Cylinder To Impulse Pump)(Cut to Required Length)	
958	698183	VALVE, Fuel Shut Off		(Plastic)	
1019	496758	KIT, Label			
1036	694318	LABEL, Emissions		Used After Code Date 98123100 Used Before Code Date 99100100	
1036	694997	LABEL, Emissions		Used After Code Date 99093000 Used Before Code Date 00070100	
1036	499363	LABEL, Emissions		Used Before Code Date 97052600	
1036	499364	LABEL, Emissions		Used After Code Date 97052500 Used Before Code Date 99010100	
1036	695700	LABEL, Emissions		Used After Code Date 00063000	