








Ref #	Part #	Description	Qty	Context Note	Foot Note
3	391086S	SEAL, Oil		(Magneto Side)	
7	693997	GASKET, Cylinder Head			
9	690937	GASKET, Breather			
12	697227	GASKET, Crankcase			
20	795387	SEAL, Oil		(PTO Side)	
51	699803	GASKET, Intake			
51A	690949	GASKET, Intake			
51B	699800	GASKET, Intake			
104	694918	PIN, Float Hinge			
105	797410	VALVE, Float Needle			
121	699814	KIT, Carburetor Overhaul			
137	698781	GASKET, Float Bowl			
276	695410	WASHER, Sealing			
358	699823	GASKET SET-ENGINE			
524	691032	SEAL, O-Ring			
633	699813	SEAL, Choke/Throttle Shaft			
633A	806131	SEAL, Choke/Throttle Shaft			
691	790574	SEAL, Governor Shaft			
842	691031	SEAL, O-Ring		(Dipstick Tube)	
868	690968	SEAL, Valve			
883	690970	GASKET, Exhaust			
943	690589	SEAL, O-Ring		(Oil Pump Cover) Used Before Code Date 08071800	
943A	796222	SEAL, O-Ring		(Oil Pump Cover) Used After Code Date 08071700	
1022	690971	GASKET, Rocker Cover			
1095	699822	GASKET SET, Valve			










Ref #	Part #	Description	Qty	Context Note	Foot Note
23	691053	FLYWHEEL			
73	494439	SCREEN, Rotating			
74	698425	SCREW		(Rotating Screen)	
75	691056	WASHER		(Flywheel)	
165	693148	NUT		(Ring Gear)	
188	691108	SCREW		(Control Bracket)	
209	793340	SPRING, Governor		(Orange)	
211	691019	SPRING, Governed Idle		(No Color)	
213	691021	BRACKET, Choke Control			
216	691022	LINK, Choke		(Manual Choke)	
222	698757	BRACKET, Control		(EU Manual Choke)	
265	691024	CLAMP, Casing			
267	792629	SCREW		(Casing Clamp)	
332	691059	NUT		(Flywheel)	
363	19203	PULLER, Flywheel			
563	799359	SCREW		(Debris Screen Guard)	
613	690341	SCREW		(Muffler)	
668	691500	SPACER			
668A	691215	SPACER			
695	693149	SCREW		(Ring Gear)	
726	499612	GEAR, Ring			
929	691003	SCREW		(Choke Control Bracket)	
934	592604	SCREW		(Fan Retainer)	
949	798767	GUARD, Debris Screen			
1005	790698	FAN, Flywheel			
1070	791680	SCREW		(Flywheel Fan)	








Ref #	Part #	Description	Qty	Context Note	Foot Note
4	796307	SUMP, Engine			
12	697227	GASKET, Crankcase			
15	691680	PLUG, Oil Drain		Used Before Code Date 08071800	
15A	690946	PLUG, Oil Drain		Used After Code Date 08071700	
20	795387	SEAL, Oil		(PTO Side)	
22	694966	SCREW		(Crankcase Cover/Sump)	
219	793338	GEAR, Governor			
220	799772	WASHER		(Governor Gear)	
221	841026	CUP, Governor			
287	697820	SCREW		(Dipstick Tube)	
404	690442	WASHER		(Governor Crank)	
415	794903	PLUG		(Sump)	
523	691036	DIPSTICK			
524	691032	SEAL, O-Ring			
525	691037	TUBE, Dipstick			
552	796638	BUSHING, Governor Crank			
552A	690553	BUSHING, Governor Crank			
615	698290	RETAINER, Governor Shaft			
616	691045	CRANK, Governor			
691	790574	SEAL, Governor Shaft			
742	690328	RETAINER, E Ring			
750	696999	SCREW		(Oil Pump Cover) Used Before Code Date 08071800	
750A	796208	SCREW		(Oil Pump Cover) Used After Code Date 08071700	
842	691031	SEAL, O-Ring		(Dipstick Tube)	
847	499602	DIPSTICK/TUBE ASSEMBLY			
943	690589	SEAL, O-Ring		(Oil Pump Cover) Used Before Code Date 08071800	
943A	796222	SEAL, O-Ring		(Oil Pump Cover) Used After Code Date 08071700	
965	499613	COVER, Oil Pump		Used Before Code Date 08071800	
965A	796221	COVER, Oil Pump		Used After Code Date 08071700	
1013	690954	NIPPLE, Oil Filter			
1017	690770	SCREEN, Oil Pump		Used Before Code Date 08071800	
1017A	796214	SCREEN, Oil Pump		Used After Code Date 08071700	
1024	794644	PUMP-OIL		Used Before Code Date 08071800	
1024A	796220	PUMP, Oil		Used After Code Date 08071700	

Ref #	Part #	Description	Qty	Context Note	Foot Note
1027	492932S	FILTER, Oil		(Black)	
1027	795890	FILTER, Oil		(Yellow)	






Ref #	Part #	Description	Qty	Context Note	Foot Note
1	591694	CYLINDER ASSEMBLY		Used After Code Date 12051300	
1	699751	CYLINDER ASSEMBLY		Used Before Code Date 07071000	
1	795118	CYLINDER ASSEMBLY		Used After Code Date 07070900 Used Before Code Date 12051400	
2	797673	KIT-BUSHING/SEAL		(Magneto Side)	
3	391086S	SEAL, Oil		(Magneto Side)	
8	792185	BREATHER ASSEMBLY			
9	690937	GASKET, Breather			
10	691108	SCREW		(Breather Assembly)	
11	792184	TUBE-BREATHER			
16	796237	CRANKSHAFT			
24	222698S	KEY, Flywheel			
25	793647	PISTON ASSEMBLY		(Standard)	
25	793648	PISTON ASSEMBLY		(.020" Oversize)	
26	791787	SET, Ring		(Standard)	
26	791792	SET, Ring		(.020" Oversize)	
27	690975	LOCK, Piston Pin			
28	690229	PIN-PISTON/STD		(Standard)	
29	796209	ROD, Connecting		(Standard)	
32	690976	SCREW		(Connecting Rod)	
45	690977	TAPPET, Valve			
46	790562	CAMSHAFT			
212	695238	LINK, Throttle			
227	798856	LEVER-GOVERNOR CONTROL			
250	690957	RETAINER, Breather			
252	794389	COLLECTOR-OIL			
278	792651	WASHER		(Governor Lever)	
306	796852	SHIELD-CYLINDER		(Cylinder #1)	
306A	798855	SHIELD, Cylinder		(EVAP Fitting Compatible)	
306A	796541	SHIELD, Cylinder		(Cylinder 2) Used After Code Date 08080300 Used Before Code Date 10052400	
306A	793205	SHIELD, Cylinder		(Cylinder 2) Used Before Code Date 08080400	
307	691003	SCREW		(Cylinder Shield)	
307A	691108	SCREW		(Cylinder Shield)	
377	690979	KEY, Woodruff			
405	697820	SCREW		(Back Plate) (Mounting)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
447	691003	SCREW		(Air Guide Cover)	
505	691029	NUT		(Governor Control Lever)	
562	690311	BOLT		(Governor Control Lever)	
573	790444	PLATE, Back			
718	690959	PIN, Locating			
741	690980	GEAR, Timing			
850	100106	SEALANT, Liquid			
865	691015	COVER, Air Guide		(Valley)	
1036		Label-Emissions			
1058	381258TRI	MANUAL, Operator's			
1319	794467	LABEL, Warning			
1319A	797669	LABEL, Warning			
1330	273521	MANUAL, Repair			



Ref #	Part #	Description	Qty	Context Note	Foot Note
309	497595	MOTOR-STARTER		(3 5/8) (Plastic Ring Gear)	
310	690323	SCREW		(Starter Motor)	
311	497608	SET, Brush			
333	799651	ARMATURE, Magneto			
334	691061	SCREW		(Magneto Armature)	
405	697820	SCREW		(Back Plate) (Mounting)	
462	691261	WASHER		(Starter Cable)	
474B	696458	ALTERNATOR		(10 and 16 Amp Regulated)	
501	794360	REGULATOR		(5/9 Amp.)	
501A	797375	REGULATOR		(10-16 AMP.)	
503	691532	STRAP-STARTER			
510	696541	DRIVE, Starter			
513	692024	CLUTCH-DRIVE			
526	691129	SCREW		(Regulator)	
526A	691108	SCREW		(Regulator)	
579	691029	NUT		(Starter Cable)	
697	591909	SCREW		(Drive Cap)	
703	691010	CLIP			
729A	797454	CLIP, Wire			
783	695708	GEAR-PINION			
				(6 Pin, #2 Side Regulator. Without EFM. Wire Assembly Includes Green Oil Pressure Switch Wire. Remove If Not Needed. Service Kit Includes Red Regulator To 2 Pin Jumper Wire.)	
789	698330	HARNESS, Wiring		(6 Pin, #1 Side Regulator. Without EFM. Without Oil Pressure Switch.) Used Before Code Date 12042300	
789A	797424	HARNESS, Wiring		(6 Pin, #1 Side Regulator. Without EFM. Without Oil Pressure Switch.) Used After Code Date 12042200	
789A	591392	HARNESS, Wiring		(6 Pin, #1 Side Regulator. Without EFM. Without Oil Pressure Switch. Wire Assembly Includes Green Oil Pressure Switch Wire.) Used Before Code Date 12042300	
789B	797460	HARNESS, Wiring		(6 Pin, #1 Side Regulator. Without EFM. Without Oil Pressure Switch. Wire Assembly Includes Green Oil Pressure Switch Wire.) Used After Code Date 12042200	
789B	591393	HARNESS, Wiring		(6 Pin, #1 Side Regulator. Without EFM. Without Oil Pressure Switch. Wire Assembly Includes Green Oil Pressure Switch Wire.) Used After Code Date 12042200	
797	693167	NUT		(Brush Retainer)	
801	691283	CAP-DRIVE			
802	691286	CAP-END			


Ref #	Part #	Description	Qty	Context Note	Foot Note
851	493880S	TERMINAL-SPARK PLUG			
877	393456	WIRE/CONNECTOR, Alternator			
877A	399916	WIRE/CONN- ALTERNATOR			
877B	790544	WIRE/CONNECTOR, Alternator			
878	691955	HARNESS, Alternator			
1051	691265	RING, Retaining			
1054	280275	TIE, Cable			
1059	698516	KIT, Screw/Washer			
1090	691293	RETAINER-BRUSH			
1119	691183	SCREW		(Alternator)	
1448	690260	WASHER		(Magneto Armature)	



Copyright © Briggs & Stratton, LLC. All rights reserved.










Ref #	Part #	Description	Qty	Context Note	Foot Note
5	796231	HEAD, Cylinder		(Cylinder #1)	
5A	796232	HEAD, Cylinder		(Cylinder #2)	
7	693997	GASKET, Cylinder Head			
13	791130	SCREW		(Cylinder Head) Used Before Code Date 08070100	
13	793988	SCREW		(Cylinder Head) Used After Code Date 08063000	
33	697576	VALVE, Exhaust			
34	792200	VALVE, Intake			
35	694865	SPRING, Valve		(Intake)	
36	694865	SPRING, Valve		(Exhaust)	
42	499586	KEEPER, Valve			
45	690977	TAPPET, Valve			
50	699801	MANIFOLD, Intake			
51	699803	GASKET, Intake			
51A	690949	GASKET, Intake			
53	690951	STUD		(Carburetor)	
54	699816	SCREW		(Intake Manifold)	
122	699802	SPACER, Carburetor			
192	690083	ADJUSTER, Rocker Arm			
212A	792265	LINK, Throttle			
337	793541	PLUG, Spark			
383	19576S	WRENCH, Spark Plug			
617	697891	SEAL, O-Ring		(Intake Manifold)	
654	690958	NUT		(Carburetor)	
798	697890	SCREW		(Rocker Arm)	
868	690968	SEAL, Valve			
883	690970	GASKET, Exhaust			
914	691127	SCREW		(Rocker Cover)	
918	793147	HOSE, Vacuum		(Formed Hose)	
918A	596163	HOSE, Vacuum		Used Before Code Date 19091800	
918A	593641	HOSE, Vacuum		Used After Code Date 19091700	
1022	690971	GASKET, Rocker Cover			
1023	793146	COVER, Rocker		(Cylinder #1)	
1023A	499600	COVER, Rocker		(Cylinder #2)	
1026	690981	ROD, Push		(Steel)	
1026A	690982	ROD, Push		(Aluminum)	
1029	690972	ARM, Rocker			
1029A	807323	ARM, Rocker			

Ref #	Part #	Description	Qty	Context Note	Foot Note
1100	791959	PIVOT, Rocker Arm			



Ref #	Part #	Description	Qty	Context Note	Foot Note
51	699803	GASKET, Intake			
51B	699800	GASKET, Intake			
95	690718	SCREW		(Throttle Valve)	
98	699721	KIT, Idle Speed			
104	694918	PIN, Float Hinge			
105	797410	VALVE, Float Needle			
108	699808	VALVE, Choke			
117	791406	JET, Main		(Standard)	
118	699820	JET, Main		(High Altitude)	
125	699807	CARBURETOR			
127	699810	PLUG, Welch			
130	699809	VALVE, Throttle			
131	699812	KIT, Throttle Shaft		(NO LONGER AVAILABLE)	
133	694914	FLOAT, Carburetor			
135	792022	TUBE-FUEL TRANSFER			
137	698781	GASKET, Float Bowl			
141	699811	KIT, Choke Shaft			
186	799158	CONNECTOR, Hose		(EVAP)	
186A	845141	CONNECTOR, Hose		(EVAP)	
187	791766	LINE, Fuel		(15" Long)(Cut to Required Length)	
217	799771	SPRING, Choke Return			
240	84001895	FILTER, Fuel		(Includes Paper Element With A 40 Micron Rating)	
240A	695666	FILTER, Fuel		(Includes Paper Element With A 30 Micron Rating)	
276	695410	WASHER, Sealing			
385	691108	SCREW		(Fuel Pump) (Fuel Pump Mounted To Fuel Pump Bracket)	
385	797409	SCREW		(Fuel Pump) (Fuel Pump Mounted To Blower Housing)	
387	808656	PUMP, Fuel			
601	691038	CLAMP, Hose		(Black)	
601	791850	CLAMP, Hose		(Green)	
633	699813	SEAL, Choke/Throttle Shaft			
633A	806131	SEAL, Choke/Throttle Shaft			
788	793145	BRACKET, Fuel Pump			
918B	799160	HOSE, Vacuum		(Length 9.4 Inches)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
947	699728	SOLENOID, Fuel			
964	799159	CAP, Connector			
975	699502	BOWL, Float			
1127	695407	SCREW		(Float Bowl) (Float Bowl to Carburetor Body) Aluminum Float Bowl	



Ref #	Part #	Description	Qty	Context Note	Foot Note
51B	699800	GASKET, Intake			
186	799158	CONNECTOR, Hose		(EVAP)	
186A	845141	CONNECTOR, Hose		(EVAP)	
304	790688	HOUSING, Blower		(Black-Compatible With Panel Style Filter)	
305	691005	SCREW		(Blower Housing)	
305A	790690	SCREW		(Blower Housing) (Blower Housing To Intake Elbow)	
431	798861	MANIFOLD, Intake			
445	499486S	FILTER-A/C CARTRIDGE		(Flat Panel)	
467	790697	KNOB, Air Cleaner Cover		(1" Long)	
467A	691008	KNOB, Air Cleaner Cover		(1 1/2)	
467B	591660	KNOB, Air Cleaner Cover		(7/8" Long)	
918B	799160	HOSE, Vacuum		(Length 9.4 Inches)	
964	799159	CAP, Connector			
967	273638S	FILTER-PRE CLEANER			
968	790689	COVER, Air Cleaner			
1040	791237	PLATE, Trim			