





Copyright © Briggs & Stratton, LLC. All rights reserved.



Ref #	Part #	Description	Qty	Context Note	Foot Note
309	497595	MOTOR-STARTER		(3 5/8) (Plastic Ring Gear)	
310	690323	SCREW		(Starter Motor)	
311	497608	SET, Brush			
333	799651	ARMATURE, Magneto			
334	691061	SCREW		(Magneto Armature)	
405	697820	SCREW		(Back Plate)	
462	691261	WASHER		(Starter Cable)	
474B	696458	ALTERNATOR		(10 and 16 Amp Regulated)	
501	794360	REGULATOR		(5/9 Amp. Regulated)	
501A	797375	REGULATOR		(10 and 16 Amp Regulated)	
503	691532	STRAP-STARTER			
510	696541	DRIVE, Starter			
513	692024	CLUTCH-DRIVE			
526	691129	SCREW		(Regulator) (5/9 Amp. Regulated)	
526A	691108	SCREW		(Regulator) (10-16 Amp Regulated)	
579	691029	NUT		(Starter Cable)	
635	692076	BOOT, Spark Plug			
697	591909	SCREW		(Drive Cap)	
703	691010	CLIP			
729	694123	CLIP, Wire			
729A	797454	CLIP, Wire			
783	695708	GEAR-PINION			
				(6 Pin, #2 Side Regulator. Without EFM. Wire Assembly Includes Green Oil Pressure Switch Wire. Remove If Not Needed. Service Kit Includes Red Regulator To 2 Pin Jumper Wire.)	
789	698330	HARNESS, Wiring			
				(6 Pin, #1 Side Regulator. Without EFM. Without Oil Pressure Switch.) Used Before Code Date 12042300	
789A	797424	HARNESS, Wiring			
				(6 Pin, #1 Side Regulator. Without EFM. Without Oil Pressure Switch.) Used After Code Date 12042200	
789A	591392	HARNESS, Wiring			
				(6 Pin, #1 Side Regulator. Without EFM. Without Oil Pressure Switch. Wire Assembly Includes Green Oil Pressure Switch Wire.) Used Before Code Date 12042300	
789B	797460	HARNESS, Wiring			
				(6 Pin, #1 Side Regulator. Without EFM. Without Oil Pressure Switch. Wire Assembly Includes Green Oil Pressure Switch Wire.) Used After Code Date 12042200	
789B	591393	HARNESS-WIRING			
				(Brush Retainer)	
797	693167	NUT			
801	691283	CAP-DRIVE			
802	691286	CAP-END			

Ref #	Part #	Description	Qty	Context Note	Foot Note
851	493880S	TERMINAL-SPARK PLUG			
877	393456	WIRE/CONNECTOR, Alternator			
877A	393537	WIRE/CONNECTOR, Alternator		(Tri Circuit) (9 Amp)	
877B	399916	WIRE/CONN- ALTERNATOR			
877C	790544	WIRE/CONNECTOR, Alternator			
878	398661	HARNESS, Wiring			
878A	691955	HARNESS, Alternator			
1051	691265	RING, Retaining			
1054	280275	TIE, Cable			
1059	698516	KIT, Screw/Washer			
1090	691293	RETAINER-BRUSH			
1119	691183	SCREW		(Alternator)	
1448	690260	WASHER		(Magneto Armature)	



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
51A	699800	GASKET, Intake			
304C	591656	HOUSING, Blower		(Black-Compatible With Canister Style Filter)	
305	691005	SCREW		(Blower Housing)	
305A	790690	SCREW		(Blower Housing) (Blower Housing To Intake Elbow)	
431B	591662	ELBOW, Intake		(EVAP)	
445B	591334	FILTER, A/C Cartridge		(Canister)	
467	790697	KNOB, Air Cleaner Cover		(1" Long)	
467A	691008	KNOB, Air Cleaner Cover		(1 1/2)	
467B	591660	KNOB, Air Cleaner Cover		(7/8" Long)	
613	690341	SCREW		(Muffler)	
613A	690297	SCREW		(Muffler)	
883	690970	GASKET, Exhaust			
964	799159	CAP, Connector			
967	273638S	FILTER-PRE CLEANER			
968B	591658	COVER, Air Cleaner		(Black-Compatible With Canister Style Filter)	
1005	499603	FAN, Flywheel		Used Before Code Date 04072000	
1005	790698	FAN, Flywheel		Used After Code Date 04071900 Used Before Code Date 06103000	
1005	791236	FAN, Flywheel		Used After Code Date 06102900	
1040	791237	PLATE, Trim			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
51	699803	GASKET, Intake			
51A	699800	GASKET, Intake			
95	690718	SCREW		(Throttle Valve)	
98	699721	KIT, Idle Speed			
104	694918	PIN-FLOAT HINGE			
105	797410	VALVE, Float Needle			
108	699808	VALVE, Choke			
117	791406	JET, Main		(Standard)	
118	699820	JET, Main		(High Altitude)	
125A	591678	CARBURETOR			
127	699810	PLUG, Welch			
130	699809	VALVE, Throttle			
131	699812	KIT, Throttle Shaft			
133	694914	FLOAT, Carburetor			
135A	591701	TUBE, Fuel Transfer			
137	698781	GASKET, Float Bowl			
141A	591700	KIT, Choke Shaft			
186	799158	CONNECTOR, Hose		(EVAP)	
186B	845141	CONNECTOR, Hose		(EVAP)	
187	791766	LINE, Fuel		(Cut To Required Length)	
187A	791872	LINE, Fuel		(Formed Hose)	
187B	791744	LINE-FUEL		(Formed)(Cut To Required Length)	
217	799771	SPRING, Choke Return			
240	84001895	FILTER, FUEL		(Includes Paper Element With A 40 Micron Rating)	
240A	695666	FILTER, Fuel		(Includes Paper Element With A 30 Micron Rating)	
276	695410	WASHER-SEALING			
385	691108	SCREW		(Fuel Pump) (Fuel Pump Mounted To Fuel Pump Bracket)	
385	797409	SCREW		(Fuel Pump) (Fuel Pump Mounted To Blower Housing)	
387	808656	PUMP, Fuel			
601	691038	CLAMP, Hose		(Black)	
601	791850	CLAMP-HOSE		(Green)	
628	691108	SCREW		(Fuel Pump Bracket) Used Before Code Date 06072800	
633	699813	SEAL, Choke/Throttle Shaft			
788	691039	BRACKET, Fuel Pump		Used Before Code Date 06072800	
788A	793145	BRACKET, Fuel Pump		Used After Code Date 06072700	


Ref #	Part #	Description	Qty	Context Note	Foot Note
918B	799160	HOSE, Vacuum		(Length 9.4 Inches)	
947A	798779	SOLENOID, Fuel			
964	799159	CAP, Connector			
975A	591699	BOWL, Float			
				(Float Bowl) (Float Bowl to	
1127	695407	SCREW		Carburetor Body) Aluminum Float	
				Bowl	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
5	796231	HEAD, Cylinder		(Cylinder #1)	
5A	796232	HEAD, Cylinder		(Cylinder #2)	
7	693997	GASKET, Cylinder Head			
13	793988	SCREW		(Cylinder Head) Used After Code Date 08063000	
13	791130	SCREW		(Cylinder Head) Used Before Code Date 08070100	
33	697576	VALVE, Exhaust			
34	792200	VALVE, Intake			
35	694865	SPRING, Valve		(Intake)	
36	694865	SPRING, Valve		(Exhaust)	
42	499586	KEEPER, Valve			
45	690977	TAPPET, Valve			
50	699801	MANIFOLD, Intake			
51	699803	GASKET, Intake			
51B	690949	GASKET, Intake			
53	690951	STUD		(Carburetor)	
54	699816	SCREW		(Intake Manifold)	
122	699802	SPACER, Carburetor			
192	690083	ADJUSTER, Rocker Arm			
212	695238	LINK, Throttle			
212A	792265	LINK, Throttle			
213	691021	BRACKET, Choke Control			
337	793541	PLUG, Spark			
383	19576S	WRENCH, Spark Plug			
617	697891	SEAL, O-Ring		(Intake Manifold)	
635	692076	BOOT, Spark Plug			
654	690958	NUT		(Carburetor)	
798	697890	SCREW		(Rocker Arm)	
868	690968	SEAL, Valve			
883	690970	GASKET, Exhaust			
914	691127	SCREW		(Rocker Cover)	
918	793147	HOSE, Vacuum		(Formed Hose)	
918A	596163	HOSE, Vacuum		Used Before Code Date 19091800	
918A	593641	HOSE, Vacuum		Used After Code Date 19091700	
929	691003	SCREW		(Choke Control Bracket)	
1022	690971	GASKET, Rocker Cover			
1023	499599	COVER, Rocker		(Cylinder 1) Used Before Code Date 06090500	
1023	793146	COVER, Rocker		(Cylinder #1) Used After Code Date 06090400	


Ref #	Part #	Description	Qty	Context Note	Foot Note
1023A	499600	COVER, Rocker		(Cylinder #2)	
1026	690981	ROD, Push		(Steel)	
1026A	690982	ROD, Push		(Aluminum)	
1029	690972	ARM, Rocker			
1029A	807323	ARM, Rocker			
1100	791959	PIVOT, Rocker Arm			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
1	591694	CYLINDER ASSEMBLY		Used After Code Date 12051300	
1	699751	CYLINDER ASSEMBLY		Used Before Code Date 07071000	
1	795118	CYLINDER ASSEMBLY		Used After Code Date 07070900 Used Before Code Date 12051400	
2	797673	KIT-BUSHING/SEAL		(Magneto Side)	
3	391086S	SEAL, Oil		(Magneto Side)	
8	792185	BREATHER ASSEMBLY			
9	690937	GASKET, Breather			
10	691108	SCREW		(Breather Assembly)	
11	792184	TUBE-BREATHER			
16	796237	CRANKSHAFT		Used After Code Date 04010800	
16A	699701	CRANKSHAFT		(Includes Connecting Rod) Used Before Code Date 04010900	
24	222698S	KEY, Flywheel			
25	793647	PISTON ASSEMBLY		(Standard)	
25	793648	PISTON ASSEMBLY		(.020" Oversize)	
26	791787	SET, Ring		(Standard) Used After Code Date 06101400	
26	499604	SET, Ring		(Standard) Used Before Code Date 06101500	
26	499606	SET, Ring		(.020 Oversize) Used Before Code Date 06101500	
26	793650	SET, Ring		(.020 Oversize) Used After Code Date 06101400	
27	690975	LOCK, Piston Pin			
28	690229	PIN-PISTON/STD		(Standard)	
29		Rod-Connecting		(For Replacement Connecting Rod, See Reference 16A) Used Before Code Date 04010900	
29	796209	ROD, Connecting		(Standard) Used After Code Date 04010900	
32	690976	SCREW		(Connecting Rod)	
45	690977	TAPPET, Valve			
46	792555	CAMSHAFT			
212	695238	LINK, Throttle			
227	798856	LEVER-GOVERNOR CONTROL			
250	690957	RETAINER, Breather			
252	794389	COLLECTOR-OIL			
278	792651	WASHER		(Governor Lever)	
306	796852	SHIELD-CYLINDER		(Cylinder #1)	
306A	798855	SHIELD, Cylinder		(EVAP Fitting Compatible)	



Ref #	Part #	Description	Qty	Context Note	Foot Note
306A	796541	SHIELD, Cylinder		(Cylinder 2) Used After Code Date 08080300 Used Before Code Date 10052400	
306A	793205	SHIELD, Cylinder		(Cylinder 2) Used Before Code Date 08080400	
307	691003	SCREW		(Cylinder Shield)	
307A	691108	SCREW		(Cylinder Shield)	
357	691483	KEY, Drive Pulley			
377	690979	KEY, Woodruff			
405	697820	SCREW		(Back Plate)	
447	691003	SCREW		(Air Guide Cover)	
505	691029	NUT		(Governor Control Lever)	
562	690311	BOLT		(Governor Control Lever)	
573	790444	PLATE, Back			
718	690959	PIN, Locating			
741	690980	GEAR, Timing			
850	100106	SEALANT, Liquid			
865A	792286	COVER, Air Guide		(Valley)	
1036		Label-Emissions			
1058	381258TRI	MANUAL, Operator's			
1319	794467	LABEL, Warning			
1319A	797669	LABEL, Warning			
1330	273521	MANUAL, Repair			



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
4	796307	SUMP, Engine			
12	697227	GASKET, Crankcase			
15	691680	PLUG-OIL DRAIN		Used Before Code Date 08071800	
15A	690946	PLUG-OIL DRAIN		Used After Code Date 08071700	
20	795387	SEAL-OIL		(PTO Side)	
22	694966	SCREW		(Crankcase Cover/Sump)	
186A	796532	CONNECTOR, Hose		Oil Drain	
219	793338	GEAR, Governor			
220	799772	WASHER		(Governor Gear)	
221	841026	CUP, Governor			
287	697820	SCREW		(Dipstick Tube)	
404	690442	WASHER		(Governor Crank)	
415	794903	PLUG			
512	796530	HOSE, Oil Drain			
523	691036	DIPSTICK			
524	691032	SEAL, O-Ring			
525	691037	TUBE, Dipstick			
552	796638	BUSHING, Governor Crank			
552A	690553	BUSHING, Governor Crank			
615	698290	RETAINER, Governor Shaft			
616	691045	CRANK, Governor			
691	790574	SEAL-GOVERNOR SHAFT			
742	690328	RETAINER, E Ring			
750	696999	SCREW		(Oil Pump Cover) Used Before Code Date 08071800	
750A	796208	SCREW		(Oil Pump Cover) Used After Code Date 08071700	
842	691031	SEAL, O-Ring		(Dipstick Tube)	
847	499602	DIPSTICK/TUBE ASSEMBLY			
943	690589	SEAL, O-Ring		(Oil Pump Cover) Used Before Code Date 08071800	
943A	796222	SEAL, O-Ring		(Oil Pump Cover) Used After Code Date 08071700	
965	499613	COVER, Oil Pump		Used Before Code Date 08071800	
965A	796221	COVER, Oil Pump		Used After Code Date 08071700	
1013	690954	NIPPLE, Oil Filter			
1017	690770	SCREEN, Oil Pump		Used Before Code Date 08071800	
1017A	796214	SCREEN, Oil Pump		Used After Code Date 08071700	
1024	794644	PUMP-OIL		Used Before Code Date 08071800	
1024A	796220	PUMP, Oil		Used After Code Date 08071700	

Ref #	Part #	Description	Qty	Context Note	Foot Note
1027	492932S	FILTER, Oil		(Black)	
1027	795890	FILTER, Oil		(Yellow)	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
3	391086S	SEAL, Oil		(Magneto Side)	
7	693997	GASKET, Cylinder Head			
9	690937	GASKET, Breather			
12	697227	GASKET, Crankcase			
20	795387	SEAL-OIL		(PTO Side)	
51	699803	GASKET, Intake			
51A	699800	GASKET, Intake			
51B	690949	GASKET, Intake			
104	694918	PIN-FLOAT HINGE			
105	797410	VALVE, Float Needle			
121	699814	KIT, Carburetor Overhaul			
137	698781	GASKET, Float Bowl			
276	695410	WASHER-SEALING			
358	699823	GASKET SET-ENGINE			
524	691032	SEAL, O-Ring			
633	699813	SEAL, Choke/Throttle Shaft			
633A	806131	SEAL, Choke/Throttle Shaft			
691	790574	SEAL-GOVERNOR SHAFT			
842	691031	SEAL, O-Ring		(Dipstick Tube)	
868	690968	SEAL, Valve			
883	690970	GASKET, Exhaust			
943	690589	SEAL, O-Ring		(Oil Pump Cover) Used Before Code Date 08071800	
943A	796222	SEAL, O-Ring		(Oil Pump Cover) Used After Code Date 08071700	
1022	690971	GASKET, Rocker Cover			
1095	699822	GASKET SET, Valve			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
23	691053	FLYWHEEL			
73	494439	SCREEN, Rotating			
74	698425	SCREW		(Rotating Screen)	
75	691056	WASHER		(Flywheel)	
165	693148	NUT		(Ring Gear)	
188	691108	SCREW		(Control Bracket)	
209A	798921	SPRING, Governor		(Orange)	
211	691019	SPRING, Governed Idle		(No Color)	
216	691022	LINK, Choke		(Manual Choke)	
222C	798916	BRACKET, Control		(V3 Manual Choke)	
265	691024	CLAMP, Casing			
267	792629	SCREW		(Casing Clamp)	
332	691059	NUT		(Flywheel)	
363	19203	PULLER, Flywheel			
563	799359	SCREW		(Debris Screen Guard)	
668	691500	SPACER			
668A	691215	SPACER			
695	693149	SCREW		(Ring Gear)	
726	499612	GEAR, Ring			
934	592604	SCREW		(Fan Retainer)	
949	798767	GUARD, Debris Screen			
1005	499603	FAN, Flywheel		Used Before Code Date 04072000	
1005	790698	FAN, Flywheel		Used After Code Date 04071900	Used Before Code Date 06103000
1005	791236	FAN, Flywheel		Used After Code Date 06102900	
1012	592556	RETAINER, Link			
1070	791680	SCREW		(Flywheel Fan)	