






Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
4	84007282	SUMP, Engine	1		
15	690946	PLUG, Oil Drain	1		
20	795387	SEAL, Oil	1	(PTO Side)	
22	694966	SCREW	10	(Crankcase Cover/Sump)	
45		TAPPET, Valve	4	(Part information located in Cylinder Head Group.)	
46		CAMSHAFT	1	(Part information located in Crankshaft Group.)	
219	793338	GEAR, Governor	1		
220	799772	WASHER	1	(Governor Gear)	
221	841026	CUP, Governor	1		
404	690442	WASHER	1	(Governor Crank)	
415	794903	PLUG	1		
552	796638	BUSHING, Governor Crank	1		
552A	690553	BUSHING, Governor Crank	2		
615	698290	RETAINER, Governor Shaft	1		
616	691045	CRANK, Governor	1		
691	790574	SEAL, Governor Shaft	1		
742	690328	RETAINER, E Ring	2		
750	796208	SCREW	3	(Part information located in Lubrication Group.)	
850	100106	SEALANT, Liquid	1		
943		SEAL, O-Ring	1	(Part information located in Lubrication Group.)	
965		COVER, Oil Pump	1	(Part information located in Lubrication Group.)	
1013	690954	NIPPLE, Oil Filter	1		
1017		SCREEN, Oil Pump	1	(Part information located in Lubrication Group.)	
1024		PUMP, Oil	1	(Part information located in Lubrication Group.)	



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
287	697820	SCREW	1	(Dipstick Tube)	
523	594528	DIPSTICK	1		
524	691032	SEAL, O-Ring	1	(Dipstick Tube)	
525	597129	TUBE, Dipstick	1		
750	796208	SCREW	3	(Oil Pump Cover)	
842	691031	SEAL, O-Ring	1	(Dipstick Cap)	
847	597130	DIPSTICK/TUBE ASSEMBLY	1		
943	796222	SEAL, O-Ring	1	(Oil Pump Cover)	
965	796221	COVER, Oil Pump	1		
1017	796214	SCREEN, Oil Pump	1		
1024	796220	PUMP, Oil	1		
1027	492932S	FILTER, Oil	1		



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
3		SEAL, Oil	1	(Part information located in Cylinder Group.)	
5	597198	HEAD, Cylinder	1		
5A	597199	HEAD, Cylinder	1		
7	693997	GASKET, Cylinder Head	2		
13	592244	SCREW	10	(Cylinder Head)	
20		SEAL, Oil	1	(Part information located in Crankcase Cover/Sump Group.)	
22		SCREW	10	(Part information located in Crankcase Cover/Sump Group.)	
33	793557	VALVE, Exhaust	2		
34	793556	VALVE, Intake	2		
35	694865	SPRING, Valve	2	(Intake)	
36	694865	SPRING, Valve	2	(Exhaust)	
42	499586	KEEPER, Valve	4		
45	690977	TAPPET, Valve	4		
50	594206	MANIFOLD, Intake	1	Used After Code Date 17081700	
50A	699801	MANIFOLD, Intake	1	Used Before Code Date 17081800	
51	699803	GASKET, Intake	2	Used Before Code Date 17081800	
51A	690949	GASKET, Intake	2	Used Before Code Date 17081800	
51B	596188	GASKET, Intake	1	Used After Code Date 17081700	
53		STUD	2	(Part information located in Carburetor and Fuel Supply Group.)	
54	699816	SCREW	4	(Intake Manifold)	
163		GASKET, Air Cleaner	1	(Part information located in Carburetor and Fuel Supply Group.)	
186B		CONNECTOR, Hose	1	(Part information located in Carburetor and Fuel Supply Group.)	
192	690083	ADJUSTER, Rocker Arm	4		
337	792015	PLUG, Spark	2		
358		GASKET SET, Engine		(Part information located in Cylinder Group.)	
358B		GASKET SET, Engine	1	(Part information located in Cylinder Group.)	
383	19576S	WRENCH, Spark Plug	1		
524		SEAL, O-Ring	1	(Part information located in Lubrication Group.)	
613	690341	SCREW	4	(Muffler)	
617	594209	SEAL, O-Ring	2	(Intake Manifold)	


Ref #	Part #	Description	Qty	Context Note	Foot Note
635		BOOT, Spark Plug	2	(Part information located in Flywheel/ Ignition/Starter Group.)	
654		NUT	2	(Part information located in Carburetor and Fuel Supply Group.)	
691		SEAL, Governor Shaft	1	(Part information located in Crankcase Cover/Sump Group.)	
798	697890	SCREW	4	(Rocker Arm)	
842		SEAL, O-Ring	1	(Part information located in Lubrication Group.)	
850		SEALANT, Liquid	1	(Part information located in Crankcase Cover/Sump Group.)	
868	690968	SEAL, Valve	2		
883	690970	GASKET, Exhaust	2		
914	691127	SCREW	8	(Rocker Cover)	
918A	596163	HOSE, Vacuum	1	Used Before Code Date 19091800	
918A	593641	HOSE, Vacuum	1	Used After Code Date 19091700	
943		SEAL, O-Ring	1	(Part information located in Lubrication Group.)	
964		CAP, Connector	1	(Part information located in Blower Housing and Air Cleaner Group.)	
1023	499600	COVER, Rocker	1		
1023A	793146	COVER, Rocker	1		
1026	690981	ROD, Push	2		
1026A	690982	ROD, Push	2		
1029	690972	ARM, Rocker	4		
1029A	807323	ARM, Rocker	4		
1100	791959	PIVOT, Rocker Arm	4		



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
1	594969	CYLINDER ASSEMBLY	1		
2	797673	KIT, Bushing/Seal	1	(Magneto Side)	
3	391086S	SEAL, Oil	1	(Magneto Side)	
7		GASKET, Cylinder Head	2	(Part information located in Cylinder Head Group.)	
10	691108	SCREW	4	(Breather Assembly)	
11	594163	TUBE, Breather	1		
20		SEAL, Oil	1	(Part information located in Crankcase Cover/Sump Group.)	
22		SCREW	10	(Part information located in Crankcase Cover/Sump Group.)	
51		GASKET, Intake	2	(Part information located in Cylinder Head Group.)	
51A		GASKET, Intake	2	(Part information located in Cylinder Head Group.)	
51B		GASKET, Intake	1	(Part information located in Cylinder Head Group.)	
163		GASKET, Air Cleaner	1	(Part information located in Carburetor and Fuel Supply Group.)	
227		LEVER, Governor Control	1	(Part information located in Controls Group.)	
306	84002166	SHIELD, Cylinder	1		
306A	84002169	SHIELD, Cylinder	1		
307	691003	SCREW	4	(Cylinder Shield)	
307A	691108	SCREW	4	(Cylinder Shield)	
358	699823	GASKET SET-ENGINE	1	(Service Kits may include extra parts not specific to this engine.) Used Before Code Date 17081800	
358B	84001915	GASKET SET, ENGINE	1	(Service Kits may include extra parts not specific to this engine.) Used After Code Date 17081700	
405	594937	SCREW	7	(Back Plate)	
447	691003	SCREW	4	(Air Guide Cover)	
505		NUT	1	(Part information located in Controls Group.)	
524		SEAL, O-Ring	1	(Part information located in Lubrication Group.)	
540	594325	PLATE, Baffle	1		
562		BOLT	1	(Part information located in Controls Group.)	
573	594902	PLATE, Back	1		
584	594164	COVER, Breather Passage	1		

Ref #	Part #	Description	Qty	Context Note	Foot Note
618	594326	SCREW	1	(Baffle Plate)	
691		SEAL, Governor Shaft	1	(Part information located in Crankcase Cover/ Sump Group.)	
718	690959	PIN, Locating	6		
718A	594988	PIN, Locating	1		
842		SEAL, O-Ring	1	(Part information located in Lubrication Group.)	
865	591667	COVER, Air Guide	1		
868		SEAL, Valve	2	(Part information located in Cylinder Head Group.)	
883		GASKET, Exhaust	2	(Part information located in Cylinder Head Group.)	
943		SEAL, O-Ring	1	(Part information located in Lubrication Group.)	
1263	594166	REED, Breather	1		
1264	594165	SCREW	1	(Breather Reed)	




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
23	594169	FLYWHEEL	1		
73	494439	SCREEN, Rotating	1		
74	698425	SCREW	4	(Rotating Screen)	
75	691056	WASHER	1	(Flywheel)	
309	590476	MOTOR, Starter	1		
332	691059	NUT	1	(Flywheel)	
333	592846	ARMATURE, Magneto	2		
334	691061	SCREW	3	(Magneto Armature)	
337		PLUG, Spark	2	(Part information located in Cylinder Head Group.)	
363	19621	PULLER, Flywheel	1		
383		WRENCH, Spark Plug	1	(Part information located in Cylinder Head Group.)	
635	692076	BOOT, Spark Plug	2		
697	591909	SCREW	2	(Starter Motor) (Drive Cap)	
729	593826	CLIP, Wire	1		
934	593638	SCREW	4	(Fan Retainer)	
1005	593640	FAN, Flywheel	1		




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
16	595704	CRANKSHAFT	1		
24	222698S	KEY, Flywheel	1		
25	793647	PISTON ASSEMBLY	1	(Standard)	
25	793648	PISTON ASSEMBLY	1	(.020" Oversize)	
26	791787	SET, Ring	1	(Standard)	
26	791792	SET, Ring	1	(.020" Oversize)	
27	690975	LOCK, Piston Pin	1		
28	593650	PIN, Piston	1		
29	796209	ROD, Connecting	1		
32	690976	SCREW	2	(Connecting Rod)	
45		TAPPET, Valve	4	(Part information located in Cylinder Head Group.)	
46	796853	CAMSHAFT	1		
377	690980	GEAR, Timing	1		
741	690979	KEY, Woodruff	1		



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
188	691108	SCREW	4	(Control Bracket)	
211	593724	SPRING, Governed Idle	1		
212A	597429	LINK, Throttle	1		
216	796879	LINK, Choke	1		
222	798916	BRACKET, Control	1		
227	798856	LEVER-GOVERNOR CONTROL	1		
232A	597550	SPRING, Governor Link	1		
265	691024	CLAMP, Casing	1		
267	792629	SCREW	1	(Casing Clamp)	
318	691127	SCREW	1	(Mounting Bracket)	
318A	792629	SCREW	2	(Mounting Bracket)	
493	797176	BRACKET, Mounting	1		
505	691029	NUT	1	(Governor Control Lever)	
537	594915	KIT, Governor/Idle Spring	1		
562	690311	BOLT	1	(Governor Control Lever)	
633	691321	SEAL-CHOKE/THR SHAFT	1		
640	796913	WIRE ASSEMBLY	1		
789	796860	HARNESS, Wiring	1		
789A	796914	HARNESS, Wiring	1		
929	691003	SCREW	2	(Choke Control Bracket) Used Before Code Date 17081800	
929	695239	SCREW	2	(Choke Control Bracket) Used After Code Date 17081700	
1054	280275	TIE, Cable	2		
1436	796918	MOTOR, Stepper/Bracket	1		
1437	699891	SCREW	2	(Stepper/Bracket Motor)	
1438	796352S	MODULE, Electronic Choke	1		
1550	595801	PIN, Speed Setting	1		



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
51		GASKET, Intake	2	(Part information located in Cylinder Head Group.)	
51A		GASKET, Intake	2	(Part information located in Cylinder Head Group.)	
51B		GASKET, Intake	1	(Part information located in Cylinder Head Group.)	
53	690951	STUD	2	(Carburetor)	
95	690718	SCREW	2	(Throttle Valve)	
98	699721	KIT, Idle Speed	1	Used Before Code Date 17081800	
98	695408	KIT, Idle Speed	1	Used After Code Date 17081700	
104	694918	PIN, Float Hinge	1		
105	698537	VALVE, Float Needle	1		
108	699808	VALVE, Choke	1	Used Before Code Date 17081800	
117	791406	JET, Main	1	(Standard) Used Before Code Date 17081800	
117	842585	JET, Main	1	(Standard) Used After Code Date 17081700	
118	699820	JET, Main	1	(High Altitude) Used Before Code Date 17081800	
118	792296	JET, Main	1	(High Altitude) Used After Code Date 17081700	
121	84001917	KIT, Carburetor Overhaul		(Service Kits may include extra parts not specific to this engine.) Used After Code Date 17081700	
121A	594375	KIT-CARBURETOR OVERHAUL		(Service Kits may include extra parts not specific to this engine.) Used Before Code Date 17081800	
122	699802	SPACER, Carburetor	1	Used Before Code Date 17081800	
125	597126	CARBURETOR	1	Used After Code Date 17081700	
125A	591678	CARBURETOR	1	Used Before Code Date 17081800	
127	699810	PLUG, Welch	1		
130	699809	VALVE, Throttle	1	Used Before Code Date 17081800	
131	699812	KIT, Throttle Shaft	1	Used Before Code Date 17081800	
133	694914	FLOAT, Carburetor	1		
135	591701	TUBE, Fuel Transfer	1		
137	698781	GASKET, Float Bowl	1		
141	591700	KIT, Choke Shaft	1	Used Before Code Date 17081800	
141	595218	KIT, Choke Shaft	1	Used After Code Date 17081700	
163	699800	GASKET, Intake	1	Used Before Code Date 17081800	
163	594203	GASKET, Intake	1	Used After Code Date 17081700	
186B	845141	CONNECTOR, Hose	1		
187	791766	LINE, Fuel	1		
187A	796491	LINE, Fuel	1		

Ref #	Part #	Description	Qty	Context Note	Foot Note
216		LINK, Choke	1	(Part information located in Controls Group.)	
217	799771	SPRING, Choke Return	1	Used Before Code Date 17081800	
240	84001895	FILTER, Fuel	1		
255	690721	BUSHING, Choke Shaft	1	Used After Code Date 17081700	
276	695410	WASHER, Sealing	1		
385	797409	SCREW	2	(Fuel Pump)	
387	597338	PUMP, Fuel	1		
601A	691038	CLAMP, Hose	2		
633	699813	SEAL, Choke/Throttle Shaft	2		
633A	806131	SEAL, Choke/Throttle Shaft	2		
654	690958	NUT	2	(Carburetor)	
703	691010	CLIP	2		
947	596039	SOLENOID, Fuel	1		
964		CAP, Connector	1	(Part information located in Blower Housing and Air Cleaner Group.)	
975	591699	BOWL, Float	1		
1126	690991	SCREW	3	(Fuel Transfer Tube) Used After Code Date 17081700	
1127	695407	SCREW	2	(Float Bowl to Carburetor Body)	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
163		GASKET, Air Cleaner	1	(Part information located in Carburetor and Fuel Supply Group.)	
186B		CONNECTOR, Hose	1	(Part information located in Carburetor and Fuel Supply Group.)	
304	591656	HOUSING, Blower	1		
305	594618	SCREW	6	(Blower Housing)	
305A	790690	SCREW	2	(Blower Housing)	
431	591662	ELBOW, Intake	1	Used Before Code Date 17081800	
431	594205	ELBOW, Intake	1	Used After Code Date 17081700	
445	594201	FILTER-A/C CARTRIDGE	1		
467	591660	KNOB, Air Cleaner Cover	2		
964	799159	CAP, Connector	1		
968	591658	COVER, Air Cleaner	1		
1036		LABEL, Emissions		(Available from a Briggs & Stratton Authorized Dealer)	
1040	791237	PLATE, Trim	1		
1319	794467	LABEL, Warning		(REQUIRED When Replacing Parts With Warning Labels Affixed)	
1319A	797669	LABEL, Warning		(REQUIRED When Replacing Parts With Warning Labels Affixed)	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
474	592830	ALTERNATOR	1		
501	593490	REGULATOR	1		
526	691129	SCREW	4	(Regulator)	
729	593826	CLIP, Wire	1		
1059	698516	KIT, Screw/Washer	1		
1119	691183	SCREW	4	(Alternator)	