






Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
51B	699800	GASKET, Intake			
186	799158	CONNECTOR, Hose		(EVAP)	
186A	845141	CONNECTOR, Hose		(EVAP)	
304	591656	HOUSING, Blower			
305	594618	SCREW		(Blower Housing)	
305A	790690	SCREW		(Blower Housing) (Blower Housing To Intake Elbow)	
431	591662	ELBOW, Intake			
445	594201	FILTER-A/C CARTRIDGE			
467	591660	KNOB, Air Cleaner Cover		(7/8" Long)	
613	690341	SCREW		(Muffler)	
918A	799160	HOSE, Vacuum		(Length 9.4 Inches)	
964	799159	CAP, Connector			
968	591658	COVER, Air Cleaner			
1040	791237	PLATE, Trim			




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
51A	690949	GASKET, Intake			
51B	699800	GASKET, Intake			
95	690718	SCREW		(Throttle Valve)	
98	699721	KIT, Idle Speed			
104	694918	PIN-FLOAT HINGE			
105	698537	VALVE, Float Needle			
108	699808	VALVE, Choke			
117	791406	JET, Main		(Standard)	
118	699820	JET, Main		(High Altitude)	
125	591678	CARBURETOR			
127	699810	PLUG, Welch			
130	699809	VALVE, Throttle			
131	699812	KIT, Throttle Shaft			
133	694914	FLOAT, Carburetor			
135	591701	TUBE, Fuel Transfer			
137	698781	GASKET, Float Bowl			
141	591700	KIT, Choke Shaft			
186	799158	CONNECTOR, Hose		(EVAP)	
186A	845141	CONNECTOR, Hose		(EVAP)	
187	791766	LINE, Fuel		(15" Long)(Cut to Required Length)	
217	799771	SPRING, Choke Return			
240	84001895	FILTER, FUEL		(Includes Paper Element With A 40 Micron Rating)	
240A	695666	FILTER, Fuel		(Includes Paper Element With A 30 Micron Rating)	
276	695410	WASHER-SEALING			
385	797409	SCREW		(Fuel Pump) (Fuel Pump Mounted To Blower Housing)	
387	808656	PUMP, Fuel			
601	691038	CLAMP, Hose		(Black)	
633	699813	SEAL, Choke/Throttle Shaft			
918A	799160	HOSE, Vacuum		(Length 9.4 Inches)	
947	798779	SOLENOID, Fuel			
964	799159	CAP, Connector			
975	591699	BOWL, Float			
1127	695407	SCREW		(Float Bowl) (Float Bowl to Carburetor Body) Aluminum Float Bowl	



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
5	796231	HEAD, Cylinder		(Cylinder #1)	
5A	796232	HEAD, Cylinder		(Cylinder #2)	
7	693997	GASKET, Cylinder Head			
13	592244	SCREW		(Cylinder Head)	
33	697576	VALVE, Exhaust			
34	792200	VALVE, Intake			
35	694865	SPRING, Valve		(Intake)	
36	694865	SPRING, Valve		(Exhaust)	
42	499586	KEEPER, Valve			
45	690977	TAPPET, Valve			
50	699801	MANIFOLD, Intake			
51	699803	GASKET, Intake			
51A	690949	GASKET, Intake			
53	690951	STUD		(Carburetor)	
54	699816	SCREW		(Intake Manifold)	
122	699802	SPACER, Carburetor			
192	690083	ADJUSTER, Rocker Arm			
337	793541	PLUG, Spark			
383	19576S	WRENCH, Spark Plug			
635	66538S	BOOT, Spark PLug			
654	690958	NUT		(Carburetor)	
798	697890	SCREW		(Rocker Arm)	
868	690968	SEAL, Valve			
883	690970	GASKET, Exhaust			
914	691127	SCREW		(Rocker Cover)	
918	596163	HOSE, Vacuum		Used Before Code Date 19091800	
918	593641	HOSE, Vacuum		Used After Code Date 19091700	
1022	690971	GASKET, Rocker Cover			
1023	793146	COVER, Rocker		(Cylinder #1)	
1023A	499600	COVER, Rocker		(Cylinder #2)	
1026	690981	ROD, Push		(Steel)	
1026A	690982	ROD, Push		(Aluminum)	
1029	690972	ARM, Rocker			
1029A	807323	ARM, Rocker			
1100	791959	PIVOT, Rocker Arm			



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
1	594969	CYLINDER ASSEMBLY		Used After Code Date 15071500	
1A	594371	CYLINDER ASSEMBLY		Used Before Code Date 15071600	
2	797673	KIT-BUSHING/SEAL		(Magneto Side)	
3	391086S	SEAL, Oil		(Magneto Side)	
8	792185	BREATHER ASSEMBLY		Used Before Code Date 14082500	
9	690937	GASKET, Breather		Used Before Code Date 14082500	
10	691108	SCREW		(Breather Assembly)	
11	594163	TUBE, Breather		Used After Code Date 14082400	
11A	792184	TUBE-BREATHER		Used Before Code Date 14082500	
16	796237	CRANKSHAFT			
24	222698S	KEY, Flywheel			
25	793648	PISTON ASSEMBLY		(.020" Oversize)	
25	793647	PISTON ASSEMBLY		(Standard)	
26	791792	SET, Ring		(.020" Oversize)	
26	791787	SET, Ring		(Standard)	
27	690975	LOCK, Piston Pin			
28	696581	PIN, Piston		(Standard)	
29	796209	ROD, Connecting		(Standard)	
32	690976	SCREW		(Connecting Rod)	
45	690977	TAPPET, Valve			
46	792555	CAMSHAFT			
212	792265	LINK, Throttle			
227	798856	LEVER-GOVERNOR CONTROL			
250	690957	RETAINER, Breather		Used Before Code Date 14082500	
252	794389	COLLECTOR-OIL		Used Before Code Date 14082500	
306	796852	SHIELD-CYLINDER		(Cylinder #1)	
306A	591666	SHIELD-CYLINDER		(Cylinder #2)	
307	691003	SCREW		(Cylinder Shield)	
307A	691108	SCREW		(Cylinder Shield)	
377	690979	KEY, Woodruff			
405	697820	SCREW		(Back Plate) (Mounting) Used Before Code Date 15071600	
405	594937	SCREW		(Back Plate) (Mounting) Used After Code Date 15071500	
447	691003	SCREW		(Air Guide Cover)	
505	691029	NUT		(Governor Control Lever)	
540	594325	PLATE, Baffle			
562	690311	BOLT		(Governor Control Lever)	
573	593465	PLATE, Back		Used Before Code Date 15071600	
573	594902	PLATE-BACK		Used After Code Date 15071500	
584	594164	COVER, Breather Passage			
618	594326	SCREW		(Baffle Plate)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
718	690959	PIN, Locating			
718A	594988	PIN, Locating			
741	690980	GEAR, Timing			
850	100106	SEALANT, Liquid			
865	591667	COVER, Air Guide			
1036		Label-Emissions			
1263	594166	REED, Breather			
1264	594165	SCREW		(Breather Reed)	
1319	794467	LABEL, Warning			
1319A	797669	LABEL, Warning			
1330	273521	MANUAL, Repair			




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
4	594974	SUMP, Engine		Used After Code Date 15071500	
4A	796307	SUMP, Engine		Used Before Code Date 15071600	
12	594195	GASKET-CRANKCASE KIT			
15	690946	PLUG-OIL DRAIN			
20	795387	SEAL-OIL		(PTO Side)	
22	694966	SCREW		(Crankcase Cover/Sump)	
219	793338	GEAR, Governor			
220	799772	WASHER		(Governor Gear)	
221	841026	CUP, Governor			
239	792028	SWITCH, Oil Pressure			
287	697820	SCREW		(Dipstick Tube)	
404	690442	WASHER		(Governor Crank)	
415	794903	PLUG		(Sump)	
523	594528	DIPSTICK			
524	691032	SEAL, O-Ring			
525	691037	TUBE, Dipstick			
552	796638	BUSHING, Governor Crank			
552A	690553	BUSHING, Governor Crank			
615	698290	RETAINER, Governor Shaft			
616	691045	CRANK, Governor			
691	790574	SEAL-GOVERNOR SHAFT			
742	690328	RETAINER, E Ring			
750	796208	SCREW		(Oil Pump Cover)	
842	691031	SEAL, O-Ring		(Dipstick Tube)	
847	594609	DIPSTICK/TUBE ASSEMBLY			
850	100106	SEALANT, Liquid			
943	796222	SEAL, O-Ring		(Oil Pump Cover)	
965	796221	COVER, Oil Pump			
1013	690954	NIPPLE, Oil Filter			
1017	796214	SCREEN, Oil Pump			
1024	796220	PUMP, Oil			
1027	696854	FILTER-OIL		(Yellow)	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
3	391086S	SEAL, Oil		(Magnet Side)	
7	693997	GASKET, Cylinder Head			
9	690937	GASKET, Breather		Used Before Code Date 14082500	
12	594195	GASKET-CRANKCASE KIT			
20	795387	SEAL-OIL		(PTO Side)	
22	694966	SCREW		(Crankcase Cover/Sump)	
51	699803	GASKET, Intake			
51A	690949	GASKET, Intake			
51B	699800	GASKET, Intake			
104	694918	PIN-FLOAT HINGE			
121	699814	KIT, Carburetor Overhaul			
137	698781	GASKET, Float Bowl			
276	695410	WASHER-SEALING			
358	699823	GASKET SET-ENGINE			
524	691032	SEAL, O-Ring			
633	699813	SEAL, Choke/Throttle Shaft			
691	790574	SEAL-GOVERNOR SHAFT			
842	691031	SEAL, O-Ring		(Dipstick Tube)	
868	690968	SEAL, Valve			
883	690970	GASKET, Exhaust			
943	796222	SEAL, O-Ring		(Oil Pump Cover)	
1022	690971	GASKET, Rocker Cover			
1095	699822	GASKET SET, Valve			



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
23	594169	FLYWHEEL			
73	494439	SCREEN, Rotating			
74	698425	SCREW		(Rotating Screen)	
75	691056	WASHER		(Flywheel)	
188	691108	SCREW		(Control Bracket)	
213	691021	BRACKET, Choke Control			
216A	796229	LINK, Choke		(Choke A Matic)	
222A	592555	BRACKET, Control			
265	691024	CLAMP, Casing			
267	792629	SCREW		(Casing Clamp)	
309	592599	MOTOR, Starter		Used After Code Date 14082400	
309A	497595	MOTOR-STARTER		Used Before Code Date 14082500	
310	690323	SCREW		(Starter Motor)	
311	497608	SET, Brush			
332	691059	NUT		(Flywheel)	
333	592846	ARMATURE, Magneto			
334	691061	SCREW		(Magneto Armature)	
363	19203	PULLER, Flywheel			
405	697820	SCREW		(Back Plate) (Mounting) Used Before Code Date 15071600	
405	594937	SCREW		(Back Plate) (Mounting) Used After Code Date 15071500	
462	691261	WASHER		(Starter Cable)	
474B	592830	ALTERNATOR		(10-16 Amp Regulated)	
501A	593490	REGULATOR		(10-16 Amp Regulated)	
503	691532	STRAP-STARTER			
510	696541	DRIVE, Starter			
513	692024	CLUTCH-DRIVE			
526	691129	SCREW		(Regulator)	
526A	691108	SCREW		(Regulator)	
537	594910	KIT, Governor/Idle Spring			
563	799359	SCREW		(Debris Screen Guard)	
579	691029	NUT		(Starter Cable)	
635	66538S	BOOT, Spark PLug			
668	691500	SPACER			
668A	691215	SPACER			
697	591909	SCREW		(Starter Motor) (Drive Cap)	
703	691010	CLIP			
729	593826	CLIP, Wire			
783	695708	GEAR-PINION			
789A	591392	HARNESS, Wiring			
797	693167	NUT		(Brush Retainer)	
801	691283	CAP-DRIVE			
802	691286	CAP-END			

Ref #	Part #	Description	Qty	Context Note	Foot Note
877	790544	WIRE/CONNECTOR, Alternator			
929	691003	SCREW		(Choke Control Bracket)	
934	593638	SCREW		(Fan Retainer)	
949	798767	GUARD, Debris Screen			
1005	593640	FAN, Flywheel			
1012	592556	RETAINER, Link			
1051	691265	RING, Retaining			
1059	698516	KIT, Screw/Washer			
1090	691293	RETAINER-BRUSH			
1119	691183	SCREW		(Alternator)	