






Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
163	691001	GASKET, Air Cleaner			
186B	799158	CONNECTOR, Hose		(EVAP)	
186C	845141	CONNECTOR, Hose		(EVAP)	
291	592581	THERMOSTAT			
304	591656	HOUSING, Blower		(Black)	
305	691005	SCREW		(Blower Housing)	
305A	790690	SCREW		(Blower Housing) (Blower Housing To Intake Elbow)	
431	591661	MANIFOLD, Intake		(EVAP)	
445	594201	FILTER-A/C CARTRIDGE			
467	591660	KNOB, Air Cleaner Cover			
613	690341	SCREW		(Muffler)	
703A	592584	CLIP			
918A	799160	HOSE, Vacuum		(Length 9.4 Inches)	
964	799159	CAP, Connector			
968	591658	COVER, Air Cleaner			
1040	791237	PLATE, Trim		(Black)	
1193	592577	SCREW		(Thermostat)	
1386	592580	VANE, Air			
1474	592579	STUD		Air Vane	
1475	592578	NUT		Air Vane	



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
51A	690949	GASKET, Intake			
51B	690950	GASKET, Intake			
95	690718	SCREW		(Throttle Valve)	
98	699721	KIT, Idle Speed			
104	694918	PIN-FLOAT HINGE			
105	797410	VALVE, Float Needle			
108	699723	VALVE, Choke			
117	792296	JET, Main		(Standard) (Left)(Nikki)	
117A	842627	JET, Main		(Standard) (Right)(Nikki)	
118	699457	JET, Main		(High Altitude) (Left)(Nikki)	
118A	699733	JET, Main		(High Altitude) (Right)(Nikki)	
125	796227	CARBURETOR			
130	690993	VALVE, Throttle			
131	799113	KIT, Throttle Shaft			
133	699724	FLOAT, Carburetor			
135	699729	TUBE, Fuel Transfer			
137	690994	GASKET, Float Bowl			
141	796228	KIT, Choke Shaft			
142	699726	NOZZLE, Carburetor			
150	841649	GASKET-NOZZLE			
163	691001	GASKET, Air Cleaner			
186B	799158	CONNECTOR, Hose		(EVAP)	
186C	845141	CONNECTOR, Hose		(EVAP)	
187	791766	LINE, Fuel		(Cut To Required Length)	
217	799771	SPRING, Choke Return			
231	690718	SCREW		(Choke Valve)	
240	84001895	FILTER, FUEL			
276	695410	WASHER-SEALING		Aluminum Float Bowl	
385	797409	SCREW		(Fuel Pump) (Fuel Pump Mounted To Blower Housing)	
387	808656	PUMP, Fuel			
418	795912	PLATE, Carburetor Cover			
601	691038	CLAMP, Hose		(Black)	
633	699813	SEAL, Choke/Throttle Shaft			
672	690234	GASKET, Carburetor Plate			
883	690970	GASKET, Exhaust			
918	593998	HOSE, Vacuum		(Length 3.2 Inches)	
918A	799160	HOSE, Vacuum		(Length 9.4 Inches)	
947	798779	SOLENOID, Fuel			
958	698183	VALVE-FUEL SHUT OFF		(Plastic)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
964	799159	CAP, Connector			
975	799114	BOWL, Float			
987	691000	SEAL-THROTTLE SHAFT			
1124	690988	SEAL, O-Ring		(Fuel Transfer Tube)	
1124A	841653	SEAL, O-Ring		(Fuel Transfer Tube)	
1126	690991	SCREW		(Fuel Transfer Tube)	
1127	695407	SCREW		(Float Bowl) (Float Bowl to Carburetor Body)	
1128	690990	SCREW		(Carburetor Nozzle)	
1169	690990	SCREW		(Carburetor Cover Plate)	



Copyright © Briggs & Stratton, LLC. All rights reserved.


Ref #	Part #	Description	Qty	Context Note	Foot Note
5	796231	HEAD, Cylinder		(Cylinder #1)	
5A	796232	HEAD, Cylinder		(Cylinder #2)	
7	693997	GASKET, Cylinder Head			
13	592244	SCREW		(Cylinder Head)	
33	697576	VALVE, Exhaust			
34	792200	VALVE, Intake			
35	694865	SPRING, Valve		(Intake)	
36	694865	SPRING, Valve		(Exhaust)	
42	499586	KEEPER, Valve			
45	690977	TAPPET, Valve			
50	591784	MANIFOLD, Intake			
51A	690949	GASKET, Intake			
51B	690950	GASKET, Intake			
53	690951	STUD		(Carburetor)	
54	699816	SCREW		(Intake Manifold)	
163	691001	GASKET, Air Cleaner			
186	795985	CONNECTOR, Hose		(Intake Manifold)	
192	690083	ADJUSTER, Rocker Arm			
212	695238	LINK, Throttle			
213	691021	BRACKET, Choke Control			
337	792015	PLUG, Spark			
383	19576S	WRENCH, Spark Plug			
415	794903	PLUG			
617	691917	SEAL, O-Ring		(Intake Manifold)	
635	66538S	BOOT, Spark PLug			
654	690958	NUT		(Carburetor)	
798	697890	SCREW		(Rocker Arm)	
868	690968	SEAL, Valve			
883	690970	GASKET, Exhaust			
914	691127	SCREW		(Rocker Cover)	
918	596163	HOSE, Vacuum		Used Before Code Date 19091800	
918	593641	HOSE, Vacuum		Used After Code Date 19091700	
929	695239	SCREW		(Choke Control Bracket)	
1022	690971	GASKET, Rocker Cover			
1023	793146	COVER, Rocker		(Cylinder #1)	
1023A	499600	COVER, Rocker		(Cylinder #2)	
1026	690981	ROD, Push		(Steel)	
1026A	690982	ROD, Push		(Aluminum)	
1029	690972	ARM, Rocker			
1029A	807323	ARM, Rocker			
1100	791959	PIVOT, Rocker Arm			



Copyright © Briggs & Stratton, LLC. All rights reserved.




Ref #	Part #	Description	Qty	Context Note	Foot Note
1	594371	CYLINDER ASSEMBLY			
2	797673	KIT-BUSHING/SEAL		(Magneto Side)	
3	391086S	SEAL, Oil		(Magneto Side)	
8	792185	BREATHER ASSEMBLY		Used Before Code Date 15110500	
9	690937	GASKET, Breather		Used Before Code Date 15110500	
10	691108	SCREW		(Breather Assembly)	
11	792184	TUBE-BREATHER		Used Before Code Date 15110500	
11A	594163	TUBE, Breather		Used After Code Date 15110400	
16	699701	CRANKSHAFT			
24	222698S	KEY, Flywheel			
25	793648	PISTON ASSEMBLY		(.020" Oversize)	
25	793647	PISTON ASSEMBLY		(Standard)	
26	791787	SET, Ring		(Standard)	
26	791792	SET, Ring		(.020" Oversize)	
27	690975	LOCK, Piston Pin			
28	696581	PIN, Piston		(Standard)	
29	796209	ROD, Connecting			
32	690976	SCREW		(Connecting Rod)	
45	690977	TAPPET, Valve			
46	790562	CAMSHAFT			
212	695238	LINK, Throttle			
227	798856	LEVER-GOVERNOR CONTROL			
250	690957	RETAINER, Breather		Used Before Code Date 15110500	
252	794389	COLLECTOR-OIL		Used Before Code Date 15110500	
306	796852	SHIELD-CYLINDER		(Cylinder #1)	
306A	591666	SHIELD-CYLINDER		(Cylinder #2)	
307	691003	SCREW		(Cylinder Shield)	
307A	691108	SCREW		(Cylinder Shield)	
357	691483	KEY, Drive Pulley			
377	690979	KEY, Woodruff			
405	697820	SCREW		(Back Plate) (Mounting)	
447	691003	SCREW		(Air Guide Cover)	
505	691029	NUT		(Governor Control Lever)	
540	594325	PLATE, Baffle			
562	690311	BOLT		(Governor Control Lever)	
573	593465	PLATE, Back			
584	594164	COVER, Breather Passage			
618	594326	SCREW		(Baffle Plate)	

Ref #	Part #	Description	Qty	Context Note	Foot Note
718	690959	PIN, Locating			
741	690980	GEAR, Timing			
850	100106	SEALANT, Liquid			
865	591667	COVER, Air Guide		(Valley)	
1036		Label-Emissions			
1263	594166	REED, Breather			
1264	594165	SCREW		(Breather Reed)	
1319	794467	LABEL, Warning			
1319A	797669	LABEL, Warning			
1330	273521	MANUAL, Repair			




Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
4	796307	SUMP, Engine			
12	594195	GASKET-CRANKCASE KIT			
15	690946	PLUG-OIL DRAIN			
20	795387	SEAL-OIL		(PTO Side)	
22	694966	SCREW		(Crankcase Cover/Sump)	
186A	796532	CONNECTOR, Hose		Oil Drain	
219	793338	GEAR, Governor			
220	799772	WASHER		(Governor Gear)	
221	841026	CUP, Governor			
239	792028	SWITCH, Oil Pressure			
287	697820	SCREW		(Dipstick Tube)	
404	690442	WASHER		(Governor Crank)	
415	794903	PLUG			
512	796530	HOSE, Oil Drain			
523	594528	DIPSTICK			
524	691032	SEAL, O-Ring			
525	691037	TUBE, Dipstick			
552	796638	BUSHING, Governor Crank			
552A	690553	BUSHING, Governor Crank			
615	698290	RETAINER, Governor Shaft			
616	691045	CRANK, Governor			
691	790574	SEAL-GOVERNOR SHAFT			
742	690328	RETAINER, E Ring			
750	796208	SCREW		(Oil Pump Cover)	
842	691031	SEAL, O-Ring		(Dipstick Tube)	
847	594609	DIPSTICK/TUBE ASSEMBLY			
943	796222	SEAL, O-Ring		(Oil Pump Cover)	
965	796221	COVER, Oil Pump			
1013	690954	NIPPLE, Oil Filter			
1017	796214	SCREEN, Oil Pump			
1024	796220	PUMP, Oil			
1027	492932S	FILTER, Oil		(Black)	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
3	391086S	SEAL, Oil		(Magnet Side)	
7	693997	GASKET, Cylinder Head			
9	690937	GASKET, Breather		Used Before Code Date 15110500	
12	594195	GASKET-CRANKCASE KIT			
20	795387	SEAL-OIL		(PTO Side)	
22	694966	SCREW		(Crankcase Cover/Sump)	
51	795123	GASKET, Intake			
51A	690949	GASKET, Intake			
51B	690950	GASKET, Intake			
104	694918	PIN-FLOAT HINGE			
105	797410	VALVE, Float Needle			
121	797890	KIT, Carburetor Overhaul			
137	690994	GASKET, Float Bowl			
150	841649	GASKET-NOZZLE			
163	691001	GASKET, Air Cleaner			
217	799771	SPRING, Choke Return			
276	695410	WASHER-SEALING		Aluminum Float Bowl	
358	694012	GASKET SET, Engine			
524	691032	SEAL, O-Ring			
633	699813	SEAL, Choke/Throttle Shaft			
672	690234	GASKET, Carburetor Plate			
691	790574	SEAL-GOVERNOR SHAFT			
842	691031	SEAL, O-Ring		(Dipstick Tube)	
868	690968	SEAL, Valve			
883	690970	GASKET, Exhaust			
943	796222	SEAL, O-Ring		(Oil Pump Cover)	
987	691000	SEAL-THROTTLE SHAFT			
1022	690971	GASKET, Rocker Cover			
1095	694013	GASKET SET, Valve			
1124	690988	SEAL, O-Ring		(Fuel Transfer Tube)	
1124A	841653	SEAL, O-Ring		(Fuel Transfer Tube)	



Copyright © Briggs & Stratton, LLC. All rights reserved.

Ref #	Part #	Description	Qty	Context Note	Foot Note
23A	594169	FLYWHEEL		Used After Code Date 14082400	
23A	799090	FLYWHEEL		Used Before Code Date 14082500	
73	494439	SCREEN, Rotating			
74	698425	SCREW		(Rotating Screen)	
75	691056	WASHER		(Flywheel)	
165	693148	NUT		(Ring Gear)	
188	691108	SCREW		(Control Bracket)	
209	799169	SPRING, Governor		(Dark Blue)	
211	691019	SPRING, Governed Idle		(No Color)	
216	691022	LINK, Choke		(Manual Choke)	
222	798916	BRACKET, Control		(V3 Manual Choke)	
265	691024	CLAMP, Casing			
267	792629	SCREW		(Casing Clamp)	
309	590476	MOTOR, Starter			
332	691059	NUT		(Flywheel)	
333	592846	ARMATURE, Magneto			
334	691061	SCREW		(Magneto Armature)	
363	19203	PULLER, Flywheel			
405	697820	SCREW		(Back Plate) (Mounting)	
474A	592829	ALTERNATOR		(Tri Circuit Or 5/9 Amp. Regulated)	
501	794360	REGULATOR		(5/9 Amp.)	
526	691129	SCREW		(Regulator)	
526A	691108	SCREW		(Regulator)	
563	799359	SCREW		(Debris Screen Guard)	
635	66538S	BOOT, Spark PLug			
668	691500	SPACER			
668A	691215	SPACER			
695	693149	SCREW		(Ring Gear)	
697	591909	SCREW		(Starter Motor) (Drive Cap)	
703	691010	CLIP			
703A	592584	CLIP			
726	499612	GEAR, Ring			
729	593826	CLIP, Wire			
789A	591392	HARNESS, Wiring			
851	493880S	TERMINAL-SPARK PLUG			
877	790544	WIRE/CONNECTOR, Alternator			
878	398661	HARNESS, Wiring			
878A	691955	HARNESS, Alternator			
934	593638	SCREW		(Fan Retainer)	
949	798767	GUARD, Debris Screen			

Ref #	Part #	Description	Qty	Context Note	Foot Note
1005	593640	FAN, Flywheel			
1012	592556	RETAINER, Link			
1059	698516	KIT, Screw/Washer			
1119	691183	SCREW		(Alternator)	
1448	690260	WASHER		(Magneto Armature)	