









Ref #	Part #	Description	Qty	Context Note	Foot Note
474	592830	ALTERNATOR			
501	593490	REGULATOR			
526	691129	SCREW		(Regulator)	
729	593826	CLIP, Wire			
1059	698516	KIT, Screw/Washer			
1119	691183	SCREW		(Alternator)	




Ref #	Part #	Description	Qty	Context Note	Foot Note
304	591669	HOUSING, Blower			
305	594618	SCREW		(Blower Housing)	
305A	790690	SCREW		(Blower Housing)	
431	798860	ELBOW, Intake			
445	792105	FILTER, A/C Cartridge			
467	790697	KNOB, Air Cleaner Cover			
964	799159	CAP, Connector			
968	798584	COVER, Air Cleaner			
1040	798585	PLATE, Trim			
1319	794467	LABEL, Warning		(REQUIRED When Replacing Parts With Warning Labels Affixed)	
1319A	797669	LABEL, Warning		(REQUIRED When Replacing Parts With Warning Labels Affixed)	




Ref #	Part #	Description	Qty	Context Note	Foot Note
53	690951	STUD		(Carburetor)	
93	845864	BUSHING, Throttle Shaft			
95	690718	SCREW		(Throttle Valve)	
98	699721	KIT, Idle Speed			
104	694918	PIN-FLOAT HINGE			
105	698537	VALVE, Float Needle			
108	699723	VALVE, Choke			
117	842630	JET, Main		(Standard)	
118	842082	JET, Main		(High Altitude)	
125	595627	CARBURETOR			
130	690993	VALVE, Throttle			
131	799113	KIT, Throttle Shaft			
133	699724	FLOAT, Carburetor			
135	699729	TUBE, Fuel Transfer			
137	690994	GASKET, Float Bowl			
141	796228	KIT, Choke Shaft			
142	796871	NOZZLE, Carburetor			
150	841649	GASKET-NOZZLE			
163	691001	GASKET, Air Cleaner			
186	795985	CONNECTOR, Hose			
186B	845141	CONNECTOR, Hose			
187	791766	LINE, Fuel			
217	799771	SPRING, Choke Return			
231	690718	SCREW		(Choke Valve)	
240	845125	FILTER, Fuel			
276	695410	WASHER-SEALING			
385	797409	SCREW		(Fuel Pump)	
387	808656	PUMP, Fuel			
418	795912	PLATE, Carburetor Cover			
601	691038	CLAMP, Hose			
633	699813	SEAL, Choke/Throttle Shaft			
654	690958	NUT		(Carburetor)	
672	690234	GASKET, Carburetor Plate			
703	691010	CLIP			
947	596039	SOLENOID, Fuel			
975	799114	BOWL, Float			
987	691000	SEAL-THROTTLE SHAFT			
1124	841653	SEAL, O-Ring		(Fuel Transfer Tube)	
1124A	690988	SEAL, O-Ring		(Fuel Transfer Tube)	
1126	690991	SCREW		(Fuel Transfer Tube)	








Ref #	Part #	Description	Qty	Context Note	Foot Note
1127	695407	SCREW		(Float Bowl) (Float Bowl to Carburetor Body)	
1128	690990	SCREW		(Carburetor Nozzle)	
1169	690990	SCREW		(Carburetor Cover Plate)	




Ref #	Part #	Description	Qty	Context Note	Foot Note
188	691108	SCREW		(Control Bracket)	
212	695238	LINK, Throttle			
216	796879	LINK, Choke			
222	798916	BRACKET, Control			
227	798856	LEVER-GOVERNOR CONTROL			
265	691024	CLAMP, Casing			
267	792629	SCREW		(Casing Clamp)	
318	691127	SCREW		(Mounting Bracket)	
318A	792629	SCREW		(Mounting Bracket)	
493	797176	BRACKET, Mounting			
505	691029	NUT		(Governor Control Lever)	
537	594913	KIT, Governor/Idle Spring			
562	690311	BOLT		(Governor Control Lever)	
633A	691321	SEAL-CHOKE/THR SHAFT		(Throttle Shaft)	
640	796913	WIRE ASSEMBLY		(Thermistor)	
789	796860	HARNESS, Wiring			
789A	796914	HARNESS, Wiring			
929	695239	SCREW		(Choke Control Bracket)	
929A	794904	SCREW		(Choke Control Bracket)	
1054	280275	TIE, Cable			
1436	796918	MOTOR, Stepper/Bracket			
1437	699891	SCREW		(Stepper/Bracket Motor)	
1438	796352S	MODULE, Electronic Choke			




Ref #	Part #	Description	Qty	Context Note	Foot Note
16	595707	CRANKSHAFT			
24	222698S	KEY, Flywheel			
25	793647	PISTON ASSEMBLY		(Standard)	
25	793648	PISTON ASSEMBLY		(.020" Oversize)	
26	791787	SET, Ring		(Standard)	
26	791792	SET, Ring		(.020" Oversize)	
27	690975	LOCK, Piston Pin			
28	593650	PIN, Piston			
29	796209	ROD, Connecting			
32	690976	SCREW		(Connecting Rod)	
46	796853	CAMSHAFT			
377	690980	GEAR, Timing			
741	690979	KEY, Woodruff			



Ref #	Part #	Description	Qty	Context Note	Foot Note
1	594969	CYLINDER ASSEMBLY			
2	797673	KIT-BUSHING/SEAL		(Magneto Side)	
3	391086S	SEAL, Oil		(Magneto Side)	
10	691108	SCREW		(Breather Assembly)	
11	594163	TUBE, Breather			
306	796852	SHIELD-CYLINDER			
306A	591666	SHIELD-CYLINDER			
307	691003	SCREW		(Cylinder Shield)	
307A	691108	SCREW		(Cylinder Shield)	
405	594937	SCREW		(Back Plate)	
447	691003	SCREW		(Air Guide Cover)	
540	594325	PLATE, Baffle			
573	594902	PLATE-BACK			
584	594164	COVER, Breather Passage			
618	594326	SCREW		(Baffle Plate)	
718	690959	PIN, Locating			
718A	594988	PIN, Locating			
865	591667	COVER, Air Guide			
1263	594166	REED, Breather			
1264	594165	SCREW		(Breather Reed)	




Ref #	Part #	Description	Qty	Context Note	Foot Note
5	796231	HEAD, Cylinder			
5A	796232	HEAD, Cylinder			
7	693997	GASKET, Cylinder Head			
13	592244	SCREW		(Cylinder Head)	
33	697576	VALVE, Exhaust			
34	792200	VALVE, Intake			
35	694865	SPRING, Valve		(Intake)	
36	694865	SPRING, Valve		(Exhaust)	
42	499586	KEEPER, Valve			
45	690977	TAPPET, Valve			
50	595606	MANIFOLD-INTAKE			
51	795123	GASKET, Intake			
51A	690950	GASKET, Intake			
54	699816	SCREW		(Intake Manifold)	
192	690083	ADJUSTER, Rocker Arm			
337	792015	PLUG, Spark			
613	690341	SCREW		(Muffler)	
617	594209	SEAL, O-Ring		(Intake Manifold)	
635	692076	BOOT, Spark Plug			
798	697890	SCREW		(Rocker Arm)	
868	690968	SEAL, Valve			
883	690970	GASKET, Exhaust			
914	691127	SCREW		(Rocker Cover)	
918	596163	HOSE, Vacuum		Used Before Code Date 19091800	
918	593641	HOSE, Vacuum		Used After Code Date 19091700	
1023	499600	COVER, Rocker			
1023A	793146	COVER, Rocker			
1026	690981	ROD, Push		(Steel)	
1026A	690982	ROD, Push		(Aluminum)	
1029	690972	ARM, Rocker			
1029A	807323	ARM, Rocker			
1100	791959	PIVOT, Rocker Arm			



Ref #	Part #	Description	Qty	Context Note	Foot Note
23	594169	FLYWHEEL			
73	494439	SCREEN, Rotating			
74	698425	SCREW		(Rotating Screen)	
75	691056	WASHER		(Flywheel)	
309	590476	MOTOR, Starter			
332	691059	NUT		(Flywheel)	
333	592846	ARMATURE, Magneto			
334	691061	SCREW		(Magneto Armature)	
363	19621	PULLER, Flywheel			
697	591909	SCREW		(Starter Motor) (Drive Cap)	
934	593638	SCREW		(Fan Retainer)	
1005	593640	FAN, Flywheel			

1027



847

523


842



287






525




524



Ref #	Part #	Description	Qty	Context Note	Foot Note
287	697820	SCREW		(Dipstick Tube)	
523	594528	DIPSTICK			
524	691032	SEAL, O-Ring		(Dipstick Tube)	
525	691037	TUBE, Dipstick			
842	691031	SEAL, O-Ring		(Dipstick Cap)	
847	594609	DIPSTICK/TUBE ASSEMBLY			
1027	798576	FILTER, Oil			



Ref #	Part #	Description	Qty	Context Note	Foot Note
121	797890	KIT, Carburetor Overhaul		(Service Kits may include extra parts not specific to this engine.)	
358	694012	GASKET SET, Engine		(Service Kits may include extra parts not specific to this engine.)	
363	19203	PULLER, Flywheel			
383	19576S	WRENCH, Spark Plug			
850	100106	SEALANT, Liquid			
1095	694013	GASKET SET, Valve		(Service Kits may include extra parts not specific to this engine.)	



Ref #	Part #	Description	Qty	Context Note	Foot Note
4	594974	SUMP, Engine			
15	690946	PLUG-OIL DRAIN			
20	795387	SEAL-OIL		(PTO Side)	
22	694966	SCREW		(Crankcase Cover/Sump)	
219	793338	GEAR, Governor			
220	799772	WASHER		(Governor Gear)	
221	841026	CUP, Governor			
404	690442	WASHER		(Governor Crank)	
415	794903	PLUG			
552	796638	BUSHING, Governor Crank			
552A	690553	BUSHING, Governor Crank			
615	698290	RETAINER, Governor Shaft			
616	691045	CRANK, Governor			
691	790574	SEAL-GOVERNOR SHAFT			
742	690328	RETAINER, E Ring			
750	796208	SCREW		(Oil Pump Cover)	
943	796222	SEAL, O-Ring		(Oil Pump Cover)	
965	796221	COVER, Oil Pump			
1013	690954	NIPPLE, Oil Filter			
1017	796214	SCREEN, Oil Pump			
1024	796220	PUMP, Oil			