





E0110-A590B



Ref.No	Part.No	Description	Q
130	130AA0616	BOLT-FLANGED,6X16	
130A	130AA0640	BOLT-FLANGED,6X40	
130B	130CA0875	BOLT-FLANGED,8X75	
172	172BA0818	BOLT-STUD,8X18	
214	214AA0408	SCREW-PAN+-,4X8	
11004	11004-7006	GASKET-HEAD	
11008	11008-7023	HEAD-COMP-CYLINDER,#2	
11008A	11008-7024	HEAD-COMP-CYLINDER,#1	
11022	11022-7002	CASE-ROCKER	
11022	11022-0728	CASE-ROCKER	remplacé par, voir ci-dessous
11022	11022-7029	CASE-ROCKER	remplacé par, voir ci-dessous
11022	11022-0728	CASE-ROCKER	
11060	11060-7012	GASKET,CRANKCASE COVER	remplacé par, voir ci-dessous
11060	11061-7098	GASKET,CRANKCASE COVER	
11060A	11060-7013	GASKET,ROCKER CASE	
11061	11061-7079	GASKET,BREATHER	
13271	13271-7006	PLATE	
14091	14091-7063	COVER	
16126	16126-7001	VALVE	
49015	49015-7064	COVER-CRANKCASE	
49120	49120-7092	CRANKCASE-COMP	remplacé par, voir ci-dessous
49120	49120-0881	CRANKCASE-COMP	
59071	59071-2079	JOINT	
92033	92033-7004	RING-SNAP	
92043	92043-7001	PIN	
92049	92049-7001	SEAL-OIL,RVC2 6X11X10.2	
92049A	92049-7005	SEAL-OIL,SO 8X14X5 HS	remplacé par, voir ci-dessous
92049A	92049-7019	SEAL-OIL,SO 8X14X5 HS	
92049B	92049-7011	SEAL-OIL,SD 35X62X8 L HS	
92049C	92049-7014	SEAL-OIL,SD 35X52X7 R HS	
92066	92066-7002	PLUG	remplacé par, voir ci-dessous
92066	92066-0881	PLUG	
92066	92066-0762	PLUG	remplacé par, voir ci-dessous
92066	92066-0881	PLUG	
92153	92153-7054	BOLT,8X50	

Catalog: 99907-6085 | Illustration: E0110 | Unused Positions:


E0120-A335A



Ref.No	Part.No	Description	C
13001	13001-7007	PISTON-ENGINE	
13002	13002-7001	PIN-PISTON	
13008	13008-6058	RING-SET-PISTON	
13025	13025-7002	RING-SET-PISTON L,0.50 A	
13029	13029-7003	PISTON-ENGINE L,0.50 A	
13031	13031-7048	CRANKSHAFT-COMP	
13251	13251-7016	ROD-ASSY-CONNECTING	
13251	13251-0746	ROD-ASSY-CONNECTING	
13251	13251-0048	ROD-ASSY-CONNECTING	
92033	92033-7002	RING-SNAP	
92033	92033-0780	RING-SNAP	
92033	92033-0725	RING-SNAP	
92033	92033-0780	RING-SNAP	
92151	92151-7017	BOLT,6X35	

Catalog: 99907-6085 | Illustration: E0120 | Unused Pos


E0200-A517G



Ref.No	Part.No	Description
130	130AA0616	BOLT-FLANGED,6X16
130A	130AA0620	BOLT-FLANGED,6X20
23062	23062-7019-9H	BRACKET-COMP
42036	42036-7012	SLEEVE
49019	49019-7001	FILTER FUEL
49019	49019-0027	FILTER-FUEL
49040	49040-7001	PUMP-FUEL
49040	49040-0801	PUMP-FUEL
92170	92170-2009	CLAMP
92170	92173-1582	CLAMP,11.8MM
92170A	92170-7003	CLAMP
92191	92191-7027	TUBE
92192B	92192-7135	TUBE,6.35X12.7X160
92192B	92192-2386	TUBE,6.35X12.7X160
92192B	92192-1549	TUBE,6.35X12.7X160
92192D	92192-7138	TUBE,6.35X12.7X200
92192D	92192-1553	TUBE,6.35X12.7X200


Catalog: 99907-6085 | Illustration: E0200 | Unused Positions

E0140-A320B




Ref.No	Part.No	Description
670	670D2016	O RING,16MM
13107	13107-7009	SHAFT <i>remplacé par, voir ci-dessous</i>
13107	13107-0858	SHAFT,OIL PUMP
13271	13271-7005	PLATE
14075	14075-7008	CAP-ASSY
16154	16154-7007	ROTOR-PUMP,IN
16154A	16154-7008	ROTOR-PUMP,OUT
49065	49065-2078	FILTER-OIL <i>remplacé par, voir ci-dessous</i>
49065	49065-0724	FILTER-OIL
49065	49065-7010	FILTER-OIL <i>remplacé par, voir ci-dessous</i>
49065	49065-0724	FILTER-OIL
49065A	49065-7003	FILTER-OIL
59051	59051-7011	GEAR SPUR <i>remplacé par, voir ci-dessous</i>
59051	59051-0835	GEAR-SPUR
59071	59071-7007	JOINT <i>remplacé par, voir ci-dessous</i>
59071	59071-0782	JOINT
59071	59071-7018	JOINT <i>remplacé par, voir ci-dessous</i>
59071	59071-0782	JOINT
59231	59231-7006	FILLER
92043	92043-7003	PIN
92066	92066-7003	PLUG <i>remplacé par, voir ci-dessous</i>
92066	92066-0774	PLUG
92140	92140-7003	BALL
92145	92145-7002	SPRING
92153	92153-7043	BOLT,6X12 <i>remplacé par, voir ci-dessous</i>
92153	92154-2938	BOLT,6X12

Catalog: 99907-6085 | Illustration: E0140 | Unused Posi




Ref.No	Part.No	Description
130	130AA0816	BOLT-FLANGED,8X16
13270	13270-7007	PLATE
14037	14037-7008-9H	SCREEN
14091	14091-7002	COVER
23062	23062-7005	BRACKET-COMP
49089	49089-7004	SHROUD-ENGINE
49089A	49089-7005	SHROUD-ENGINE
49089B	49089-7049	SHROUD-ENGINE
59041	59041-7003	FAN
59066	59066-7003	HOUSING-FAN
92026	92026-7007	SPACER
92153	92153-7007	BOLT
92153A	92153-7008	BOLT
92153A	92154-2823	BOLT,6MM
92153B	92153-7043	BOLT,6X12
92153B	92154-2938	BOLT,6X12
92172	92172-7029	SCREW,SOCKET,6X12

Catalog: 99907-6085 | Illustration: E0150 | Unused Positions




Ref.No	Part.No	Description
130	130AA0620	BOLT-FLANGED,6X20
510	510A5100	KEY-WOODRUFF
21066	21066-7011	REGULATOR-VOLTAGE
21171	21171-7039	COIL-ASSY-IGNITION
		remplacé par, voir ci-dessous
21171	21171-0745	COIL-ASSY-IGNITION
21171	21171-0713	COIL-ASSY-IGNITION
		remplacé par, voir ci-dessous
21171	21171-0745	COIL-ASSY-IGNITION
21193	21193-7019	FLYWHEEL-ASSY
		remplacé par, voir ci-dessous
21193	21193-0021	FLYWHEEL-ASSY
26030	26030-7002	HARNESS
26031	26031-7003	HARNESS
59031	59031-7009	COIL-CHARGING
59031A	59031-7014	COIL-CHARGING
		remplacé par, voir ci-dessous
59031A	59031-7009	COIL-CHARGING
92009	92009-2308	SCREW
		remplacé par, voir ci-dessous
92009	92172-1091	SCREW,5X12
92066	92066-7002	PLUG
		remplacé par, voir ci-dessous
92066	92066-0881	PLUG
92066	92066-0762	PLUG
		remplacé par, voir ci-dessous
92066	92066-0881	PLUG
92070	92070-2110	PLUG-SPARK,BPR2ES(NGK),SOLID
		remplacé par, voir ci-dessous
92070	BPR2ES	PLUG-SPARK,BPR2ES(NGK),SOLID
92072	92072-7003	BAND
92151	92151-2097	BOLT,12X30
		remplacé par, voir ci-dessous
92151	92154-2017	BOLT,12X30
92172	92172-7018	SCREW,5X20
92200	92200-7002	WASHER
		remplacé par, voir ci-dessous
92200	92200-2119	WASHER,12.2X40X3.0

Catalog: 99907-6085 | Illustration: E0160 | Unused Positions: strike



Ref.No	Part.No	Description
214	214AA0408	SCREW-PAN+-,4X8
311	311AA0600	NUT-HEX,6MM
411	411AA0600	WASHER-PLAIN,6MM
13107	13107-7013	SHAFT <i>remplacé par, voir ci-dessous</i>
13107	13107-0751	SHAFT
13271	13271-7032	PLATE
16169	16169-7006	LINK-CHOKE <i>remplacé par, voir ci-dessous</i>
16169	16169-0009	LINK-CHOKE
16171	16171-7016	LINK
39129	39129-7012	SPRING-GOVERNOR <i>remplacé par, voir ci-dessous</i>
39129	39129-7004	SPRING-GOVERNOR
49103	49103-7004	ARM-GOVERNOR
49113	49113-7017	PANEL-COMP-CONTROL
92145	92145-7004	SPRING <i>remplacé par, voir ci-dessous</i>
92145	92145-2180	SPRING
92145	92145-7032	SPRING <i>remplacé par, voir ci-dessous</i>
92145	92145-2180	SPRING
92145A	92145-7005	SPRING
92145B	92145-7037	SPRING <i>remplacé par, voir ci-dessous</i>
92145B	92145-7034	SPRING
92150	92150-2182	BOLT,5X18
92151	92151-7014	BOLT,5X30
92153	92153-7033	BOLT,6X35
92153A	92153-7043	BOLT,6X12 <i>remplacé par, voir ci-dessous</i>
92153A	92154-2938	BOLT,6X12
92170	92170-7001	CLAMP

Catalog: 99907-6085 | Illustration: E0170 | Unused Posi




Ref.No	Part.No	Description
130	130AA0620	BOLT-FLANGED,6X20
172	172BA06105	BOLT-STUD,6X105
214	214AA0510	SCREW-PAN+-.5X10
11009	11009-2056	GASKET
11060	11060-7011	GASKET,MANIFOLD
11060A	11060-7024	GASKET,CARBURETOR
11061	11061-7037	GASKET
11061A	11061-7038	GASKET
11061B	11061-7039	GASKET
11061C	11061-7043	GASKET
14091	14091-7031	COVER
15004	15004-7028	CARBURETOR ASSY <i>remplacé par, voir ci-dessous</i>
15004	15004-1007	CARBURETOR-ASSY
16025	16025-7003	VALVE-THROTTLE
16030	16030-7004	VALVE-FLOAT
16031	16031-7003	FLOAT
16041	16041-7021	SHAFT-CARBURETOR <i>remplacé par, voir ci-dessous</i>
16041	16041-0028	SHAFT-CARBURETOR
16041A	16041-7023	SHAFT-CARBURETOR <i>remplacé par, voir ci-dessous</i>
16041A	16041-0030	SHAFT-CARBURETOR
16073	16073-7005	INSULATOR
16126	16126-7015	VALVE
16184A	16184-7022	CHAMBER-ASSY-FLOAT
16187	16187-7002	NEEDLE-JET
21188	21188-7003	SOLENOID
59076A	59076-7011	MANIFOLD INTAKE <i>remplacé par, voir ci-dessous</i>
59076A	59076-0026	MANIFOLD-INTAKE
92009	92009-7003	SCREW
92009A	92009-7004	SCREW
92009B	92009-7006	SCREW,DRAIN
92026	92026-7011	SPACER
92043	92043-7014	PIN
92055	92055-7012	RING-O <i>remplacé par, voir ci-dessous</i>
92055	92055-7024	RING-O
92055A	92055-7013	RING-O
92055B	92055-7016	RING-O
92063B	92063-7069	JET-MAIN,#108
92063D	92063-7075	JET-MAIN,#101,3280FT
92063E	92063-7076	JET-MAIN,#098,6560FT
92063F	92063-7077	JET-MAIN,#105,3280FT
92063G	92063-7078	JET-MAIN,#102,6560FT
92063H	92063-7082	JET-MAIN,#104
92066	92066-7009	PLUG,EXPANSION
92093	92093-7001	SEAL,D=5.9
92093A	92093-7002	SEAL,D=6.9

PARTS SHIPPED LOOSE

Diagram illustrating the assembly of a mechanical component, showing various parts and their assembly sequence:


- 11065A**: Small cylindrical component.
- 11011**: Large cylindrical component with a threaded section.
- 11010**: Small cylindrical component.
- 11013**: Long cylindrical component.
- 11013A**: Short cylindrical component.
- 11011A**: Small cylindrical component.
- 92171**: Small cylindrical component.
- 92192**: Large cylindrical component.
- 92171A**: Small cylindrical component.
- 11065**: Small cylindrical component.
- 92171B**: Small cylindrical component.
- 92191**: Small cylindrical component.
- 130**: Small cylindrical component.
- 16060**: Small cylindrical component.
- 92015**: Small cylindrical component.
- 23062**: Small cylindrical component.
- 130A**: Small cylindrical component.
- 461**: Small cylindrical component.
- 92210**: Small cylindrical component.
- 11053**: Small cylindrical component.
- 92153**: Small cylindrical component.

RefNo	Part.No	Description
130	130AA06105	BOLT-FLANGED,6X105
130A	130AA0814	BOLT-FLANGED,8X14
461	461DA0800	WASHER-SPRING,8MM
11010	11010-7011	FILTER ASSY AIR <i>remplacé par, voir ci-dessous</i>
11010	11010-0970	FILTER-ASSY-AIR
11010	11010-7032	FILTER ASSY AIR <i>remplacé par, voir ci-dessous</i>
11010	11010-0970	FILTER-ASSY-AIR
11011	11011-7013	CASE AIR FILTER <i>remplacé par, voir ci-dessous</i>
11011	11011-7059	CASE-AIR FILTER
11011A	11011-7014	CASE-AIR FILTER
11013	11013-7019	ELEMENT-AIR FILTER
11013A	11013-7020	ELEMENT-AIR FILTER
11053	11053-7016	BRACKET
11060	11060-7016	GASKET,MUFFLER
11065	11065-7008	CAP
11065A	11065-7009	CAP
16060	16060-7021	PIPE INTAKE <i>remplacé par, voir ci-dessous</i>
16060	16060-0763	PIPE-INTAKE
16060	16060-7041	PIPE INTAKE <i>remplacé par, voir ci-dessous</i>
16060	16060-0763	PIPE-INTAKE
23062	23062-7009	BRACKET-COMP
92015	92015-1193	NUT <i>remplacé par, voir ci-dessous</i>
92015	92015-1367	NUT
92153	92153-7043	BOLT,6X12 <i>remplacé par, voir ci-dessous</i>
92153	92154-2938	BOLT,6X12
92171	92171-7007	CLAMP <i>remplacé par, voir ci-dessous</i>
92171	92173-7010	CLAMP
92171A	92171-7009	CLAMP
92171B	92173-7003	CLAMP <i>remplacé par, voir ci-dessous</i>
92171B	92171-7013	CLAMP
92191	92191-7006	TUBE <i>remplacé par, voir ci-dessous</i>
92191	92192-2333	TUBE
92192	92192-7030	TUBE
92210	92210-7027	NUT,M8



Ref.No	Part.No	Description
130	130AA0816	BOLT-FLANGED,8X16
13101	13101-7003	GEAR-ASSY
13101	99999-7080	STARTER-ELECTRIC
21039	21039-7004	BRUSH
21039	99999-7080	STARTER-ELECTRIC
21080	21080-7005	ARMATURE
21163	21163-7022	STARTER-ELECTRIC
21163	99999-7080	STARTER-ELECTRIC
39184	39184-7004	BRACKET-ASSY
92151	92151-7013	BOLT

Catalog: 99907-6085 | Illustration: E0210 | Unused Po



Ref.No	Part.No	Description
12004	12004-7002	VALVE-INTAKE
12005	12005-7004	VALVE-EXHAUST
12009	12009-7001	RETAINER-VALVE SPRING
12011	12011-2056	COLLET
12016	12016-7007	ARM-ROCKER
12032	12032-7001	TAPPET
13070	13070-7004	GUIDE
13070A	13070-7007	GUIDE
13116	13116-7002	ROD-PUSH
13271	13271-7007	PLATE
13271A	13271-7021	PLATE,GOVERNOR
42036	42036-7010	SLEEVE
49078	49078-7002	SPRING-ENGINE VALVE,IN
49118	49118-7017	CAMSHAFT-COMP
92009	92009-2341	SCREW
92015	92015-2253	NUT
92026	92026-7015	SPACER,16.3X25X1.37
92033	92033-7001	RING-SNAP
92033	92033-0727	RING-SNAP
92140	92140-7005	BALL
92145	92145-7001	SPRING
92145	92145-1653	SPRING
92153	92153-7019	BOLT
92200	92200-7009	WASHER,16X42X0.91
92200	92200-0945	WASHER,16X42X0.91

Catalog: 99907-6085 | Illustration: E0130 | Unused Position