




# SPARE PARTS LIST

LAWN MOWERS: CONSUMER  
WALK-BEHINDS

560 R, 2000-04



| Numéro de Pièce | Description           | Remarque         | Qté Kit équipement |
|-----------------|-----------------------|------------------|--------------------|
| 510 68 59-82    | CARTER                |                  |                    |
| 510 69 09-67    | PLAQUE                |                  |                    |
| 510 69 10-82    | CARTER                |                  |                    |
| 510 69 33-82    | CARTER                |                  |                    |
| 510 69 48-67    | OEILLET               |                  |                    |
| 511 87 47-01    | SAC                   |                  |                    |
| 511 87 85-02    | TIE STRAP PLAIN       |                  |                    |
| 511 88 39-67    | POIGNÉE               |                  |                    |
| 511 88 92-00    | ARBRE                 |                  |                    |
| 511 88 97-00    | ARBRE                 |                  |                    |
| 511 89 19-03    | POIGNÉE               |                  |                    |
| 512 73 82-67    | BOUTON                |                  |                    |
| 512 78 16-83    | ENJOLIVEUR            |                  |                    |
| 512 78 16-83    | ENJOLIVEUR            |                  |                    |
| 512 78 63-00    | COMMANDE              |                  |                    |
| 512 78 91-03    | DECAL                 |                  |                    |
| 512 79 31-67    | ÉCROU PAPILLON        |                  |                    |
| 512 79 99-67    | DOUILLE               |                  |                    |
| 513 77 24-00    | SUPPORT               |                  |                    |
| 513 86 18-00    | COUVERCLE             |                  |                    |
| 513 86 18-00    | COUVERCLE             |                  |                    |
| 513 86 20-00    | RESSORT               |                  |                    |
| 513 86 57-00    | LEVIER                |                  |                    |
| 513 86 59-00    | RESSORT               |                  |                    |
| 513 86 68-00    | CÂBLE                 |                  |                    |
| 513 93 48-01    | RAIL                  |                  |                    |
| 513 94 80-00    | RONDELLE              |                  |                    |
| 513 95 32-00    | DECAL                 |                  |                    |
| 513 96 21-00    | BUSHING               |                  |                    |
| 513 97 08-00    | ROUE                  |                  |                    |
| 513 97 08-00    | ROUE                  |                  |                    |
| 513 97 10-08    | CARTER                |                  |                    |
| 513 97 18-00    | ADAPTATEUR            | INCLUDES * ITEMS |                    |
| 513 98 00-01    | DECAL                 |                  |                    |
| 513 99 87-00    | DECAL                 |                  |                    |
| 5130508-67/3    |                       |                  |                    |
| 5139338-67/6    |                       |                  |                    |
| 514 00 53-00    | TOUCHE                |                  |                    |
| 514 02 66-00    | RONDELLE              |                  |                    |
| 514 02 66-00    | RONDELLE              |                  |                    |
| 514 66 77-09    | VIS                   |                  |                    |
| 514 71 50-00    | SANGLES               |                  |                    |
| 514 71 80-00    | ÉCROU                 |                  |                    |
| 514 71 80-00    | ÉCROU                 |                  |                    |
| 514 85 51-00    | RONDELLE D'ESPACEMENT |                  |                    |
| 514 91 34-00    | ÉCROU                 |                  |                    |
| 514 91 34-00    | ÉCROU                 |                  |                    |
| 514 91 64-00    | RONDELLE              |                  |                    |
| 514 91 67-00    | BOULON                |                  |                    |
| 514 91 97-01    | VIS                   |                  |                    |
| 514 96 79-00    | STARLOCK WASHER       |                  |                    |
| 514 96 79-00    | STARLOCK WASHER       |                  |                    |
| 514 97 53-01    | VIS                   |                  |                    |
| 514 97 53-01    | VIS                   |                  |                    |
| 514 97 53-01    | VIS                   |                  |                    |
| 514 97 53-01    | VIS                   |                  |                    |
| 514 97 53-04    | VIS                   |                  |                    |
| 514 99 23-02    | VIS                   |                  |                    |
| 514 99 45-01    | BOULON                |                  |                    |
| 515 76 80-09    | RONDELLE              |                  |                    |
| 516 62 71-01    | HOLDER                |                  |                    |
| 516 87 73-09    | SUPPORT               |                  |                    |
| 531 00 80-16    | COUTEAU               |                  |                    |
| 725 23 78-51    | VIS EHHM              |                  |                    |