





SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

560 RD, 2002-04




Numéro de Pièce	Description	Remarque	QTÉ Kit équipement
510 68 59-82	CARTER		
510 69 09-67	PLAQUE		
510 69 10-82	CARTER		
511 92 24-00	MOWER BLADE		
512 78 63-00	COMMANDE		
512 78 91-04	DECAL		
512 79 99-67	DOUILLE		
513 05 08-00	SUPPORT		
513 09 07-08	CARTER	INCLUDES ITEMS	
513 86 20-00	RESSORT		
513 86 92-00	VIS		
513 93 38-67	PROTECTOR		
513 94 80-00	RONDELLE		
513 96 21-00	BUSHING		
513 97 18-00	ADAPTATEUR	INCLUDES * ITEMS	
513 98 39-01	POULIE	INCLUDES '+' ITEMS	
513 99 87-00	DECAL		
514 00 53-00	TOUCHE		
514 00 53-00	TOUCHE		
514 66 77-09	VIS		
514 85 51-00	RONDELLE D'ESPACEMENT		
514 91 67-00	BOULON		
514 91 97-01	VIS		
514 93 13-00	RONDELLE		
514 97 53-01	VIS		
514 97 53-01	VIS		
514 97 53-01	VIS		
514 99 23-02	VIS		



POIGNEE & CONTROLES

560 RD, 2002-04

Numéro de Pièce	Description	Remarque	QTÉ Kit équipement
510 69 48-67	OEILLET		
510 69 49-67	OEILLET		
511 88 39-67	POIGNÉE		
511 89 19-03	POIGNÉE		
512 79 31-67	ÉCROU PAPILLON		
513 05 39-00	COMMANDE		
513 06 06-00	WIRE, DRIVE		
513 07 63-00	HOLDER		
513 95 31-00	DECAL		
513 95 32-00	DECAL		
514 02 66-00	RONDELLE		
514 02 66-00	RONDELLE		
514 71 50-00	SANGLES		
514 71 80-00	ÉCROU		
514 71 80-00	ÉCROU		
514 91 64-00	RONDELLE		
514 99 45-01	BOULON		
516 87 73-09	SUPPORT		
725 23 78-51	VIS EHHM		



Numéro de Pièce	Description	Remarque	Qté Kit équipement
510 69 33-82	CARTER		
511 87 85-02	TIE STRAP PLAIN		
511 88 92-00	ARBRE		
511 88 98-00	ARBRE		
511 92 60-01	SAC		
512 68 84-01	PLAQUE		
512 73 82-67	BOUTON		
512 78 14-83	ENJOLIVEUR		
512 78 16-83	ENJOLIVEUR		
512 80 34-00	GEARBOX		
513 09 08-02	LEVIER	SUPPLIED WITH * ITEMS 1	
513 77 24-00	SUPPORT		
513 80 50-00	ROUE D'ENTRAÎNEMENT'	L/H	
513 80 50-01	ROUE D'ENTRAÎNEMENT'	R/H	
513 86 18-00	COUVERCLE		
513 86 18-00	COUVERCLE		
513 86 59-00	RESSORT		
513 93 48-01	RAIL		
513 95 08-02	RESSORT		
513 97 08-00	ROUE		
513 97 09-00	ROUE		
513 98 00-01	DECAL		
514 84 85-00	BUSHING		
514 88 31-00	CLIQUET D'ENTRAÎNEMENT		
514 91 34-00	ÉCROU		
514 91 34-00	ÉCROU		
514 96 79-00	STARLOCK WASHER		
514 96 79-00	STARLOCK WASHER		
514 97 53-01	VIS		
514 97 53-01	VIS		
514 97 53-04	VIS		
531 00 80-19	COURROIE		