




SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS


580 RD, BBC, 2000-04



CHASSIS

580 RD, BBC, 2000-04

Numéro de Pièce	Description	Remarque	Qté Kit équipement
510 68 59-82	CARTER		
510 68 73-82	CARTER		
510 69 54-67	PLAQUE		
510 69 60-82	CARTER		
511 87 85-03	TIE STRAP PLAIN		
511 88 92-00	ARBRE		
511 88 95-00	ARBRE		
512 68 84-01	PLAQUE		
512 73 82-67	BOUTON		
512 77 31-67	PLAQUE		
512 77 47-01	GEARBOX		
512 77 54-00	VIS DE REGLAGE		
512 77 56-00	SUPPORT		
512 78 14-83	ENJOLIVEUR		
512 78 16-83	ENJOLIVEUR		
512 78 91-05	DECAL		
513 05 09-67	SUPPORT		
513 77 24-00	SUPPORT		
513 80 50-00	ROUE D'ENTRAÎNEMENT'	L/H	
513 80 50-01	ROUE D'ENTRAÎNEMENT'	R/H	
513 86 18-00	COUVERCLE		
513 86 18-00	COUVERCLE		
513 86 20-00	RESSORT		
513 86 57-00	LEVIER		
513 86 59-00	RESSORT		
513 86 92-00	VIS		
513 90 31-00	ADAPTATEUR		
513 90 36-00	BOULON		
513 90 37-00	VIS		
513 90 99-00	RONDELLE		
513 95 08-03	RESSORT		
513 96 21-00	BUSHING		
513 97 08-00	ROUE		
513 97 09-00	ROUE		
513 98 39-01	POULIE	INCLUDES '+' ITEMS	
513 99 87-00	DECAL		
513 99 96-00	EMBRAYAGE		
514 00 53-00	TOUCHE		
514 84 85-00	BUSHING		
514 85 51-01	DOUILLE		
514 88 31-00	CLIQUET D'ENTRAÎNEMENT		
514 91 06-00	ÉCROU		
514 91 34-00	ÉCROU		
514 91 34-00	ÉCROU		
514 91 34-00	ÉCROU		
514 91 97-01	VIS		
514 93 13-00	RONDELLE		
514 96 19-00	RONDELLE		
514 96 79-00	STARLOCK WASHER		
514 96 79-00	STARLOCK WASHER		
514 97 53-01	VIS		
514 97 53-01	VIS		
514 97 53-01	VIS		
514 97 53-01	VIS		
514 97 53-01	VIS		
514 97 53-04	VIS		
514 99 15-00	RESSORT		
514 99 23-02	VIS		
514 99 89-00	VIS		
514 99 96-01	RONDELLE		
5149108-02/8			
515 79 60-19	RONDELLE		
531 00 80-17	MOWER BLADE		
531 00 80-18	COURROIE		



Numéro de Pièce	Description	Remarque	QTÉ Kit équipement
510 68 80-82	PANNEAU		
510 68 81-82	PANNEAU		
510 69 33-82	CARTER		
510 69 48-67	OEILLET		
511 87 47-01	SAC		
511 88 39-67	POIGNÉE		
511 89 53-03	POIGNÉE		
512 77 64-67	OEILLET		
512 78 01-68	SUPPORT		
512 78 92-02	THROTTLE TRIGGER		
512 78 95-00	COMMANDE		
512 79 31-67	ÉCROU PAPILLON		
512 79 99-67	DOUILLE		
513 91 15-00	DECAL		
513 91 15-00	DECAL		
513 91 86-00	BOUCHON		
513 93 48-01	RAIL		
513 94 72-01	DECAL		
513 94 84-00	CÂBLE		
513 95 32-00	DECAL		
513 95 69-00	CONTROL PAIR		
513 95 69-00	CONTROL PAIR		
513 98 00-01	DECAL		
514 02 66-00	RONDELLE		
514 02 66-00	RONDELLE		
514 71 50-00	SANGLES		
514 71 80-00	ÉCROU		
514 71 80-00	ÉCROU		
514 86 67-02	BOUTON		
514 91 40-01	VIS		
514 91 40-02	VIS		
514 91 64-00	RONDELLE		
514 92 75-00	RONDELLE D'ESPACEMENT		
514 97 53-01	VIS		
514 99 14-00	RESSORT		
514 99 36-00	BOULON		
516 62 71-01	HOLDER		