



SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

600 RDM2, J600RDMG, 954130051,
2002-06

Référence	Numéro de Pièce	Description	Remarque	Qté Kit équipement
1	532 16 15-87	CÂBLE		
2	532 16 14-73	OEILLET		
3	532 16 45-57	ARRÊT		
4	532 08 38-16	VIS		
5	532 16 15-37	CARTER		
6	532 75 06-34	VIS		
7	532 16 08-16	COURROIE		
8	532 13 20-10	ÉCROU		
9	532 16 39-39	POULIE		
10	532 16 45-53	GUIDE DE COURROIE		
11	817 54 10-11	VIS		
12	532 07 51-92	RESSORT		
13	532 16 96-11	GEARBOX		
14	532 14 53-54	PIN RETAINING SCREW		
15	532 05 70-79	RONDELLE		
16	532 16 15-84	BARRE		
17	532 16 16-02	RESSORT		
18	532 16 45-54	RESSORT		
19	532 16 19-61	BOUTON		
20	812 00 00-22	RETAINING RING		
21	532 16 33-65	SUPPORT		
22	532 16 99-11	ROULEMENT À BILLES		
23	532 16 45-55	SUPPORT		
24	532 05 78-08	VIS		
25	532 17 00-11	PIN RETAINING SCREW		
26	532 16 64-50	PIGNON		
28	812 00 00-58	CIRCLIP		
29	532 18 05-04	PROTECTOR		
30	532 06 77-25	RONDELLE		
32	532 18 07-53	ROUE		
33	532 08 39-23	ÉCROU		
34	532 05 71-43	RONDELLE		
35	532 16 45-52	ARBRE		
36	532 16 45-50	ARBRE		
37	532 16 14-63	SUPPORT		
38	532 16 34-09	VIS		
39	532 70 02-79	COLLIER DE SERRAGE		
40	532 14 35-93	ROUE		
41	532 15 01-82	ENJOLIVEUR		
42	819 57 22-16	RONDELLE		
44	532 05 21-60	RONDELLE		
45	532 06 23-35	RONDELLE		
46	532 08 81-18	RONDELLE		

Référence	Numéro de Pièce	Description	Remarque	Qté Kit équipement
1	532 16 71-63	POIGNÉE		
2	532 16 45-56	POIGNÉE		
3	532 13 10-36	OEILLET		
4	532 17 95-85	HOLDER		
5	532 13 20-04	ÉCROU		
6	532 06 64-26	HOOP		
7	532 13 19-59	BOULON		
8	532 08 76-92	BOUTON		
9	532 16 42-65	POIGNÉE		
10	532 16 15-51	BOULON		
11	873 99 05-00	ÉCROU		
12	532 05 17-93	PIN RETAINING SCREW		
13	532 13 31-07	CÂBLE		
14	532 12 51-62	PLAQUE		
15	532 08 38-16	VIS		
16	532 16 20-85	CARTER		
17	532 17 98-85	LIST, SEAL		
18	532 18 27-78	BOUCHON		
19	532 16 34-24	CARTER		
20	532 16 45-48	SUPPORT		
21	532 16 93-06	SUPPORT		
22	532 15 00-78	VIS		
23	532 16 31-83	BOULON		
24	532 06 31-24	ÉCROU		
25	532 16 13-33	PLAQUE		
26	532 16 34-09	VIS		
27	532 08 38-16	VIS		
28	532 11 11-90	COUVERCLE		
29	532 18 20-02	ÉCRAN		
30	532 85 15-14	BLADE ADAPTOR		
31	532 17 50-52	MOWER BLADE		
32	532 85 10-74	RONDELLE		
33	532 85 02-63	RONDELLE		
34	532 85 10-84	VIS		
35	532 08 45-96	POULIE		
36	532 08 76-77	TOUCHE		
37	532 15 04-06	BOULON		
39	532 18 36-22	SAC		
40	532 18 00-26	CADRE		
41	532 14 49-29	VIS		
42	532 18 21-54	GASREGLAGE		
43	532 18 21-66	DECAL		
44	532 05 45-83	VIS		
45	532 06 36-01	ÉCROU		
--	532 18 21-34	DECALC."WARNING"		
--	532 16 68-32	OPERATORS MANUAL		
--	532 16 68-33	OPERATORS MANUAL		