




SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

600 SD, J600SDE, 954130050, 2001-03

REPAIR PARTS

ROTARY LAWN MOWER --- MODEL NO. 600SD (J600SDE), PRODUCT NO. 954 13 00-50

GEAR CASE ASSEMBLY PART NUMBER 532702511


BOITE DE VITESSE

600 SD, J600SDE, 954130050, 2001-03

Référence	Numéro de Pièce	Description	Remarque	Qté Kit équipement
1	817 49 04-16	VIS		
2	532 14 02-69	SUPPORT		
3	532 13 70-53	SHIFTER		
4	532 05 70-72	JOINT		
6	532 04 83-73	GEAR CASE		
7	532 07 78-81	ROULEMENT		
8	532 13 70-51	ARBRE		
9	532 13 70-74	ARBRE		
--	532 13 70-77	ARBRE		
10	532 05 70-79	RONDELLE		
11	532 13 14-84	LEVIER		
12	532 70 03-43	BUSHING		
13	532 08 64-47	BOUCHON		
14	532 13 70-50	ENGRENAGE		
15	532 75 04-36	EMBAYAGE		
16	532 75 03-69	GRAISSE		
17	812 00 00-03	RETAINING RING		
18	532 85 08-48	TOUCHE		
19	532 12 54-41	RESSORT		

REPAIR PARTS


ROTARY LAWN MOWER - - MODEL NO. 600SD (J600SDE), PRODUCT NO. 954 13 00-50



Référence	Numéro de Pièce	Description	Remarque	Qté Kit équipement
1	532 14 57-55	COMMANDE		
2	532 15 87-55	VIS		
3	532 75 11-52	ÉCROU		
4	532 05 71-43	RONDELLE		
5	532 14 65-27	COURROIE		
6	532 75 00-97	SCREW HEX HEAD RL508A/B		
8	532 13 28-00	BOUTON		
9	532 15 04-95	PIN RETAINING SCREW		
10	532 15 24-65	WHEEL KIT		
11	532 15 24-63	WHEEL KIT		
12	532 08 80-80	DUST PROTECTION		
13	532 13 70-54	PIGNON		
14	812 00 00-58	CIRCLIP		
15	532 80 11-56	ROUE		
19	532 80 11-53	ENJOLIVEUR		
20	532 08 60-12	ARBRE		
22	532 13 70-90	RESSORT		
23	532 70 25-11	GEARBOX		
25	532 07 51-92	RESSORT		
26	532 06 77-25	RONDELLE		
27	532 13 70-52	POULIE		
28	532 13 20-10	ÉCROU		
32	532 13 70-88	CARTER		
34	532 14 60-72	VIS		
36	532 08 39-23	ÉCROU		
37	532 06 36-01	ÉCROU		
--	532 16 10-57	DECAL		

REPAIR PARTS

ROTARY LAWN MOWER - - MODEL NO. 600SD (J600SDE), PRODUCT NO. 954 13 00-50



Référence	Numéro de Pièce	Description	Remarque	Qté Kit équipement
1	532 14 57-94	LEVIER		
2	532 16 42-65	POIGNÉE		
3	532 16 71-63	POIGNÉE		
5	532 05 71-43	RONDELLE		
7	532 13 63-76	BOUTON		
8	532 06 36-01	ÉCROU		
9	532 06 64-26	HOOP		
11	532 15 36-38	GUIDE		
12	532 06 91-80	ÉCROU		
13	532 16 69-71	GASREGLAGE		
14	532 14 49-29	VIS		
15	532 15 36-05	POIGNÉE		
16	532 13 19-59	BOULON		
17	532 05 17-93	PIN RETAINING SCREW		
26	532 14 72-86	BARRE		
27	532 08 75-89	RESSORT		
28	532 08 75-93	SUPPORT		
29	532 75 01-49	PROTECTEUR		
30	532 80 11-53	ENJOLIVEUR		
33	532 75 05-50	ROUE		
34	532 14 27-48	BOULON		
35	532 06 23-35	RONDELLE		
36	532 15 12-54	ARBRE		
37	532 13 28-00	BOUTON		
38	532 12 52-59	RESSORT		
40	532 14 66-30	RONDELLE D'ESPACEMENT		
41	532 13 43-40	SUPPORT		
42	532 13 43-41	SUPPORT		
43	532 17 09-77	SUPPORT		
44	532 17 09-75	SUPPORT		
45	532 17 04-99	CHÂSSIS		
47	532 14 97-41	VIS		
48	532 75 15-92	LOCKNUT 3/8-16 RL508A/B		
52	532 12 50-78	RONDELLE		
53	532 13 46-12	PROTECTEUR NPCREMP:532048283*		
54	532 15 04-06	BOULON		
55	532 85 10-84	VIS		
56	532 85 02-63	RONDELLE		
57	532 85 10-74	RONDELLE		
58	532 85 09-73	COUTEAU		
59	532 85 15-14	BLADE ADAPTOR		
61	532 17 04-91	PLAQUE		
66	532 08 45-96	POULIE		
67	532 08 76-77	TOUCHE		
71	532 15 41-47	PROTECTOR		
72	532 08 58-25	VIS		
74	532 14 54-94	DECAL		
81	532 08 39-23	ÉCROU		
82	532 13 31-07	CÂBLE		
83	532 11 11-90	COUVERCLE		
84	532 08 38-16	VIS		
85	817 60 04-06	VIS		
86	532 12 84-15	RIVET		
--	532 12 53-81	DÉFLECTEUR D'AIR		
--	532 16 87-11	MANUAL D'UTILISATION		
--	532 16 87-10	MANUAL D'UTILISATION		
--	GCK5000	9540518-01 GRASS CATCHER		
--	MK22SD			