





SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

LM 2040 H, 2003-01



compl 964 90 10-01



Numéro de Pièce	Description	Remarque	QTÉ Kit équipement
293 88 76-01	RACLOIR		
293 88 79-01	CROCHET		
293 88 82-01	SAC D'ACCESSOIRES		
295 61 32-02	ROUE		
295 61 32-02	ROUE		
295 61 33-01	WHEEL COVER GREY		
295 61 33-01	WHEEL COVER GREY		
295 64 73-01	ARBRE		
295 64 73-01	ARBRE		
295 65 58-01	ROULEMENT		
295 65 58-01	ROULEMENT		
295 65 69-01	ROULEAU		
295 66 83-01	CARTER		
371 16 78-01	BOUTON		
371 16 78-01	BOUTON		
371 37 91-01	SLIDE LOCK		
371 37 91-01	SLIDE LOCK		
371 37 96-03	POIGNÉE		
371 39 58-01	RESSORT		
371 39 58-01	RESSORT		
371 39 63-03	OEILLET		
371 39 63-03	OEILLET		
371 39 67-33	SUPPORT		
371 39 67-34	SUPPORT		
371 39 71-05	POIGNÉE		
371 39 75-22	MOWER BLADE		
371 39 93-01	ROLLER HOLDER		
371 39 93-01	ROLLER HOLDER		
371 90 01-01	DOUILLE		
371 90 01-01	DOUILLE		
371 90 07-01	BOULON		
371 90 07-01	BOULON		
371 90 20-01	POIGNÉE		
371 90 20-01	POIGNÉE		
371 90 21-01	LOCKING DISC		
371 90 21-01	LOCKING DISC		
371 90 61-01	ENGRENAGE		
371 90 62-01	ENGRENAGE		
371 90 74-01	VIS		
371 90 74-01	VIS		
371 91 33-22	COUTEAU		
371 91 42-01	COLLIER DE SERRAGE		
371 91 42-01	COLLIER DE SERRAGE		
371 91 44-01	DISQUE		
371 91 44-01	DISQUE		
371 92 64-14	PROTECTOR		
371 92 64-14	PROTECTOR		
725 23 79-51	VIS EHHM		
725 23 79-51	VIS EHHM		
725 23 79-51	VIS EHHM		
725 23 80-51	VIS EHHM		
732 21 16-01	ÉCROU		
732 21 16-01	ÉCROU		
732 21 16-01	ÉCROU		
964 90 10-01	GRASS CATCHER UNIVERSAL FOR AL		