




SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS


LM 2156 CMDA, 96141022302, 2010-05



CHASSIS

LM 2156 CMDA, 96141022302, 2010-05

Référence	Numéro de Pièce	Description	Remarque	QTÉ Kit équipement
1	532 18 45-76	DEMI-POIGNÉE	Includes Foam Grip	
2	532 42 96-43	CÂBLE		
3	532 43 00-34	SUPPORT		
4	532 14 50-06	COLLIER DE SERRAGE		
6	532 18 23-98	BOUTON		
7	532 75 06-34	VIS		
8	532 42 65-05	CONTRÔLE DE PRESENCE DE L'OPERATEUR		
9	532 42 63-00	DOOR ASY		
10	532 42 30-63	RONDELLE		
11	532 42 55-75	HAIR PIN COTTER		
12	532 19 19-38	BOUTON		
17	532 42 73-07	PLAQUE		
18	532 13 20-04	ÉCROU		
19	532 19 47-88	GUIDE		
20	532 42 24-67	PROTECTEUR		
21	532 41 99-49	RESSORT		
22	532 14 18-41	VIS		
24	532 41 99-48	RESSORT		
25	532 40 91-49	ÉCROU		
26	532 41 99-45	VIS		
27	532 43 27-47	ROUE		
28	872 25 05-05	BOULON		
30	532 41 38-08	ÉCROU		
31	532 43 18-93	BOUTON		
32	532 41 99-44	CLIQUET DE VERROUILLAGE		
33	532 42 33-56	MULCH DOOR		
34	532 42 61-25	PIVOT		
35	532 43 11-31	ROUE D'AJUSTEMENT	Includes Knob and Pushnut	
36	532 17 57-35	CHARNIÈRE		
37	532 42 88-67	BOULON		
38	532 42 61-29	DÉFLECTEUR		
39	532 43 00-39	SUPPORT		
40	532 43 00-33	SUPPORT		
41	532 15 04-06	BOULON		
42	532 19 30-00	CHARNIÈRE		
43	532 19 17-30	ÉCROU		
44	532 43 06-72	CARTER		
45	532 17 56-50	BARRE		
46	532 42 17-82	ADAPTATEUR		
47	532 42 27-06	COUTEAU		
48	532 85 10-74	RONDELLE		
49	532 85 02-63	RONDELLE		
50	532 85 10-84	VIS		
51	532 43 05-99	PLAQUE		
52	532 18 21-66	DECAL		
53	817 00 05-10	BOULON		
54	532 08 83-48	RONDELLE		
55	532 19 17-30	ÉCROU		
56	817 41 13-12	VIS		
57	532 15 53-77	ÉCROU		
58	532 42 60-72	DEMI-POIGNÉE		
59	532 19 15-74	HANDLE BOLT		
62	532 43 50-59	SUPPORT		
63	532 17 88-48	VIS		
64	000 00 00-00	W/O DESCRIPTION	B&S 12S902-1368-EA	
65	532 19 74-80	JOINT TORIQUE		
68	532 43 11-34	ROUE D'AJUSTEMENT	Includes Knob and Pushnut	
70	532 18 27-48	POIGNÉE		
84	532 42 81-24	FASTENER		
96	532 19 79-91	COLLIER DE SERRAGE		



Référence	Numéro de Pièce	Description	Remarque	Qté Kit équipement
1	532 43 13-81	COMMANDE	Includes Cable	
2	532 43 16-39	CARTER		
3	532 43 22-86	CAM		
4	532 42 03-78	SUPPORT		
5	532 42 03-81	RESSORT		
6	532 43 22-73	BUSHING		
7	532 43 32-96	CARTER		
8	532 43 32-98	LEVIER DE COMMANDE		
9	532 43 16-49	CÂBLE		
10	532 43 27-90	SUPPORT		
11	532 40 25-67	ROUE		
12	812 00 00-58	CIRCLIP		
13	532 40 38-49	PIGNON		
14	532 18 94-03	PARE-POUSSIÈRE		
15	532 40 48-45	PAWL, DRIVE		
16	532 06 77-25	RONDELLE		
17	532 41 38-08	ÉCROU		
18	532 43 18-95	BOUTON		
25	532 43 17-11	SUPPORT		
26	532 16 34-09	VIS		
28	532 43 26-75	DRIVE COVER	Includes Mounting Screw and Pushnut	
29	532 40 91-48	ÉCROU		
32	532 19 40-18	POULIE		
33	532 42 66-09	COURROIE EN V		
35	532 43 11-24	ROUE D'AJUSTEMENT	Includes Black Knob and Pushnut	
36	532 42 46-57	BOITE A VITESSE		
38	532 19 17-30	ÉCROU		
40	532 40 65-58	RESSORT		
41	532 43 11-21	ROUE D'AJUSTEMENT	Includes Black Knob and Pushnut	
54	532 43 15-55	GRASSBAG		
57	532 41 99-51	GRASSBAG		
80	532 42 11-14	WATER CONNECTOR		
81	532 41 97-35	HOSE FITTING		
82	532 41 55-85	RONDELLE DE BLOCAGE		
83	532 41 55-86	LOCKING NUT		
20	532 18 16-98	VIS		
84	532 43 20-66	ADAPTATEUR		